


AUDIO

Цепь	Конт.
+3.3V	1
GND	2
	3
	4
DMC0	5
DMC1	6
DMC2	7
DMC3	8
DMC4	9
DMC5	10
DMC6	11
SOUT1	13
SOUT0	14
SOUT3	15
SOUT2	16
SOUT5	17
SOUT4	18



KEY

Цепь	Конт.
GND	1
VCC	2
	3
KEY3	4
KEY1	5
KEY4	6
KEY0	7
KEY5	8
KEY2	9
KEY6	10
	11
KEY7	12
	13
KEY8	14
	15
KEY9	16
	17
KEY10	18
	19
KEY11	20
KEY12	21
KEY13	24
	25
KEY14	26
	27
KEY15	28
	29
KEY16	30
COIN_INP	31
KEY17	32
KEY20	33
KEY18	34
	35
KEY19	36
GND	37
+3.3V	38
+3.3V	39
+3.3V	40

