```
Function: OCOHan
                                                 interrupt 8 void OCOHan(void) {
                        PSHA >
                                                 unsigned char i;
 0000 36
                 [2]
                              #4
  0001 C604
                        LDAB
                                                   Debug Profile (4);
                  [I]
                                                   PTT PTT0 = 1;
  0003 87
                        CLRA
                  [1]
  0004 0700
                        BSR
                              Debug Profile
                                                   TFL\overline{G}1 = 0x01;
                  [4]
                                                                        // ack
  0006 1c000001
                 [4]
                        BSET
                               PTT,#1
                                                   TC0 = TC0 + 24000;
                              #1
                                                   for(i=0; i<=BackData; i++){
  000a c601
                        LDAB
                 [1]
                              _TFLG1
  000c 5b00
                        STAB
                                                     if (RxFifo Put (i) == 0) {
                  [2]
  000e dc00
                  [3]
                        LDD
                               TCO
                                                       NumLost++;
                 [2]
                              #24000
                                                     }
  0010 c35dc0
                        ADDD
                        STD
  0013 5c00
                  121
                               TCO
 1015 6980
                              0,SP
                  [2]
                        CLR
                                                   BackData++;
  0017 2011
                               *+19 ; 002a
                                                   if(BackData=10){
    BackData = 0; // 0 to 9
                        BRA
                  [3]
                        LDAB
                              O,SP
                  [3]
 ш19 е680
                              RxFifo Put
D,*+10 ; 0028
  001b 160000
                 [4]
                        JSR
  001e 046407
                        TBNE
                                                   PTT PTT0 = 0;
                  [3]
  0021 fe0000
                 [3]
                        LDX
                              NumLost
  0024 08
                        INX
                 [1]
                              NumLost
  0025 7e0000
                        STY
  0028 6280
                  [3]
                        INC
                              O,SP_
  002a F60000
                        LDAR
                              BackData
  002d e180
                  [3]
                        CMPB
                              0.SP
  002f 24e8
                [3/1]
                        BCC
                              *-22 ; 0019
  0031 720000
                        INC
                              BackData
                 [4]
  0034 f60000
                 [3]
                        LDAB
                              BackData
  0037 c10a
                        CMPB
                              #10
                 [1]
  0039 2603
                [3/1]
                        BNE
                               *+5 ; 003e
  003b 790000
                 [3]
                        CLR
                              BackData
  003e 1d000001
                        BCLR
                               PTT,#1
0042 32
                 [3]
                        PULA
  0043 0b
                 [8]
                        RTI
```

PTT_PTT0=1 takes 4 cycles.