// File ********Timer.h********
// Timer wait routine, 9S12DP512

```
Page: 1
```

```
// assumes PLL is active and E clock is 24 \ensuremath{\text{MHz}}
// TCNT will become 1.5MHz
// Jonathan W. Valvano 1/27/09
// This example accompanies the books
//
    "Embedded Microcomputer Systems: Real Time Interfacing",
//
          Thomson Engineering, copyright (c) 2006,
//
    "Introduction to Embedded Microcomputer Systems:
//
     Motorola 6811 and 6812 Simulation", Thomson, copyright (c) 2002
// Copyright 2007 by Jonathan W. Valvano, valvano@mail.utexas.edu
     You may use, edit, run or distribute this file
     as long as the above copyright notice remains
//----Timer_Init-----
// activate TCNT at 1.5 MHz
// inputs: none
// outputs: none
void Timer_Init(void);
//----Timer_Wait-----
// fixed time delay
// inputs: time to wait in 667ns cycles
// outputs: none
void Timer_Wait(unsigned short delay);
//----Timer_Wait1ms-----
// fixed time delay
// inputs: time to wait in ms
// outputs: none
// 1500 cycles equals 1ms
void Timer_Wait1ms(unsigned short delay);
//----Timer_Wait10ms-----
// fixed time delay
// inputs: time to wait in 10ms
// outputs: none
// 15000 cycles equals 10ms
void Timer_Wait10ms(unsigned short delay);
```