

Mills-Operation, Playwright Test Report

Run started 8/30/2026, 1:47:54 AM, finished 8/30/2026, 1:50:04 AM. Overall result: passed.

48

TOTAL

48

PASSED

0

FAILED

0

FLAKY

0

SKIPPED

api.spec.js

18 of 18 passed

TEST	STATUS	DURATION
Backend API, held out test data > GET /api/meta returns the real evaluated model numbers	Passed	358ms
Backend API, held out test data > GET /api/fleet returns all 6 stands with sensor readings	Passed	44ms
Backend API, held out test data > GET /api/stands/{id}/timeseries returns downsampled points and alert bands	Passed	53ms
Backend API, held out test data > GET /api/stands/{id}/summary returns ground truth failures for the test window	Passed	19ms
Backend API, held out test data > an unknown stand id returns 404, not a 500 or a silent empty result	Passed	14ms
Backend API, live data > GET /api/live/fleet reflects the running live feed, not the static test set	Passed	12ms
Backend API, live data > GET /api/live/data-bounds returns a real earliest selectable date	Passed	366ms
Backend API, live data > GET /api/live/stands/{id}/timeseries with no range returns the live buffer	Passed	12ms
Backend API, live data > GET /api/live/stands/{id}/timeseries with a range reaching into history pulls both sets	Passed	72.70s
Backend API, live data > GET /api/live/stands/{id}/summary has no ground truth list, live data has no answer key	Passed	12ms
Backend API, live data > POST /api/live/ask answers a free text fleet question grounded in real data	Passed	23ms
Backend API, live data > POST /api/stands/{id}/explain and /api/live/stands/{id}/explain both return grounded text	Passed	23ms
Backend API, degradation simulator > GET /api/simulator/state returns baseline values and the real alert threshold	Passed	18ms
Backend API, degradation simulator > POST /api/simulator/correlate moves every signal toward the same failure point	Passed	15ms
Backend API, degradation simulator > correlate rejects a signal name that is not one of the five real signals	Passed	13ms
Backend API, degradation simulator > a full start, tick, tick cycle scores real minutes and reaches the failure target	Passed	208ms
Backend API, degradation simulator > ticking with no active run returns 400, not a crash	Passed	30ms
Backend API, degradation simulator > reset clears an in progress run back to normal baseline values	Passed	87ms

copilot-extra.spec.js

3 of 3 passed

TEST	STATUS	DURATION
Copilot extras > the clear chat button is hidden until there is a conversation, then empties it	Passed	4.53s
Copilot extras > switching to another tab and back keeps the conversation intact	Passed	1.77s
Copilot extras > the send button is disabled with an empty question	Passed	1.03s

dashboard.spec.js

5 of 5 passed

TEST	STATUS	DURATION
Mills-Operation reliability console > loads and shows fleet status for all 6 stands	Passed	750ms
Mills-Operation reliability console > shows real detection performance numbers, not placeholders	Passed	904ms
Mills-Operation reliability console > selecting a stand renders its signal charts with real content	Passed	1.33s
Mills-Operation reliability console > copilot tab produces a real explanation for the selected stand	Passed	1.21s
Mills-Operation reliability console > fleet copilot chat answers a free-text question and keeps history visible	Passed	1.59s

fleet.spec.js

5 of 5 passed

TEST	STATUS	DURATION
Fleet landing and navigation > landing page shows the title, all 6 stand cards, and no tab bar	Passed	715ms
Fleet landing and navigation > each stand card shows a status badge and live sensor readings	Passed	685ms
Fleet landing and navigation > the model performance panel shows real numbers, not placeholders	Passed	704ms
Fleet landing and navigation > opening a stand reveals the tab bar and back button, closing it returns to the fleet	Passed	1.17s
Fleet landing and navigation > picking a different stand from the fleet updates the detail view	Passed	1.71s

live-monitor.spec.js

6 of 6 passed

TEST	STATUS	DURATION
Live monitor tab > all 5 signal charts render with real drawn content, not just an empty container	Passed	1.40s
Live monitor tab > the current readings panel matches the selected stand	Passed	1.25s
Live monitor tab > the date range filter defaults to Today and switches presets	Passed	1.51s
Live monitor tab > custom range reveals two date pickers bounded by the real data window	Passed	1.37s
Live monitor tab > the mini fleet panel switches stands without returning to the landing page	Passed	1.45s
Live monitor tab > closing and reopening the mini fleet panel works	Passed	1.52s

simulator.spec.js

7 of 7 passed

TEST	STATUS	DURATION
Degradation simulator > starts on the editable Signal values panel, not a live readout	Passed	1.35s
Degradation simulator > editing one signal by hand correlates the other four	Passed	1.54s
Degradation simulator > the duration caption shows how many real seconds a run will take	Passed	1.55s
Degradation simulator > starting a run switches to a live, ticking readings panel	Passed	2.44s
Degradation simulator > a full run reaches the failure targets and trips an alert	Passed	7.94s
Degradation simulator > reset returns to the editable panel and clears the run history	Passed	6.60s
Degradation simulator > the duration input rejects non positive values	Passed	1.59s

sound.spec.js

4 of 4 passed

TEST	STATUS	DURATION
Sound toggle > starts muted, since audio cannot legally autoplay before a user gesture	Passed	247ms
Sound toggle > a plain click turns sound on, and a second click turns it back off	Passed	953ms
Sound toggle > dragging the button repositions it and does not toggle the mute state	Passed	507ms
Sound toggle > the dragged position is remembered across a reload	Passed	548ms