MOMIX PRO

Owner’ s manual

MOMIX PRO

INTRODUCTION

MOMIX PRO is an audio mixer for portable devices’ recording and live streaming, you can connect it to microphone, guitars, keyboard, electronic drum sets and more, and 2 stereo line-level input Jacks for your multi-media equipments. Just set up the instruments, vocal volume of the MOMIX PRO and select the magnitude of REVERB effects properly, connect the headphone or amp to it, and it can monitor well.

MOMIX PRO features built-in lithium battery, you can also charge your smart phone via MOMIX PRO when it’s been charged simultaneously, facilitating live streaming or recording outdoors, your smart phone will have much longer battery life.

When you’re composing songs or want to use guitar tone apps, just turn on GarageBand or similar types of apps, and use it with MOMIX PRO, besides, MOMIX PRO is suitable for singing and live streaming, just turn on MOMIX PRO’s CENTER CANCEL function and reduce the original vocal volume of playback music, making your vocal prominent.

If you need audio-to-video synchronization, MOMIX PRO can output the stereo audio to your smart phone in real time, it’s perfect for composing songs, live streamer’s instrumental performance/karaoke, musicians’ recording performances, making the present music performance much more convenient and versatile!

Panel



1.OTG 2 Secondary port: for connecting MOMIX PRO to smart phone or PC, you can charge the smart phone via it.

2.Charge port: for charging (5V 2000mA)

3.OTG 1 Primary port: for connecting MOMIX PRO to smart phone or PC, you can charge the smart phone via it.(It fits for guitar tone apps, pls refer to No.18 for detailed operations.)

4.CH2 48V phantom power switch: for turning on/off the phantom power, the phantom power is turned on when the green LED is on. Remember to turn on the 48V phantom power when you’re using the condenser mic via the CH1 Jack.(*Don’t turn on the 48V phantom power when you’re using the moving coil mic, so as not to damage the mic.)

5.CH2 Channel Input Jack: 2 in 1 Jack for 6.35mm and XLR, for connecting to mic, guitar and more.

6.CH2 Guitar mode switch: Press this button when you connect electric guitar, electric bass or other high-impedance instruments via the CH2 Jack, it indicates the high impedance Input Mode is turned on when the green LED is on.

7.CH1 REVERB effects selection switch: for selecting the magnitude of REVERB effects, green, yellow and red indicate small, middle, large effects respectively, it indicates the REVERB is off when the LED is off.

8.CH2 Channel Gain Control Knob: for controlling the Gain of CH2 Input Jack, the external layer of LED is in green normally, if the red LED is on, it indicates the input signals are too large, you should reduce the Gain accordingly.

9.MAIN Volume Control Knob: for controlling the Volume of MAIN Output Jack, the external layer of LED is in green normally, if the red LED is on, it indicates the input signals are too large, you should reduce the Gain accordingly.

10.MAIN OUT Jack: 6.35mm Stereo Output Jack, for connecting to the amps.

11.CH1 48V phantom power switch: for turning on/off the phantom power, the phantom power is turned on when the green LED is on. Remember to turn on the 48V phantom power when you’re using the condenser mic via the CH1 Jack.(*Don’t turn on the 48V phantom power when you’re using the moving coil mic, so as not to damage the mic.)

12.Power switch: long press it to turn on/off the power, the button features red and green LED, the audio mixer is in low-battery condition if the red LED is on while using, pls charge it in time, the red LED will be off once fully charged.

13.CH1 Channel Input Jack: 2 in 1 Jack for 6.35mm and XLR, for connecting to mic, guitar and more.

14.CH1 Guitar Mode Switch: pls press this button(the LED will be on)to turn on the high impedance Input Mode when using electric guitar, electric bass or other high impedance instruments via the CH1 Jack.

15.CH1 Channel Gain Control Knob: for controlling the Gain of CH1 Input Jack, the external layer of LED is in green normally, if the red LED is on, it indicates the input signals are too large, you should reduce the Gain accordingly.

16.CH2 REVERB Effects Selection Switch: for selecting the magnitude of REVERB effects, green, yellow and red indicate small, middle, large effects respectively, it indicates the REVERB is off when the LED is off.

17.INSTRUMENT Jack Gain Control Knob: for controlling the Gain of INSTRUMENT Jack, the external layer of LED is in green normally, if the red LED is on, it indicates the input signals are too large, you should reduce the Gain accordingly.

18.Monitor Mode Selection Button: the LED is on once it’s been activated, you can DIRECT MONITOR now, meanwhile, turn on LOOPBACK function, both DIRECT MONITOR and LOOPBACK are turned off once the LED is off, pls turn off this Monitor mode so as to avoid background noise while using guitar tone apps.

19.INSTRUMENT Jack: 6.35mm stereo Input Jack, for connecting to multi-effects processor, electronic drum sets, keyboards, etc.

20.MONITOR Volume Control Knob: for controlling the Volume of Headphone Out.

21.AUX IN Jack: can connect to smart phone or other portable devices for playing backing track.

22.CENTER CANCEL Switch: when it’s been turned on, it can reduce the volume of the main vocal.

23.MONITOR 1 Jack: Headphone Out Jack

24.MONITOR 2 Jack: Headphone Out Jack

25.Smart phone Headset Jack: fits for smart phone 4 pin earphone (*The earphone mic is controlled by CH2 Channel)

CONNECTION DIAGRAMS



SPECIFICATIONS

Dimensions: 140mmx84mmx45mm
Weight: 203g
Charging current: 800mA
Power: Type-C 5V/2A
Max Output Current: 1A

Input Impedance and Sensitivity

2 in 1 Jack for mic and guitar:
3.6K-45dBV(low impedance)
470K -45dBV(high impedance)
INS : 10K-10dBV
LINE IN : 10K -10dBV
Output level: 0dBV
Headphone Output: 0dBV

ACCESSORIES

USB cable X1
Type-C Male to Male cables X2
Smart phone port converter X2
Type-C to 3.5mm audio cable X1

JOYO TECHNOLOGY CO., LTD

Address:2/F, Lushi Industry Building, 28th District, Bao’an, Shenzhen, 518133 China.

www.joyoaudio.com

Email:info@joyoaudio.com

Tel: 0086-755-29765381