



Windows



Android



iOS / iPadOS



Routers



Router Config Tips

Corporate Firewalls

Teltonika Networks

MikroTik

OpenWRT

OPNsense

Ubiquiti

Route between ZeroTier and

Physical Networks

VPN



IoT



OS / Platform Notes



Routers



MikroTik

MikroTik

MikroTik maintains a [ZeroTier package](#) for their line of networking products.



MIKROTIK AND ZEROTIER

Choosing a model

For best performance it is recommended that you choose a model that has a `64-bit ARM` chip (arm64). **Not 32-bit ARM**. 32-bit ARM devices will work but with significantly reduced performance. Currently no `MIPS` ZeroTier package exists for MikroTik devices.



NOTE

If you're an enterprise-sized entity looking to integrate MikroTik + ZeroTier we'd recommend getting some guidance from [IP ArchiTechs](#) who are very familiar with the performance characteristics of various models and can help design a solution for you.

Troubleshooting

Since MikroTik developed and maintains the ZeroTier package themselves you may need to [search](#) or ask questions on [their forum](#) if you need additional help please come visit our forum and we'll try to help.

If you're new to ZeroTier we'd recommend reading our [Getting Started Guide](#).



TIP

See [community threads](#) about MikroTik

Tags:

[mikrotik](#)

[installation](#)

[platform-specific](#)

Product

[Download](#)

[ZeroTier Central](#)

[Pricing](#)

[Security](#)

Documentation

[Getting Started](#)

[This is ZeroTier](#)

[Guides](#)

[FAQ](#)

Community & Support

[Discussion Forum](#)

[GitHub](#)

[Contact Support](#)

Company

[About](#)

[Blog](#)

[Careers](#)

[Privacy Policy](#)