Virtual Memory and Linux

Konsulko Group

Matt Porter
Embedded Linux Conference Europe
October 13, 2016

About the original author, Alan Ott

- Unfortunately, he is unable to be here at ELCE 2016.
- Veteran embedded systems and Linux developer
- Linux Architect at SoftIron
 - 64-bit ARM servers and data center appliances
 - Hardware company, strong on software
 - Overdrive 3000, more products in process



Physical Memory




Single Address Space

- Simple systems have a single address space
 - Memory and peripherals share
 - Memory is mapped to one part
 - Peripherals are mapped to another
 - All processes and OS share the same memory space
 - No memory protection!
 - Processes can stomp one another
 - User space can stomp kernel mem!



Single Address Space

- CPUs with single address space
 - 8086-80206
 - ARM Cortex-M
 - 8- and 16-bit PIC
 - AVR
 - SH-1, SH-2
 - Most 8- and 16-bit systems





x86 Physical Memory Map

Memory-Mapped I/O (PCI) **Extended Memory High Memory Area** Various BIOS **VGA Memory DOS** Area

4 GB

Top of Physical RAM

1.625 MB

1 MB

768 KB

640 KB

- Lots of Legacy
- RAM is split (DOS Area and Extended)
- Hardware mapped between RAM areas.
- High and Extended accessed differently

Limitations

- Portable C programs expect flat memory
 - Multiple memory access methods limit portability
- Management is tricky
 - Need to know or detect total RAM
 - Need to keep processes separated
- No protection
 - Rogue programs can corrupt the entire system



Virtual Memory



What is Virtual Memory?

- Virtual Memory is a system that uses an address mapping
 - Maps virtual address space to physical address space
 - Maps virtual addresses to physical RAM
 - Maps virtual addresses to hardware devices
 - PCI devices
 - GPU RAM
 - On-SoC IP blocks



What is Virtual Memory?

- Advantages
 - Each processes can have a different memory mapping
 - One process's RAM is inaccessible (and invisible) to other processes.
 - Built-in memory protection
 - Kernel RAM is invisible to user space processes
 - Memory can be moved
 - Memory can be swapped to disk



What is Virtual Memory?

- Advantages (cont)
 - Hardware device memory can be mapped into a process's address space
 - Requires the kernel to perform the mapping
 - Physical RAM can be mapped into multiple processes at once
 - Shared memory
 - Memory regions can have access permissions
 - Read, write, execute



Virtual Memory Details

- Two address spaces
 - Physical addresses
 - Addresses as used by the hardware
 - DMA, peripherals
 - Virtual addresses
 - Addresses as used by software
 - Load/Store instructions (RISC)
 - Any instruction accessing memory (CISC)



Virtual Memory Details

- Mapping is performed in hardware
 - No performance penalty for accessing alreadymapped RAM regions
 - Permissions are handled without penalty
 - The same CPU instructions are used for accessing RAM and mapped hardware
 - Software, during its normal operation, will only use virtual addresses.
 - Includes kernel and user space



Memory-Management Unit

- The memory-management unit (MMU) is the hardware responsible for implementing virtual memory.
 - Sits between the CPU core and memory
 - Most often part of the physical CPU itself.
 - On ARM, it's part of the licensed core.
 - Separate from the RAM controller
 - DDR controller is a separate IP block



Memory-Management Unit


- MMU (cont)
 - Transparently handles all memory accesses from Load/Store instructions
 - Maps memory accesses using virtual addresses to system RAM
 - Maps accesses using virtual addresses to memory-mapped peripheral hardware
 - Handles permissions
 - Generates an exception (page fault) on an invalid access
 - Unmapped address or insufficient permissions
 Konsulko

Translation Lookaside Buffer

- The TLB is a list of mappings from virtual to physical address space in hardware
 - Also holds permission bits
- There are a fixed number of entires in the TLB, which varies by CPU.
- The TLB is part of the MMU system.



Virtual Memory System (hardware)



Translation Lookaside Buffer

- TLB is consulted by the MMU when the CPU accesses a virtual address
 - If the virtual address is in the TLB, the MMU can look up the physical resource (RAM or hardware).
 - If the virtual address **is not** in the TLB, the MMU will generate a **page fault** exception and interrupt the CPU.
 - If the address is in the TLB, but the permissions are insufficient,
 the MMU will generate a page fault.



Page Faults

- A page fault is a CPU exception, generated when software attempts to use an invalid virtual address. There are three cases:
 - The virtual address is **not mapped** for the process requesting it.
 - The processes has insufficient permissions for the address.
 - The virtual address is valid, but swapped out.
 - This is a software condition



Kernel Virtual Memory



Kernel Virtual Memory

- In Linux, the kernel uses virtual addresses, as user space processes do.
 - This is not true of all OS's
- Virtual address space is split.
 - The upper part is used for the kernel
 - The lower part is used for user space
- On 32-bit, the split is at $0 \times C000000$



Kernel Addresses

Userspace Addresses

OxFFFFFFF (4GB)

CONFIG_PAGE_OFFSET (default 0xC0000000)

• By default, the **kernel** uses the **top 1GB** of virtual address space.

 Each user space process gets the lower 3GB of virtual address space.

0000000



- Kernel address space is the area above CONFIG_PAGE_OFFSET.
 - For 32-bit, this is configurable at kernel build time.
 - The kernel can be given a different amount of address space as desired
 - See CONFIG_VMSPLIT_1G, CONFIG_VMSPLIT_2G, etc.
 - For 64-bit, the split varies by architecture, but it's high enough:
 - 0x800000000000000 ARM64
 - 0xffff88000000000 x86 64




- There are three kinds of virtual addresses in Linux.
 - The terminology varies, even in the kernel source, but the definitions in *Linux Device Drivers*, 3rd Edition, chapter 15, are somewhat standard.
 - LDD 3 can be downloaded for free at: https://lwn.net/Kernel/LDD3/



- Three kinds of Virtual Addresses
 - Kernel:
 - Kernel Logical Address
 - Kernel Virtual Address
 - User space:
 - User Virtual Address
 - ➤ LDD3 also talks about Bus Addresses, which are architecture specific. We ignore them here.






- Kernel Logical Addresses
 - Normal address space of the kernel
 - kmalloc()
 - Virtual addresses are a **fixed offset** from their physical addresses.
 - Virt: 0xc0000000 → Phys: 0x0000000
 - This makes converting between physical and virtual addresses easy.



Virtual Address Space

Physical Address Space



 Kernel logical addresses can be converted to and from physical addresses using the macros:

```
__pa(x)
_va(x)
```

• For **small-memory** systems (below ~1G of RAM) Kernel Logical address space starts at PAGE_OFFSET and goes through the **end of physical memory**.



Konsulko

- Kernel logical address space includes:
 - Memory allocated with kmalloc() and most other allocation methods
 - Kernel stacks (per process)
- Kernel logical memory can never be swapped out!
 - ➤ Note that just because all physical addresses could have a kernel logical address, it doesn't mean the kernel is actually using every byte of memory on the system.

- Kernel Logical Addresses use a fixed mapping between physical and virtual address space.
- This means virtually-contiguous regions are by nature also physically contiguous.
 - This, combined with the inability to be swapped out, makes them suitable for DMA transfers.



- For 32-bit large-memory systems (more than ~1GB RAM), not all of the physical RAM can be mapped into the kernel's address space.
 - Kernel address space is the top 1GB of virtual address space, by default.
 - Further, ~104 MB is reserved at the top of the kernel's memory space for non-contiguous allocations
 - See vmalloc() described later



- Thus, in a large memory situation, only the bottom part of physical RAM is mapped directly into kernel logical address space.
 - Or rather, only the bottom part of physical RAM has a kernel logical address
- Note that on 64-bit systems, this case never happens.
 - There is always enough kernel address space to accommodate all the RAM.



Kernel Logical Addresses (Large Mem)

Virtual Address Space

Physical Address Space

to Kernel Space


0xfffffff (4GB) Kernel Logical Addresses **PAGE_OFFSET** Physical RAM RAM without Direct Mapping to Kernel Space User Space Addresses RAM with Direct Mapping

0x0000000

Kernel Logical Addresses (Large Mem)

Virtual Address Space

Physical Address Space



Low and High Memory

- Low memory
 - Physical memory which has a kernel logical address
 - Physically contiguous
- High memory
 - Physical memory beyond ~896MB
 - Has no logical address
 - Not physically contiguous when used in the kernel
 - Only on 32-bit



Kernel Virtual Addresses

 Kernel Virtual Addresses are addresses in the region above the kernel logical address mapping.

 This is also called the vmalloc() area.



Kernel Virtual Addresses

- Kernel Virtual Addresses are used for:
 - Non-contiguous memory mappings
 - Often for large buffers which could potentially be too large to find contiguous memory
 - vmalloc()
 - Memory-mapped I/O
 - Map peripheral devices into kernel
 - PCI, SoC IP blocks
 - ioremap(), kmap()



Kernel Virtual Addresses (Small Mem)

Virtual Address Space

Physical Address Space

Oxfffffff Kernel Virtual Addresses (4GB) Kernel Logical Addresses PAGE_OFFSET **Userspace Addresses Physical RAM** 0x0000000


Kernel Virtual Addresses

- The important difference is that memory in the kernel virtual address area (or vmalloc() area) is **non-contiguous** physically.
 - This makes it easier to allocate, especially for large buffers on small-memory systems.
 - This makes it unsuitable for DMA



Kernel Virtual Addresses (Large Mem)

Virtual Address Space



Kernel Virtual Addresses

- In a large memory situation, the kernel virtual address area is smaller, because there is more physical memory.
 - An interesting case, where more memory means less space for kernel virtual addresses.
 - In 64-bit, of course, this doesn't happen, as PAGE_OFFSET is large, and there is much more virtual address space.



User Virtual Memory



- User Virtual Addresses represent memory used by user space programs.
 - This is most of the memory on most systems
 - This is where most of the complication is
- User virtual addresses are all addresses below PAGE_OFFSET.
- Each process has its own mapping
 - Threads share a mapping
 - Complex behavior with clone(2)



- Unlike kernel logical addresses, which use a fixed mapping between virtual and physical addresses, user space processes make full use of the MMU.
 - Only the used portions of RAM are mapped
 - Memory is not contiguous
 - Memory may be swapped out
 - Memory can be moved



- Since user virtual addresses are not guaranteed to be swapped in, or even allocated at all, user buffers are not suitable for use by the kernel (or for DMA), by default.
- Each process has its own memory map
 - struct mm, pointers in task_struct
- At context switch time, the memory map is changed.
 - This is part of the overhead



Kernel Addresses

User Virtual Addresses

0xFFFFFFF (4GB)

PAGE_OFFSET

- Each process will have its own mapping for user virtual addresses
- The mapping is changed during context switch

0x0000000


The Memory Management Unit



- The Memory Management Unit (MMU) is a hardware component which manages virtual address mappings
 - Maps virtual addresses to physical addresses
- The MMU operates on basic units of memory called pages.
 - Page size varies by architecture
 - Some architectures have configurable page sizes



- Common page sizes:
 - ARM 4k
 - ARM64 4k or 64k
 - MIPS widely configurable
 - x86 4k
 - > Architectures which are configurable are configured at kernel build time.






- Terminology
 - A page is a unit of memory sized and aligned at the page size.
 - A page frame, or frame, refers to a pagesized and page-aligned physical memory block.
 - ➤ A page is somewhat abstract, where a frame is concrete
 - In the kernel, the abbreviation **pfn**, for **page frame number**, is often used to refer to refer to physical page frames



- The MMU operates on pages
 - The MMU maps physical frames to virtual addresses.
 - A memory map for a process will contain many mappings
 - A mapping often covers multiple pages
 - The TLB holds each mapping
 - Virtual address
 - Physical address
 - Permissions



Virtual Memory System (hardware)




Page Faults


- When a process accesses a region of memory that is not mapped, the MMU will generate a page fault exception.
 - The kernel handles page fault exceptions regularly as part of its memory management design.
 - TLB is often smaller than the total number of maps for a process.
 - Page faults at context switch time
 - Lazy allocation




User Virtual Address Space




User Virtual Address Space




User Virtual Address Space



User Virtual Address Space



User Virtual Address Space



- Mappings to virtually contiguous regions do not have to be physically contiguous.
 - This makes memory easier to allocate.
 - Almost all user space code does not need physically contiguous memory.



Multiple Processes


Each process has its own set of mappings.

 The same virtual addresses in two different processes will likely be used to map different physical addresses.




Multiple Processes – Process 1

User Virtual Address Space



Multiple Processes – Process 2

User Virtual Address Space



Shared Memory

Shared memory is easily implemented with an MMU.

 Simply map the same physical frame into two different processes.


The virtual addresses need not be the same.

 If pointers to values inside a shared memory region are used, it might be important for them to have the same virtual addresses, though.




Shared Memory – Process 1

User Virtual Address Space



Shared Memory – Process 2

User Virtual Address Space



Shared Memory

- Note in the previous example, the shared memory region was mapped to different virtual addresses in each process.
- The mmap() system call allows the user space process to request a specific virtual address to map the shared memory region.
 - The kernel may not be able to grant a mapping at this address, causing mmap() to return failure.



 The kernel will not allocate pages requested by a process immediately.

 The kernel will wait until those pages are actually used.

• This is called **lazy allocation** and is a performance optimization.

 For memory that gets allocated but doesn't get used, allocation never has to happen!



Process

- When memory is requested, the kernel simply creates a record of the request in its page tables and then returns (quickly) to the process, without updating the TLB.
- When that newly-allocated memory is touched, the CPU will generate a page fault, because the CPU doesn't know about the mapping.



- Process (cont)
 - In the page fault handler, the kernel uses its page tables to determine that the mapping is valid (from the kernel's point of view) yet unmapped in the TLB.
 - The kernel will allocate a physical page frame and update the TLB with the new mapping.
 - The kernel returns from the exception handler and the user space program can resume.



- In a lazy allocation case, the user space program never is aware that the page fault happened.
 - The page fault can only be detected in the time that was lost to handle it.
- For processes that are time-sensitive, pages can be pre-faulted, or simply touched, at the start of execution.
 - Also see mlock() and mlockall() in this case.



Page Tables

- The entries in the TLB are a **limited resource**.
- Far more mappings can be made than can exist in the TLB at one time.
- The kernel must keep track of all of the mappings all of the time.
- The kernel stores all this information in the page tables.
 - See struct mm and vm area struct



Page Tables

 Since the TLB can only hold a limited subset of the total mappings for a process, some valid mappings will not have TLB entries.

 When these addresses are touched, the CPU will generate a page fault, because the CPU has no knowledge of the mapping; only the kernel does.



Page Tables

- When the page fault handler executes in this case, it will:
 - Find the appropriate mapping for the offending address in the kernel's page tables
 - Select and remove an existing TLB entry
 - Create a TLB entry for the page containing the address
 - Return to the user space process
 - Observe the similarities to lazy allocation handling



Swapping

- When memory utilization is high, the kernel may swap some frames to disk to free up RAM.
 - Having an MMU makes this possible.
- The kernel can copy a frame to disk and remove its TLB entry.
- The frame can be re-used by another process



Swapping

- When the frame is needed again, the CPU will generate a page fault (because the address is not in the TLB).
- The kernel can then, at page fault time:
 - Put the process to sleep
 - Copy the frame from the disk into an unused frame in RAM
 - Fix the page table entry
 - Wake the process




Swapping


- Note that when the page is restored to RAM, it's not necessarily restored to the same physical frame where it originally was located.
- The MMU will use the same virtual address though, so the user space program will not know the difference
 - This is why user space memory cannot typically be used for DMA.




User Virtual Address Space




User Virtual Address Space



User Virtual Address Space




User Virtual Address Space




Swapping In

User Virtual Address Space




Swapping In

User Virtual Address Space



Swapping In

User Virtual Address Space



User Space



User Space

- There are several ways to allocate memory from user space
 - Ignoring the familiar *alloc() functions, which sit on top of platform methods.
- mmap() can be used directly to allocate and map pages.
- brk()/sbrk() can be used to increase the heap size.



mmap()

- mmap() is the standard way to allocate large amounts of memory from user space
 - While mmap() is often used for files, the MAP_ANONYMOUS flag causes mmap() to allocate normal memory for the process.
 - The MAP_SHARED flag can make the allocated pages sharable with other processes.



brk()/sbrk()

- brk() sets the top of the program break.
 - The man page says this is the top of the data segment, but inspection of kernel/sys.c shows it separate from the data segment.
 - This in effect increases the size of the heap.
- sbrk() increases the program break (rather than setting it directly).



brk()/sbrk()

- Lazy Allocation
 - See mm/mmap.c for do_brk()
 - do_brk() is implemented similar to mmap().
 - Modify the page tables for the new area
 - Wait for the page fault
 - ➤ Optionally, do_brk() can pre-fault the new area and allocate it. See mlock(2) to control this behavior.



High-Level Implementation

- The familiar C allocators malloc() and calloc() will use either brk() or mmap() depending on the requested allocation size.
 - Small allocations use brk()
 - Large allocations use mmap()
 - See mallopt(3) and the
 M_MMAP_THRESHOLD parameter
 to control this behavior.



Stack

- Stack Expansion
 - If a process accesses memory beyond its stack, the CPU will trigger a page fault.
 - The page fault handler detects the address is just beyond the stack, and allocates a new page to extend the stack.
 - The new page will not be physically contiguous with the rest of the stack.
 - See __do_page_fault() in arch/arm/mm/fault.c



Summary

- Physical Memory
- Virtual Memory
- Kernel addressing
- User space addressing
- Swapping
- User space allocation

