

Cooling Water System Manual

Purpose:

Maintain safe operating temperatures.

Inspection Checklist:

- Check pump operation.
- Verify flow rate.
- Inspect cooling tower.
- Monitor water temperature.

Alarm Conditions:

Water Temperature > 45°C

Pump Vibration > 5 mm/s

Common Issues:

- Pump failure
- Heat exchanger fouling
- Water leakage
- Blocked pipelines