

Lubrication SOP

Purpose:

Reduce equipment wear and extend service life.

Procedure:

1. Clean lubrication points.
2. Verify lubricant type.
3. Apply recommended quantity.
4. Remove excess grease.
5. Record maintenance activity.

Common Problems:

- Under lubrication
- Over lubrication
- Contaminated lubricant

Inspection Frequency:

Weekly