### 403 Forbidden

本电子书由CyberArticle制作。点击这里下载CyberArticle。注册版本不会显示该信息。 <u>删除广告</u>

本电子书由CyberArticle制作。点击这里下载CyberArticle。注册版本不会显示该信息。 <u>删除广告</u>

本电子书由CyberArticle制作。点击这里下载CyberArticle。注册版本不会显示该信息。 <u>删除广告</u>

本电子书由CyberArticle制作。点击这里下载CyberArticle。注册版本不会显示该信息。 <u>删除广告</u>

本电子书由CyberArticle制作。点击这里下载CyberArticle。注册版本不会显示该信息。 删除广告

# V5交换机二层组播配置方法 (命令行版)

#### 目录

V5交换机二层组播配置方法(命令行版)

- 1配置需求或说明
  - 1.1 适用产品系列
  - 1.2 配置需求
- 2组网图
- 3 配置步骤
  - 3.1 进入SW1的命令行,全局下开启IGMP Snooping功能
  - 3.2 在VLAN 1内使能IGMP Snooping,并使能IGMP Snooping查询器
  - 3.3 保存配置
  - 3.4 进入SW2的命令行,全局和VLAN1下都开启IGMP Snooping功能
  - 3.5 检查配置结果

## 1 配置需求或说明

### 1.1 适用产品系列

本案例适用于如S3100V2-16TP-EI、S5008PV2-EI、S5120-28P-SI、MS4120-26TP等的V5和V7交换机,


V5交换机二层组播配置方法(命令行版... Page 3 of 8

V5、V7 交 换 机 具 体 分 类 及 型 号 可 以 参 考 "1.1 Comware V5、V7平台交换机分类说明"。

### 1.2 配置需求

公司内部部署了一台组播源,为保证终端能正常接收组播源传输的业务,需在所经交换机上开启组播功能。

### 2组网图



# 3 配置步骤

## 3.1 进入SW1的命令行,全局下开启 IGMP Snooping功能

<H3C>system -view

```
System View: return to User View with Ctrl+Z..
[H3C] igmp-snooping
[H3C-igmp-snooping] quit
```

### 3.2 在VLAN 1内使能IGMP Snooping, 并使能IGMP Snooping查询器

```
[H3C]vlan 1
[H3C-vlan1]igmp-snooping enable
[H3C-vlan1]igmp-snooping querier
```

#### 3.3 保存配置

[H3C]save force

# 3.4 进入SW2的命令行,全局和VLAN1下都开启IGMP Snooping功能

```
<H3C>system-view
System View: return to User View with
Ctrl+Z.
[H3C] igmp-snooping
[H3C]vlan 1
[H3C-vlan1]igmp-snooping enable
```

#### 3.5 检查配置结果


#### 组播接收方:



V5交换机二层组播配置方法(命令行版... Page 6 of 8

#### 组播源:

(0x0000)



GE1/0/3

Host port(s):total 1 port(s).

```
(D) ( 00:02:58 )
   MAC group(s):
      MAC group address:0100-5e7f-fffa
          Host port unit board: Mask
(0x0000)
          Host port(s):total 1 port(s).
            GE1/0/3
IP group(s):the following ip group
(s) match to one mac group.
IP group address:239.3.4.4
//组播组地址
        (0.0.0.0, 239.3.4.4):
          Attribute:
                         Host Port
          Host port unit board: Mask
(0x0000)
          Host port(s):total 1 port(s).
   GE1/0/3
(00:02:49) //主机端口,连接Pc2的端口
(D)
   MAC group(s):
      MAC group address:0100-5e03-0404
          Host port unit board: Mask
(0x0000)
          Host port(s):total 1 port(s).
            GE1/0/3
```

V5交换机二层组播配置方法(命令行版... Page 8 of 8