

Q1: Which PDF in the repository provides the STM32L4S series data sheet?

A1: 'STM32L4Sxxx Data-sheet.pdf' at the repository root.

Q2: Where can you find the full schematic for the B-L4S5I-IOT01A discovery board?

A2: In 'L4S5VI-e03\_schematic.pdf' located at the repository root.

Q3: Which document explains the STM32L4+ series discovery kit hardware?

A3: 'STM32L4+ series Discovery kit.pdf'.

Q4: Which PDF would you open for the MCU technical reference manual?

A4: 'STM32L4+ Technical reference manual.pdf'.

Q5: Where is the ARMv7-M architecture reference stored?

A5: 'ARMv7-M Architecture Ref Manual.pdf' in the project root.

Q6: Which document covers the official I2C-bus specification?

A6: 'UM10204 I2C-bus specification and user manual.pdf'.

Q7: Where is the STM32CubeIDE getting-started material located?

A7: Look at 'STM32CubeIDE\_Quick\_Start\_Guide.pdf'.

Q8: Which PDF in the repo is the assignment brief?

A8: 'S1AY2526 Assignment 2 \_ EE2028 Microcontroller Programming and Interfacing [2510].pdf'.

Q9: What file outlines pseudo-code guidance for the assignment?

A9: 'pesudocode.txt' at the repository root.

Q10: Where are the assignment instructions summarized?

A10: In 'instruction.txt' at the repository root.

Q11: Which directory contains the STM32 board support drivers?

A11: 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01'.

Q12: Where are the CMSIS core header files located?

A12: Under 'Assignment2-AY2526S1/Drivers/CMSIS/Include'.

Q13: Which source file controls the SSD1306 OLED driver logic?

A13: 'Assignment2-AY2526S1/Core/Src/ssd1306.c'.

Q14: Where is the HT16K33 LED matrix driver implemented?

A14: 'Assignment2-AY2526S1/Core/Src/ht16k33.c'.

Q15: Which header exposes the Grove 5-way switch API?

A15: 'Assignment2-AY2526S1/Core/Inc/grove\_5way.h'.

Q16: Where can you review the buzzer note definitions?

A16: 'Assignment2-AY2526S1/Core/Inc/buzzer\_scale.h'.

Q17: Which file defines the system clock setup for STM32L4S5?

A17: 'Assignment2-AY2526S1/Core/Src/system\_stm32l4xx.c'.

Q18: Where are the startup assembly instructions kept?

A18: 'Assignment2-AY2526S1/Core/Startup/startup\_stm32l4s5vitx.s'.

Q19: Which folder stores the build artifacts for the Debug configuration?

A19: 'Assignment2-AY2526S1/Debug/'.

Q20: Which folder stores the build artifacts for the Release configuration?

A20: 'Assignment2-AY2526S1/Release/'.

Q21: Where is the linker script for flash configuration located?

A21: 'Assignment2-AY2526S1/STM32L4S5VITX\_FLASH.ld'.

Q22: Which header defines application-wide macros and prototypes?

A22: 'Assignment2-AY2526S1/Core/Inc/main.h'.

Q23: Where would you look for bitmap assets used on the OLED?

A23: 'Assignment2-AY2526S1/Core/Inc/bitmap.h' and related images in 'Core/Src'.

Q24: Which file collects the horse animation frames?

A24: 'Assignment2-AY2526S1/Core/Src/horse\_anim.h'.

Q25: Where is the NFCTAG BSP driver implemented?

A25: 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c'.

Q26: Which file provides magnetometer driver functions?

A26: 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_magneto.c'.

Q27: Where is the humidity sensor BSP code stored?

A27: 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_hsensor.c'.

Q28: Which document would you consult for NFC field behavior?

A28: 'stm32l4s5i\_iot01\_nfctag.c' and its header in the BSP driver folder.

Q29: Where are the HAL MSP initialization hooks written?

A29: 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_hal\_msp.c'.

Q30: Which module implements the menu state machine?

A30: 'Assignment2-AY2526S1/Core/Src/menu\_system.c'.

Q31: Where are the board LED and button pins defined?

A31: 'Assignment2-AY2526S1/Core/Inc/main.h' and the generated CubeMX configuration.

Q32: Which file defines custom fonts for the OLED?

A32: 'Assignment2-AY2526S1/Core/Src/fonts.c' with declarations in 'Core/Inc/fonts.h'.

Q33: Where can you inspect the accelerometer BSP implementation?

A33: 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_accelero.c'.

Q34: Which header declares the pressure sensor API?

A34: 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_psensor.h'.

Q35: Where does the gyro BSP driver reside?

A35: 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_gyro.c'.

Q36: Which file bundles the task menu configuration data?

A36: 'Assignment2-AY2526S1/Core/Src/menu\_system.c'.

Q37: Where is the multi-switch abstraction implemented?

A37: 'Assignment2-AY2526S1/Core/Src/multi\_switch.c'.

Q38: Which document would you read for microcontroller pin descriptions?

A38: 'STM32L4Sxxx Data-sheet.pdf'.

Q39: Where is the watchdog or fault handling interrupt defined?

A39: 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c'.

Q40: Which header exposes the HT16K33 control API?

A40: 'Assignment2-AY2526S1/Core/Inc/ht16k33.h'.

Q41: Where can you find the buzzer control API declarations?

A41: 'Assignment2-AY2526S1/Core/Inc/buzzer.h'.

Q42: Which file initializes the system heap and stack for newlib?

A42: 'Assignment2-AY2526S1/Core/Src/systemem.c'.

Q43: Where are the low-level syscall stubs implemented?

A43: 'Assignment2-AY2526S1/Core/Src/syscalls.c'.

Q44: Which BSP driver handles temperature readings?

A44: 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_tsensor.c'.

Q45: Which repository file explains how to build and flash the assignment?

A45: 'instruction.txt'.

Q46: Where are the project launch configurations stored?

A46: 'Assignment2-AY2526S1/Assignment2-AY2526S1 Debug.launch' and related '.cfg' files.

Q47: Which directory contains the HAL driver sources?

A47: 'Assignment2-AY2526S1/Drivers/STM32L4xx\_HAL\_Driver/Src'.

Q48: Where is the CMSIS device header for STM32L4 included?

A48: 'Assignment2-AY2526S1/Drivers/CMSIS/Device/ST/STM32L4xx/Include'.

Q49: Which folder holds the generated linker scripts?

A49: Project root ('STM32L4S5VITX\_FLASH.ld' and 'STM32L4S5VITX\_RAM.ld').

Q50: Where is the project-level makefile for Debug builds kept?

A50: 'Assignment2-AY2526S1/Debug/makefile'.

Q51: Which file lists the compiled object files for the Release build?

A51: 'Assignment2-AY2526S1/Release/objects.list'.

Q52: Where is the generated ELF binary for Debug stored?

A52: 'Assignment2-AY2526S1/Debug/Assignment2-AY2526S1.elf'.

Q53: Which directory contains the OLED bitmap images referenced by 'images.h'?

A53: 'Assignment2-AY2526S1/Core/Src/' alongside 'images.h'.

Q54: What file defines the buzzer tune sequences used by the games?

A54: 'Assignment2-AY2526S1/Core/Src/buzzer.c'.

Q55: What is the return type of 'Buzzer\_Init' defined in

'Assignment2-AY2526S1/Core/Src/buzzer.c'?

A55: It returns 'void'.

Q56: How many parameters does 'Buzzer\_Init' accept?

A56: It takes no parameters.

Q57: List the parameters for 'Buzzer\_Init'.

A57: None; the parameter list is empty.

Q58: Where in the project is 'Buzzer\_Init' implemented?

A58: In 'Assignment2-AY2526S1/Core/Src/buzzer.c' near line 43.

Q59: Is 'Buzzer\_Init' declared 'static'?

A59: No, it is globally visible.

Q60: What is the return type of 'FONTS\_GetStringSize' defined in

'Assignment2-AY2526S1/Core/Src/fonts.c'?

A60: It returns 'char\*'.

Q61: How many parameters does 'FONTS\_GetStringSize' accept?

A61: It takes 3 parameters.

Q62: List the parameters for 'FONTS\_GetStringSize'.

A62: char\* str, FONTS\_SIZE\_t\* SizeStruct, FontDef\_t\* Font

Q63: Where in the project is 'FONTS\_GetStringSize' implemented?

A63: In 'Assignment2-AY2526S1/Core/Src/fonts.c' near line 334.

Q64: Is 'FONTS\_GetStringSize' declared 'static'?

A64: No, it is globally visible.

Q65: What is the return type of 'Grove5Way\_Init' defined in

'Assignment2-AY2526S1/Core/Src/grove\_5way.c'?

A65: It returns 'bool'.

Q66: How many parameters does 'Grove5Way\_Init' accept?

A66: It takes 3 parameters.

Q67: List the parameters for 'Grove5Way\_Init'.

A67: Grove5Way\_Handle \*handle, I2C\_HandleTypeDef \*hi2c, uint8\_t address

Q68: Where in the project is 'Grove5Way\_Init' implemented?

A68: In 'Assignment2-AY2526S1/Core/Src/grove\_5way.c' near line 29.

Q69: Is 'Grove5Way\_Init' declared 'static'?

A69: No, it is globally visible.

Q70: What is the return type of 'ht16k33\_write\_cmd' defined in

'Assignment2-AY2526S1/Core/Src/ht16k33.c'?

A70: It returns 'HAL\_StatusTypeDef'.

Q71: How many parameters does 'ht16k33\_write\_cmd' accept?

A71: It takes 2 parameters.

Q72: List the parameters for 'ht16k33\_write\_cmd'.

A72: const HT16K33\_HandleTypeDef \*h, uint8\_t cmd

Q73: Where in the project is 'ht16k33\_write\_cmd' implemented?

A73: In 'Assignment2-AY2526S1/Core/Src/ht16k33.c' near line 7.

Q74: Is 'ht16k33\_write\_cmd' declared 'static'?

A74: Yes, it is declared 'static'.

Q75: What is the return type of 'printu' defined in 'Assignment2-AY2526S1/Core/Src/main.c'?

A75: It returns 'void'.

Q76: How many parameters does 'printu' accept?

A76: It takes 2 parameters.

Q77: List the parameters for 'printu'.

A77: const char \*fmt, ...

Q78: Where in the project is 'printu' implemented?

A78: In 'Assignment2-AY2526S1/Core/Src/main.c' near line 42.

Q79: Is 'printu' declared 'static'?

A79: No, it is globally visible.

Q80: What is the return type of 'get\_mag\_value' defined in 'Assignment2-AY2526S1/Core/Src/menu\_system.c'?

A80: It returns 'float'.

Q81: How many parameters does 'get\_mag\_value' accept?

A81: It takes 1 parameter.

Q82: List the parameters for 'get\_mag\_value'.

A82: int index

Q83: Where in the project is 'get\_mag\_value' implemented?

A83: In 'Assignment2-AY2526S1/Core/Src/menu\_system.c' near line 47.

Q84: Is 'get\_mag\_value' declared 'static'?

A84: Yes, it is declared 'static'.

Q85: What is the return type of 'readDev' defined in 'Assignment2-AY2526S1/Core/Src/multi\_switch.c'?

A85: It returns 'int'.

Q86: How many parameters does 'readDev' accept?

A86: It takes 3 parameters.

Q87: List the parameters for 'readDev'.

A87: GroveMultiSwitch\_t \*handle, uint8\_t \*data, int len

Q88: Where in the project is 'readDev' implemented?

A88: In 'Assignment2-AY2526S1/Core/Src/multi\_switch.c' near line 20.

Q89: Is 'readDev' declared 'static'?

A89: Yes, it is declared 'static'.

Q90: What is the return type of 'SSD1306\_Init' defined in 'Assignment2-AY2526S1/Core/Src/ssd1306.c'?

A90: It returns 'uint8\_t'.

Q91: How many parameters does 'SSD1306\_Init' accept?

A91: It takes no parameters.

Q92: List the parameters for 'SSD1306\_Init'.

A92: None; the parameter list is empty.

Q93: Where in the project is 'SSD1306\_Init' implemented?

A93: In 'Assignment2-AY2526S1/Core/Src/ssd1306.c' near line 26.

Q94: Is 'SSD1306\_Init' declared 'static'?

A94: No, it is globally visible.

Q95: What is the return type of 'HAL\_MspInit' defined in 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_hal\_msp.c'?

A95: It returns 'void'.

Q96: How many parameters does 'HAL\_MspInit' accept?

A96: It takes no parameters.

Q97: List the parameters for 'HAL\_MspInit'.

A97: None; the parameter list is empty.

Q98: Where in the project is 'HAL\_MspInit' implemented?

A98: In 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_hal\_msp.c' near line 63.

Q99: Is 'HAL\_MspInit' declared 'static'?

A99: No, it is globally visible.

Q100: What is the return type of 'NMI\_Handler' defined in 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c'?

A100: It returns 'void'.

Q101: How many parameters does 'NMI\_Handler' accept?

A101: It takes no parameters.

Q102: List the parameters for 'NMI\_Handler'.

A102: None; the parameter list is empty.

Q103: Where in the project is 'NMI\_Handler' implemented?

A103: In 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c' near line 69.

Q104: Is 'NMI\_Handler' declared 'static'?

A104: No, it is globally visible.

Q105: What is the return type of 'initialise\_monitor\_handles' defined in 'Assignment2-AY2526S1/Core/Src/syscalls.c'?

A105: It returns 'void'.

Q106: How many parameters does 'initialise\_monitor\_handles' accept?

A106: It takes no parameters.

Q107: List the parameters for 'initialise\_monitor\_handles'.

A107: None; the parameter list is empty.

Q108: Where in the project is 'initialise\_monitor\_handles' implemented?

A108: In 'Assignment2-AY2526S1/Core/Src/syscalls.c' near line 44.

Q109: Is 'initialise\_monitor\_handles' declared 'static'?

A109: No, it is globally visible.

Q110: What is the return type of 'SystemInit' defined in 'Assignment2-AY2526S1/Core/Src/system\_stm32l4xx.c'?

A110: It returns 'void'.

Q111: How many parameters does 'SystemInit' accept?

A111: It takes no parameters.

Q112: List the parameters for 'SystemInit'.

A112: None; the parameter list is empty.

Q113: Where in the project is 'SystemInit' implemented?

A113: In 'Assignment2-AY2526S1/Core/Src/system\_stm32l4xx.c' near line 197.

Q114: Is 'SystemInit' declared 'static'?

A114: No, it is globally visible.

Q115: What is the return type of 'BSP\_GetVersion' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c'?

A115: It returns 'uint32\_t'.

Q116: How many parameters does 'BSP\_GetVersion' accept?

A116: It takes no parameters.

Q117: List the parameters for 'BSP\_GetVersion'.

A117: None; the parameter list is empty.

Q118: Where in the project is 'BSP\_GetVersion' implemented?

A118: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c' near line 129.

Q119: Is 'BSP\_GetVersion' declared 'static'?

A119: No, it is globally visible.

Q120: What is the return type of 'BSP\_ACCELERO\_Init' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_accelero.c'?

A120: It returns 'ACCELERO\_StatusTypeDef'.

Q121: How many parameters does 'BSP\_ACCELERO\_Init' accept?

A121: It takes no parameters.

Q122: List the parameters for 'BSP\_ACCELERO\_Init'.

A122: None; the parameter list is empty.

Q123: Where in the project is 'BSP\_ACCELERO\_Init' implemented?

A123: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_accelero.c' near line 48.

Q124: Is 'BSP\_ACCELERO\_Init' declared 'static'?

A124: No, it is globally visible.

Q125: What is the return type of 'BSP\_GYRO\_Init' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_gyro.c'?

A125: It returns 'uint8\_t'.

Q126: How many parameters does 'BSP\_GYRO\_Init' accept?

A126: It takes no parameters.

Q127: List the parameters for 'BSP\_GYRO\_Init'.

A127: None; the parameter list is empty.

Q128: Where in the project is 'BSP\_GYRO\_Init' implemented?

A128: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_gyro.c' near line 51.

Q129: Is 'BSP\_GYRO\_Init' declared 'static'?

A129: No, it is globally visible.

Q130: What is the return type of 'BSP\_HSENSOR\_Init' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_hsensor.c'?

A130: It returns 'uint32\_t'.

Q131: How many parameters does 'BSP\_HSENSOR\_Init' accept?

A131: It takes no parameters.

Q132: List the parameters for 'BSP\_HSENSOR\_Init'.

A132: None; the parameter list is empty.

Q133: Where in the project is 'BSP\_HSENSOR\_Init' implemented?

A133: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_hsensor.c' near line 50.

Q134: Is 'BSP\_HSENSOR\_Init' declared 'static'?

A134: No, it is globally visible.

Q135: What is the return type of 'BSP\_MAGNETO\_Init' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_magneto.c'?

A135: It returns 'MAGNETO\_StatusTypeDef'.

Q136: How many parameters does 'BSP\_MAGNETO\_Init' accept?

A136: It takes no parameters.

Q137: List the parameters for 'BSP\_MAGNETO\_Init'.

A137: None; the parameter list is empty.

Q138: Where in the project is 'BSP\_MAGNETO\_Init' implemented?

A138: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_magneto.c' near line 51.

Q139: Is 'BSP\_MAGNETO\_Init' declared 'static'?

A139: No, it is globally visible.

Q140: What is the return type of 'BSP\_NFCTAG\_Init' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c'?

A140: It returns 'int32\_t'.

Q141: How many parameters does 'BSP\_NFCTAG\_Init' accept?

A141: It takes 1 parameter.

Q142: List the parameters for 'BSP\_NFCTAG\_Init'.

A142: uint32\_t Instance

Q143: Where in the project is 'BSP\_NFCTAG\_Init' implemented?

A143: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c' near line 65.

Q144: Is 'BSP\_NFCTAG\_Init' declared 'static'?

A144: No, it is globally visible.

Q145: What is the return type of 'BSP\_PSENSOR\_Init' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_psensor.c'?

A145: It returns 'uint32\_t'.

Q146: How many parameters does 'BSP\_PSENSOR\_Init' accept?

A146: It takes no parameters.

Q147: List the parameters for 'BSP\_PSENSOR\_Init'.

A147: None; the parameter list is empty.

Q148: Where in the project is 'BSP\_PSENSOR\_Init' implemented?

A148: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_psensor.c' near line 50.

Q149: Is 'BSP\_PSENSOR\_Init' declared 'static'?

A149: No, it is globally visible.

Q150: What is the return type of 'BSP\_TSENSOR\_Init' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_tsensor.c'?

A150: It returns 'uint32\_t'.

Q151: How many parameters does 'BSP\_TSENSOR\_Init' accept?

A151: It takes no parameters.

Q152: List the parameters for 'BSP\_TSENSOR\_Init'.

A152: None; the parameter list is empty.



Q153: Where in the project is 'BSP\_TSENSOR\_Init' implemented?

A153: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_tsensor.c' near line 50.

Q154: Is 'BSP\_TSENSOR\_Init' declared 'static'?

A154: No, it is globally visible.

Q155: What is the return type of 'Buzzer\_PlayToneAsync' defined in 'Assignment2-AY2526S1/Core/Src/buzzer.c'?

A155: It returns 'void'.

Q156: How many parameters does 'Buzzer\_PlayToneAsync' accept?

A156: It takes 2 parameters.

Q157: List the parameters for 'Buzzer\_PlayToneAsync'.

A157: float frequency\_hz, uint32\_t duration\_ms

Q158: Where in the project is 'Buzzer\_PlayToneAsync' implemented?

A158: In 'Assignment2-AY2526S1/Core/Src/buzzer.c' near line 66.

Q159: Is 'Buzzer\_PlayToneAsync' declared 'static'?

A159: No, it is globally visible.

Q160: What is the return type of 'Grove5Way\_Poll' defined in 'Assignment2-AY2526S1/Core/Src/grove\_5way.c'?

A160: It returns 'bool'.

Q161: How many parameters does 'Grove5Way\_Poll' accept?

A161: It takes 2 parameters.

Q162: List the parameters for 'Grove5Way\_Poll'.

A162: Grove5Way\_Handle \*handle, Grove5Way\_Event \*event

Q163: Where in the project is 'Grove5Way\_Poll' implemented?

A163: In 'Assignment2-AY2526S1/Core/Src/grove\_5way.c' near line 60.

Q164: Is 'Grove5Way\_Poll' declared 'static'?

A164: No, it is globally visible.

Q165: What is the return type of 'ht16k33\_reverse\_byte' defined in 'Assignment2-AY2526S1/Core/Src/ht16k33.c'?

A165: It returns 'uint8\_t'.

Q166: How many parameters does 'ht16k33\_reverse\_byte' accept?

A166: It takes 1 parameter.

Q167: List the parameters for 'ht16k33\_reverse\_byte'.

A167: uint8\_t value

Q168: Where in the project is 'ht16k33\_reverse\_byte' implemented?

A168: In 'Assignment2-AY2526S1/Core/Src/ht16k33.c' near line 12.

Q169: Is 'ht16k33\_reverse\_byte' declared 'static'?

A169: Yes, it is declared 'static'.

Q170: What is the return type of 'led\_set\_blink' defined in 'Assignment2-AY2526S1/Core/Src/main.c'?

A170: It returns 'void'.

Q171: How many parameters does 'led\_set\_blink' accept?

A171: It takes 4 parameters.

Q172: List the parameters for 'led\_set\_blink'.

A172: int level) /\* -1 off, 0 slow, 1 med, 2 fast \*/  
{  
 if (level < 0

Q173: Where in the project is 'led\_set\_blink' implemented?

A173: In 'Assignment2-AY2526S1/Core/Src/main.c' near line 170.

Q174: Is 'led\_set\_blink' declared 'static'?

A174: Yes, it is declared 'static'.

Q175: What is the return type of 'set\_mag\_value' defined in  
'Assignment2-AY2526S1/Core/Src/menu\_system.c'?

A175: It returns 'void'.

Q176: How many parameters does 'set\_mag\_value' accept?

A176: It takes 2 parameters.

Q177: List the parameters for 'set\_mag\_value'.

A177: int index, float value

Q178: Where in the project is 'set\_mag\_value' implemented?

A178: In 'Assignment2-AY2526S1/Core/Src/menu\_system.c' near line 53.

Q179: Is 'set\_mag\_value' declared 'static'?

A179: Yes, it is declared 'static'.

Q180: What is the return type of 'writeDev' defined in  
'Assignment2-AY2526S1/Core/Src/multi\_switch.c'?

A180: It returns 'int'.

Q181: How many parameters does 'writeDev' accept?

A181: It takes 3 parameters.

Q182: List the parameters for 'writeDev'.

A182: GroveMultiSwitch\_t \*handle, const uint8\_t \*data, int len

Q183: Where in the project is 'writeDev' implemented?

A183: In 'Assignment2-AY2526S1/Core/Src/multi\_switch.c' near line 43.

Q184: Is 'writeDev' declared 'static'?

A184: Yes, it is declared 'static'.

Q185: What is the return type of 'SSD1306\_UpdateScreen' defined in  
'Assignment2-AY2526S1/Core/Src/ssd1306.c'?

A185: It returns 'void'.

Q186: How many parameters does 'SSD1306\_UpdateScreen' accept?

A186: It takes no parameters.

Q187: List the parameters for 'SSD1306\_UpdateScreen'.

A187: None; the parameter list is empty.

Q188: Where in the project is 'SSD1306\_UpdateScreen' implemented?

A188: In 'Assignment2-AY2526S1/Core/Src/ssd1306.c' near line 91.

Q189: Is 'SSD1306\_UpdateScreen' declared 'static'?

A189: No, it is globally visible.

Q190: What is the return type of 'HAL\_I2C\_Mspltinit' defined in 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_hal\_msp.c'?

A190: It returns 'void'.

Q191: How many parameters does 'HAL\_I2C\_Mspltinit' accept?

A191: It takes 1 parameter.

Q192: List the parameters for 'HAL\_I2C\_Mspltinit'.

A192: I2C\_HandleTypeDef\* hi2c

Q193: Where in the project is 'HAL\_I2C\_Mspltinit' implemented?

A193: In 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_hal\_msp.c' near line 81.

Q194: Is 'HAL\_I2C\_Mspltinit' declared 'static'?

A194: No, it is globally visible.

Q195: What is the return type of 'HardFault\_Handler' defined in 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c'?

A195: It returns 'void'.

Q196: How many parameters does 'HardFault\_Handler' accept?

A196: It takes no parameters.

Q197: List the parameters for 'HardFault\_Handler'.

A197: None; the parameter list is empty.

Q198: Where in the project is 'HardFault\_Handler' implemented?

A198: In 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c' near line 84.

Q199: Is 'HardFault\_Handler' declared 'static'?

A199: No, it is globally visible.

Q200: What is the return type of '\_getpid' defined in 'Assignment2-AY2526S1/Core/Src/syscalls.c'?

A200: It returns 'int'.

Q201: How many parameters does '\_getpid' accept?

A201: It takes no parameters.

Q202: List the parameters for '\_getpid'.

A202: None; the parameter list is empty.

Q203: Where in the project is '\_getpid' implemented?

A203: In 'Assignment2-AY2526S1/Core/Src/syscalls.c' near line 48.

Q204: Is '\_getpid' declared 'static'?

A204: No, it is globally visible.

Q205: What is the return type of 'SystemCoreClockUpdate' defined in 'Assignment2-AY2526S1/Core/Src/system\_stm32l4xx.c'?

A205: It returns 'void'.

Q206: How many parameters does 'SystemCoreClockUpdate' accept?

A206: It takes no parameters.

Q207: List the parameters for 'SystemCoreClockUpdate'.

A207: None; the parameter list is empty.

Q208: Where in the project is 'SystemCoreClockUpdate' implemented?

A208: In 'Assignment2-AY2526S1/Core/Src/system\_stm32l4xx.c' near line 251.

Q209: Is 'SystemCoreClockUpdate' declared 'static'?

A209: No, it is globally visible.

Q210: What is the return type of 'BSP\_LED\_Init' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c'?

A210: It returns 'void'.

Q211: How many parameters does 'BSP\_LED\_Init' accept?

A211: It takes 1 parameter.

Q212: List the parameters for 'BSP\_LED\_Init'.

A212: Led\_TypeDef Led

Q213: Where in the project is 'BSP\_LED\_Init' implemented?

A213: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c' near line 140.

Q214: Is 'BSP\_LED\_Init' declared 'static'?

A214: No, it is globally visible.

Q215: What is the return type of 'BSP\_ACCELERO\_DeInit' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_accelero.c'?

A215: It returns 'void'.

Q216: How many parameters does 'BSP\_ACCELERO\_DeInit' accept?

A216: It takes no parameters.

Q217: List the parameters for 'BSP\_ACCELERO\_DeInit'.

A217: None; the parameter list is empty.

Q218: Where in the project is 'BSP\_ACCELERO\_DeInit' implemented?

A218: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_accelero.c' near line 89.

Q219: Is 'BSP\_ACCELERO\_DeInit' declared 'static'?

A219: No, it is globally visible.

Q220: What is the return type of 'BSP\_GYRO\_DeInit' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_gyro.c'?

A220: It returns 'void'.

Q221: How many parameters does 'BSP\_GYRO\_DeInit' accept?

A221: It takes no parameters.

Q222: List the parameters for 'BSP\_GYRO\_DeInit'.

A222: None; the parameter list is empty.

Q223: Where in the project is 'BSP\_GYRO\_DeInit' implemented?

A223: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_gyro.c' near line 94.

Q224: Is 'BSP\_GYRO\_DeInit' declared 'static'?

A224: No, it is globally visible.

Q225: What is the return type of 'BSP\_HSENSOR\_ReadID' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_hsensor.c'?

A225: It returns 'uint8\_t'.

Q226: How many parameters does 'BSP\_HSENSOR\_ReadID' accept?

A226: It takes no parameters.

Q227: List the parameters for 'BSP\_HSENSOR\_ReadID'.

A227: None; the parameter list is empty.

Q228: Where in the project is 'BSP\_HSENSOR\_ReadID' implemented?

A228: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_hsensor.c' near line 73.

Q229: Is 'BSP\_HSENSOR\_ReadID' declared 'static'?

A229: No, it is globally visible.

Q230: What is the return type of 'BSP\_MAGNETO\_DeInit' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_magneto.c'?

A230: It returns 'void'.

Q231: How many parameters does 'BSP\_MAGNETO\_DeInit' accept?

A231: It takes no parameters.

Q232: List the parameters for 'BSP\_MAGNETO\_DeInit'.

A232: None; the parameter list is empty.

Q233: Where in the project is 'BSP\_MAGNETO\_DeInit' implemented?

A233: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_magneto.c' near line 82.

Q234: Is 'BSP\_MAGNETO\_DeInit' declared 'static'?

A234: No, it is globally visible.

Q235: What is the return type of 'BSP\_NFCTAG\_DeInit' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c'?

A235: It returns 'void'.

Q236: How many parameters does 'BSP\_NFCTAG\_DeInit' accept?

A236: It takes 1 parameter.

Q237: List the parameters for 'BSP\_NFCTAG\_DeInit'.

A237: uint32\_t Instance

Q238: Where in the project is 'BSP\_NFCTAG\_DeInit' implemented?

A238: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c' near line 105.

Q239: Is 'BSP\_NFCTAG\_DeInit' declared 'static'?

A239: No, it is globally visible.

Q240: What is the return type of 'BSP\_PSENSOR\_ReadID' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_psensor.c'?

A240: It returns 'uint8\_t'.

Q241: How many parameters does 'BSP\_PSENSOR\_ReadID' accept?

A241: It takes no parameters.

Q242: List the parameters for 'BSP\_PSENSOR\_ReadID'.

A242: None; the parameter list is empty.

Q243: Where in the project is 'BSP\_PSENSOR\_ReadID' implemented?

A243: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_psensor.c' near line 74.

Q244: Is 'BSP\_PSENSOR\_ReadID' declared 'static'?

A244: No, it is globally visible.

Q245: What is the return type of 'BSP\_TSENSOR\_ReadTemp' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_tsensor.c'?

A245: It returns 'float'.

Q246: How many parameters does 'BSP\_TSENSOR\_ReadTemp' accept?

A246: It takes no parameters.

Q247: List the parameters for 'BSP\_TSENSOR\_ReadTemp'.

A247: None; the parameter list is empty.

Q248: Where in the project is 'BSP\_TSENSOR\_ReadTemp' implemented?

A248: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_tsensor.c' near line 75.

Q249: Is 'BSP\_TSENSOR\_ReadTemp' declared 'static'?

A249: No, it is globally visible.

Q250: What is the return type of 'Buzzer\_PlayNoteAsync' defined in 'Assignment2-AY2526S1/Core/Src/buzzer.c'?

A250: It returns 'void'.

Q251: How many parameters does 'Buzzer\_PlayNoteAsync' accept?

A251: It takes 2 parameters.

Q252: List the parameters for 'Buzzer\_PlayNoteAsync'.

A252: buzzer\_note\_t note, uint32\_t duration\_ms

Q253: Where in the project is 'Buzzer\_PlayNoteAsync' implemented?

A253: In 'Assignment2-AY2526S1/Core/Src/buzzer.c' near line 73.

Q254: Is 'Buzzer\_PlayNoteAsync' declared 'static'?

A254: No, it is globally visible.

Q255: What is the return type of 'grove5way\_write\_cmd' defined in 'Assignment2-AY2526S1/Core/Src/grove\_5way.c'?

A255: It returns 'bool'.

Q256: How many parameters does 'grove5way\_write\_cmd' accept?

A256: It takes 2 parameters.

Q257: List the parameters for 'grove5way\_write\_cmd'.

A257: Grove5Way\_Handle \*handle, uint8\_t cmd

Q258: Where in the project is 'grove5way\_write\_cmd' implemented?

A258: In 'Assignment2-AY2526S1/Core/Src/grove\_5way.c' near line 90.

Q259: Is 'grove5way\_write\_cmd' declared 'static'?

A259: Yes, it is declared 'static'.

Q260: What is the return type of 'HT16K33\_Init' defined in 'Assignment2-AY2526S1/Core/Src/ht16k33.c'?

A260: It returns 'HAL\_StatusTypeDef'.

Q261: How many parameters does 'HT16K33\_Init' accept?

A261: It takes 3 parameters.

Q262: List the parameters for 'HT16K33\_Init'.

A262: HT16K33\_HandleTypeDef \*h, I2C\_HandleTypeDef \*hi2c, uint8\_t addr7bit

Q263: Where in the project is 'HT16K33\_Init' implemented?

A263: In 'Assignment2-AY2526S1/Core/Src/ht16k33.c' near line 20.

Q264: Is 'HT16K33\_Init' declared 'static'?

A264: No, it is globally visible.

Q265: What is the return type of 'led\_blink\_process' defined in 'Assignment2-AY2526S1/Core/Src/main.c'?

A265: It returns 'void'.

Q266: How many parameters does 'led\_blink\_process' accept?

A266: It takes 1 parameter.

Q267: List the parameters for 'led\_blink\_process'.

A267: uint32\_t now

Q268: Where in the project is 'led\_blink\_process' implemented?

A268: In 'Assignment2-AY2526S1/Core/Src/main.c' near line 190.

Q269: Is 'led\_blink\_process' declared 'static'?

A269: Yes, it is declared 'static'.

Q270: What is the return type of 'get\_arrow\_count' defined in 'Assignment2-AY2526S1/Core/Src/menu\_system.c'?

A270: It returns 'float'.

Q271: How many parameters does 'get\_arrow\_count' accept?

A271: It takes no parameters.

Q272: List the parameters for 'get\_arrow\_count'.

A272: None; the parameter list is empty.

Q273: Where in the project is 'get\_arrow\_count' implemented?

A273: In 'Assignment2-AY2526S1/Core/Src/menu\_system.c' near line 58.

Q274: Is 'get\_arrow\_count' declared 'static'?

A274: Yes, it is declared 'static'.

Q275: What is the return type of 'readReg' defined in 'Assignment2-AY2526S1/Core/Src/multi\_switch.c'?

A275: It returns 'int'.

Q276: How many parameters does 'readReg' accept?

A276: It takes 4 parameters.

Q277: List the parameters for 'readReg'.

A277: GroveMultiSwitch\_t \*handle, uint8\_t reg, uint8\_t \*data, int len

Q278: Where in the project is 'readReg' implemented?

A278: In 'Assignment2-AY2526S1/Core/Src/multi\_switch.c' near line 66.

Q279: Is 'readReg' declared 'static'?

A279: Yes, it is declared 'static'.

Q280: What is the return type of 'SSD1306\_ToggleInvert' defined in 'Assignment2-AY2526S1/Core/Src/ssd1306.c'?

A280: It returns 'void'.

Q281: How many parameters does 'SSD1306\_ToggleInvert' accept?

A281: It takes no parameters.

Q282: List the parameters for 'SSD1306\_ToggleInvert'.

A282: None; the parameter list is empty.

Q283: Where in the project is 'SSD1306\_ToggleInvert' implemented?

A283: In 'Assignment2-AY2526S1/Core/Src/ssd1306.c' near line 100.

Q284: Is 'SSD1306\_ToggleInvert' declared 'static'?

A284: No, it is globally visible.

Q285: What is the return type of 'HAL\_I2C\_MspDeInit' defined in 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_hal\_msp.c'?

A285: It returns 'void'.

Q286: How many parameters does 'HAL\_I2C\_MspDeInit' accept?

A286: It takes 1 parameter.

Q287: List the parameters for 'HAL\_I2C\_MspDeInit'.

A287: I2C\_HandleTypeDef\* hi2c

Q288: Where in the project is 'HAL\_I2C\_MspDeInit' implemented?

A288: In 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_hal\_msp.c' near line 99.

Q289: Is 'HAL\_I2C\_MspDeInit' declared 'static'?

A289: No, it is globally visible.

Q290: What is the return type of 'MemManage\_Handler' defined in 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c'?

A290: It returns 'void'.

Q291: How many parameters does 'MemManage\_Handler' accept?

A291: It takes no parameters.

Q292: List the parameters for 'MemManage\_Handler'.

A292: None; the parameter list is empty.

Q293: Where in the project is 'MemManage\_Handler' implemented?

A293: In 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c' near line 99.

Q294: Is 'MemManage\_Handler' declared 'static'?

A294: No, it is globally visible.

Q295: What is the return type of '\_kill' defined in 'Assignment2-AY2526S1/Core/Src/syscalls.c'?

A295: It returns 'int'.

Q296: How many parameters does '\_kill' accept?

A296: It takes 2 parameters.

Q297: List the parameters for '\_kill'.

A297: int pid, int sig

Q298: Where in the project is '\_kill' implemented?

A298: In 'Assignment2-AY2526S1/Core/Src/syscalls.c' near line 53.

Q299: Is '\_kill' declared 'static'?

A299: No, it is globally visible.

Q300: What is the return type of 'BSP\_LED\_DeInit' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c'?



A300: It returns 'void'.

Q301: How many parameters does 'BSP\_LED\_DeInit' accept?

A301: It takes 1 parameter.

Q302: List the parameters for 'BSP\_LED\_DeInit'.

A302: Led\_TypeDef Led

Q303: Where in the project is 'BSP\_LED\_DeInit' implemented?

A303: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c' near line 160.

Q304: Is 'BSP\_LED\_DeInit' declared 'static'?

A304: No, it is globally visible.

Q305: What is the return type of 'BSP\_ACCELERO\_LowPower' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_accelero.c'?

A305: It returns 'void'.

Q306: How many parameters does 'BSP\_ACCELERO\_LowPower' accept?

A306: It takes 1 parameter.

Q307: List the parameters for 'BSP\_ACCELERO\_LowPower'.

A307: uint16\_t status

Q308: Where in the project is 'BSP\_ACCELERO\_LowPower' implemented?

A308: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_accelero.c' near line 106.

Q309: Is 'BSP\_ACCELERO\_LowPower' declared 'static'?

A309: No, it is globally visible.

Q310: What is the return type of 'BSP\_GYRO\_LowPower' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_gyro.c'?

A310: It returns 'void'.

Q311: How many parameters does 'BSP\_GYRO\_LowPower' accept?

A311: It takes 1 parameter.

Q312: List the parameters for 'BSP\_GYRO\_LowPower'.

A312: uint16\_t status

Q313: Where in the project is 'BSP\_GYRO\_LowPower' implemented?

A313: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_gyro.c' near line 111.

Q314: Is 'BSP\_GYRO\_LowPower' declared 'static'?

A314: No, it is globally visible.

Q315: What is the return type of 'BSP\_HSENSOR\_ReadHumidity' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_hsensor.c'?

A315: It returns 'float'.

Q316: How many parameters does 'BSP\_HSENSOR\_ReadHumidity' accept?

A316: It takes no parameters.

Q317: List the parameters for 'BSP\_HSENSOR\_ReadHumidity'.

A317: None; the parameter list is empty.

Q318: Where in the project is 'BSP\_HSENSOR\_ReadHumidity' implemented?

A318: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_hsensor.c' near line

82.

Q319: Is 'BSP\_HSENSOR\_ReadHumidity' declared 'static'?

A319: No, it is globally visible.

Q320: What is the return type of 'BSP\_MAGNETO\_LowPower' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_magneto.c'?

A320: It returns 'void'.

Q321: How many parameters does 'BSP\_MAGNETO\_LowPower' accept?

A321: It takes 1 parameter.

Q322: List the parameters for 'BSP\_MAGNETO\_LowPower'.

A322: uint16\_t status

Q323: Where in the project is 'BSP\_MAGNETO\_LowPower' implemented?

A323: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_magneto.c' near line 97.

Q324: Is 'BSP\_MAGNETO\_LowPower' declared 'static'?

A324: No, it is globally visible.

Q325: What is the return type of 'BSP\_NFCTAG\_isInitialized' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c'?

A325: It returns 'uint8\_t'.

Q326: How many parameters does 'BSP\_NFCTAG\_isInitialized' accept?

A326: It takes 1 parameter.

Q327: List the parameters for 'BSP\_NFCTAG\_isInitialized'.

A327: uint32\_t Instance

Q328: Where in the project is 'BSP\_NFCTAG\_isInitialized' implemented?

A328: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c' near line 121.

Q329: Is 'BSP\_NFCTAG\_isInitialized' declared 'static'?

A329: No, it is globally visible.

Q330: What is the return type of 'BSP\_PSENSOR\_ReadPressure' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_psensor.c'?

A330: It returns 'float'.

Q331: How many parameters does 'BSP\_PSENSOR\_ReadPressure' accept?

A331: It takes no parameters.

Q332: List the parameters for 'BSP\_PSENSOR\_ReadPressure'.

A332: None; the parameter list is empty.

Q333: Where in the project is 'BSP\_PSENSOR\_ReadPressure' implemented?

A333: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_psensor.c' near line 83.

Q334: Is 'BSP\_PSENSOR\_ReadPressure' declared 'static'?

A334: No, it is globally visible.

Q335: What is the return type of 'Buzzer\_Service' defined in 'Assignment2-AY2526S1/Core/Src/buzzer.c'?

A335: It returns 'void'.

Q336: How many parameters does 'Buzzer\_Service' accept?

A336: It takes 1 parameter.

Q337: List the parameters for 'Buzzer\_Service'.

A337: uint32\_t now\_ms

Q338: Where in the project is 'Buzzer\_Service' implemented?

A338: In 'Assignment2-AY2526S1/Core/Src/buzzer.c' near line 81.

Q339: Is 'Buzzer\_Service' declared 'static'?

A339: No, it is globally visible.

Q340: What is the return type of 'grove5way\_read\_event' defined in 'Assignment2-AY2526S1/Core/Src/grove\_5way.c'?

A340: It returns 'bool'.

Q341: How many parameters does 'grove5way\_read\_event' accept?

A341: It takes 2 parameters.

Q342: List the parameters for 'grove5way\_read\_event'.

A342: Grove5Way\_Handle \*handle, uint8\_t \*button\_bytes

Q343: Where in the project is 'grove5way\_read\_event' implemented?

A343: In 'Assignment2-AY2526S1/Core/Src/grove\_5way.c' near line 103.

Q344: Is 'grove5way\_read\_event' declared 'static'?

A344: Yes, it is declared 'static'.

Q345: What is the return type of 'HT16K33\_SetBrightness' defined in 'Assignment2-AY2526S1/Core/Src/ht16k33.c'?

A345: It returns 'HAL\_StatusTypeDef'.

Q346: How many parameters does 'HT16K33\_SetBrightness' accept?

A346: It takes 2 parameters.

Q347: List the parameters for 'HT16K33\_SetBrightness'.

A347: HT16K33\_HandleTypeDef \*h, uint8\_t level

Q348: Where in the project is 'HT16K33\_SetBrightness' implemented?

A348: In 'Assignment2-AY2526S1/Core/Src/ht16k33.c' near line 40.

Q349: Is 'HT16K33\_SetBrightness' declared 'static'?

A349: No, it is globally visible.

Q350: What is the return type of 'HAL\_GPIO\_EXTI\_Callback' defined in 'Assignment2-AY2526S1/Core/Src/main.c'?

A350: It returns 'void'.

Q351: How many parameters does 'HAL\_GPIO\_EXTI\_Callback' accept?

A351: It takes 1 parameter.

Q352: List the parameters for 'HAL\_GPIO\_EXTI\_Callback'.

A352: uint16\_t GPIO\_Pin

Q353: Where in the project is 'HAL\_GPIO\_EXTI\_Callback' implemented?

A353: In 'Assignment2-AY2526S1/Core/Src/main.c' near line 206.

Q354: Is 'HAL\_GPIO\_EXTI\_Callback' declared 'static'?

A354: No, it is globally visible.

Q355: What is the return type of 'set\_arrow\_count' defined in 'Assignment2-AY2526S1/Core/Src/menu\_system.c'?

A355: It returns 'void'.

Q356: How many parameters does 'set\_arrow\_count' accept?

A356: It takes 1 parameter.

Q357: List the parameters for 'set\_arrow\_count'.

A357: float value

Q358: Where in the project is 'set\_arrow\_count' implemented?

A358: In 'Assignment2-AY2526S1/Core/Src/menu\_system.c' near line 63.

Q359: Is 'set\_arrow\_count' declared 'static'?

A359: Yes, it is declared 'static'.

Q360: What is the return type of 'GroveMultiSwitch\_Init' defined in 'Assignment2-AY2526S1/Core/Src/multi\_switch.c'?

A360: It returns 'bool'.

Q361: How many parameters does 'GroveMultiSwitch\_Init' accept?

A361: It takes 3 parameters.

Q362: List the parameters for 'GroveMultiSwitch\_Init'.

A362: GroveMultiSwitch\_t \*handle, I2C\_HandleTypeDef \*hi2c, uint8\_t addr

Q363: Where in the project is 'GroveMultiSwitch\_Init' implemented?

A363: In 'Assignment2-AY2526S1/Core/Src/multi\_switch.c' near line 87.

Q364: Is 'GroveMultiSwitch\_Init' declared 'static'?

A364: No, it is globally visible.

Q365: What is the return type of 'SSD1306\_Fill' defined in 'Assignment2-AY2526S1/Core/Src/ssd1306.c'?

A365: It returns 'void'.

Q366: How many parameters does 'SSD1306\_Fill' accept?

A366: It takes 1 parameter.

Q367: List the parameters for 'SSD1306\_Fill'.

A367: SSD1306\_COLOR\_t color

Q368: Where in the project is 'SSD1306\_Fill' implemented?

A368: In 'Assignment2-AY2526S1/Core/Src/ssd1306.c' near line 107.

Q369: Is 'SSD1306\_Fill' declared 'static'?

A369: No, it is globally visible.

Q370: What is the return type of 'HAL\_TIM\_Base\_MspInit' defined in 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_hal\_msp.c'?

A370: It returns 'void'.

Q371: How many parameters does 'HAL\_TIM\_Base\_MspInit' accept?

A371: It takes 1 parameter.

Q372: List the parameters for 'HAL\_TIM\_Base\_MspInit'.

A372: TIM\_HandleTypeDef\* htim\_base

Q373: Where in the project is 'HAL\_TIM\_Base\_MspInit' implemented?

A373: In 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_hal\_msp.c' near line 108.

Q374: Is 'HAL\_TIM\_Base\_MspInit' declared 'static'?

A374: No, it is globally visible.

Q375: What is the return type of 'BusFault\_Handler' defined in 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c'?

A375: It returns 'void'.

Q376: How many parameters does 'BusFault\_Handler' accept?

A376: It takes no parameters.

Q377: List the parameters for 'BusFault\_Handler'.

A377: None; the parameter list is empty.

Q378: Where in the project is 'BusFault\_Handler' implemented?

A378: In 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c' near line 114.

Q379: Is 'BusFault\_Handler' declared 'static'?

A379: No, it is globally visible.

Q380: What is the return type of '\_exit' defined in 'Assignment2-AY2526S1/Core/Src/syscalls.c'?

A380: It returns 'void'.

Q381: How many parameters does '\_exit' accept?

A381: It takes 1 parameter.

Q382: List the parameters for '\_exit'.

A382: int status

Q383: Where in the project is '\_exit' implemented?

A383: In 'Assignment2-AY2526S1/Core/Src/syscalls.c' near line 59.

Q384: Is '\_exit' declared 'static'?

A384: No, it is globally visible.

Q385: What is the return type of 'BSP\_LED\_On' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c'?

A385: It returns 'void'.

Q386: How many parameters does 'BSP\_LED\_On' accept?

A386: It takes 1 parameter.

Q387: List the parameters for 'BSP\_LED\_On'.

A387: Led\_TypeDef Led

Q388: Where in the project is 'BSP\_LED\_On' implemented?

A388: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c' near line 178.

Q389: Is 'BSP\_LED\_On' declared 'static'?

A389: No, it is globally visible.

Q390: What is the return type of 'BSP\_ACCELERO\_AccGetXYZ' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_accelero.c'?

A390: It returns 'void'.

Q391: How many parameters does 'BSP\_ACCELERO\_AccGetXYZ' accept?

A391: It takes 1 parameter.

Q392: List the parameters for 'BSP\_ACCELERO\_AccGetXYZ'.

A392: int16\_t \*pDataXYZ

Q393: Where in the project is 'BSP\_ACCELERO\_AccGetXYZ' implemented?

A393: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_accelero.c' near line 124.

Q394: Is 'BSP\_ACCELERO\_AccGetXYZ' declared 'static'?

A394: No, it is globally visible.

Q395: What is the return type of 'BSP\_GYRO\_GetXYZ' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_gyro.c'?

A395: It returns 'void'.

Q396: How many parameters does 'BSP\_GYRO\_GetXYZ' accept?

A396: It takes 1 parameter.

Q397: List the parameters for 'BSP\_GYRO\_GetXYZ'.

A397: float\* pData

Q398: Where in the project is 'BSP\_GYRO\_GetXYZ' implemented?

A398: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_gyro.c' near line 127.

Q399: Is 'BSP\_GYRO\_GetXYZ' declared 'static'?

A399: No, it is globally visible.

Q400: What is the return type of 'BSP\_MAGNETO\_GetXYZ' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_magneto.c'?

A400: It returns 'void'.

Q401: How many parameters does 'BSP\_MAGNETO\_GetXYZ' accept?

A401: It takes 1 parameter.

Q402: List the parameters for 'BSP\_MAGNETO\_GetXYZ'.

A402: int16\_t \*pDataXYZ

Q403: Where in the project is 'BSP\_MAGNETO\_GetXYZ' implemented?

A403: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_magneto.c' near line 114.

Q404: Is 'BSP\_MAGNETO\_GetXYZ' declared 'static'?

A404: No, it is globally visible.

Q405: What is the return type of 'BSP\_NFCTAG\_ReadID' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c'?

A405: It returns 'int32\_t'.

Q406: How many parameters does 'BSP\_NFCTAG\_ReadID' accept?

A406: It takes 2 parameters.

Q407: List the parameters for 'BSP\_NFCTAG\_ReadID'.

A407: uint32\_t Instance, uint8\_t \* const wai\_id

Q408: Where in the project is 'BSP\_NFCTAG\_ReadID' implemented?

A408: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c' near line 132.

Q409: Is 'BSP\_NFCTAG\_ReadID' declared 'static'?

A409: No, it is globally visible.

Q410: What is the return type of 'Buzzer\_TestPattern' defined in

'Assignment2-AY2526S1/Core/Src/buzzer.c'?

A410: It returns 'void'.

Q411: How many parameters does 'Buzzer\_TestPattern' accept?

A411: It takes no parameters.

Q412: List the parameters for 'Buzzer\_TestPattern'.

A412: None; the parameter list is empty.

Q413: Where in the project is 'Buzzer\_TestPattern' implemented?

A413: In 'Assignment2-AY2526S1/Core/Src/buzzer.c' near line 104.

Q414: Is 'Buzzer\_TestPattern' declared 'static'?

A414: No, it is globally visible.

Q415: What is the return type of 'HT16K33\_SetBlinkRate' defined in 'Assignment2-AY2526S1/Core/Src/ht16k33.c'?

A415: It returns 'HAL\_StatusTypeDef'.

Q416: How many parameters does 'HT16K33\_SetBlinkRate' accept?

A416: It takes 2 parameters.

Q417: List the parameters for 'HT16K33\_SetBlinkRate'.

A417: HT16K33\_HandleTypeDef \*h, uint8\_t rate

Q418: Where in the project is 'HT16K33\_SetBlinkRate' implemented?

A418: In 'Assignment2-AY2526S1/Core/Src/ht16k33.c' near line 47.

Q419: Is 'HT16K33\_SetBlinkRate' declared 'static'?

A419: No, it is globally visible.

Q420: What is the return type of 'process\_clicks' defined in 'Assignment2-AY2526S1/Core/Src/main.c'?

A420: It returns 'void'.

Q421: How many parameters does 'process\_clicks' accept?

A421: It takes 1 parameter.

Q422: List the parameters for 'process\_clicks'.

A422: uint32\_t now

Q423: Where in the project is 'process\_clicks' implemented?

A423: In 'Assignment2-AY2526S1/Core/Src/main.c' near line 214.

Q424: Is 'process\_clicks' declared 'static'?

A424: Yes, it is declared 'static'.

Q425: What is the return type of 'get\_sequence\_time' defined in 'Assignment2-AY2526S1/Core/Src/menu\_system.c'?

A425: It returns 'float'.

Q426: How many parameters does 'get\_sequence\_time' accept?

A426: It takes no parameters.

Q427: List the parameters for 'get\_sequence\_time'.

A427: None; the parameter list is empty.

Q428: Where in the project is 'get\_sequence\_time' implemented?

A428: In 'Assignment2-AY2526S1/Core/Src/menu\_system.c' near line 72.

Q429: Is 'get\_sequence\_time' declared 'static'?

A429: Yes, it is declared 'static'.

Q430: What is the return type of 'GroveMultiSwitch\_ProbeDevID' defined in 'Assignment2-AY2526S1/Core/Src/multi\_switch.c'?

A430: It returns 'uint32\_t'.

Q431: How many parameters does 'GroveMultiSwitch\_ProbeDevID' accept?

A431: It takes 1 parameter.

Q432: List the parameters for 'GroveMultiSwitch\_ProbeDevID'.

A432: GroveMultiSwitch\_t \*handle

Q433: Where in the project is 'GroveMultiSwitch\_ProbeDevID' implemented?

A433: In 'Assignment2-AY2526S1/Core/Src/multi\_switch.c' near line 120.

Q434: Is 'GroveMultiSwitch\_ProbeDevID' declared 'static'?

A434: No, it is globally visible.

Q435: What is the return type of 'SSD1306\_DrawPixel' defined in 'Assignment2-AY2526S1/Core/Src/ssd1306.c'?

A435: It returns 'void'.

Q436: How many parameters does 'SSD1306\_DrawPixel' accept?

A436: It takes 3 parameters.

Q437: List the parameters for 'SSD1306\_DrawPixel'.

A437: uint16\_t x, uint16\_t y, SSD1306\_COLOR\_t color

Q438: Where in the project is 'SSD1306\_DrawPixel' implemented?

A438: In 'Assignment2-AY2526S1/Core/Src/ssd1306.c' near line 111.

Q439: Is 'SSD1306\_DrawPixel' declared 'static'?

A439: No, it is globally visible.

Q440: What is the return type of 'HAL\_TIM\_Base\_MspDeInit' defined in 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_hal\_msp.c'?

A440: It returns 'void'.

Q441: How many parameters does 'HAL\_TIM\_Base\_MspDeInit' accept?

A441: It takes 1 parameter.

Q442: List the parameters for 'HAL\_TIM\_Base\_MspDeInit'.

A442: TIM\_HandleTypeDef\* htim\_base

Q443: Where in the project is 'HAL\_TIM\_Base\_MspDeInit' implemented?

A443: In 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_hal\_msp.c' near line 118.

Q444: Is 'HAL\_TIM\_Base\_MspDeInit' declared 'static'?

A444: No, it is globally visible.

Q445: What is the return type of 'UsageFault\_Handler' defined in 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c'?

A445: It returns 'void'.

Q446: How many parameters does 'UsageFault\_Handler' accept?

A446: It takes no parameters.

Q447: List the parameters for 'UsageFault\_Handler'.

A447: None; the parameter list is empty.



Q448: Where in the project is 'UsageFault\_Handler' implemented?

A448: In 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c' near line 129.

Q449: Is 'UsageFault\_Handler' declared 'static'?

A449: No, it is globally visible.

Q450: What is the return type of '\_close' defined in 'Assignment2-AY2526S1/Core/Src/syscalls.c'?

A450: It returns 'int'.

Q451: How many parameters does '\_close' accept?

A451: It takes 1 parameter.

Q452: List the parameters for '\_close'.

A452: int file

Q453: Where in the project is '\_close' implemented?

A453: In 'Assignment2-AY2526S1/Core/Src/syscalls.c' near line 88.

Q454: Is '\_close' declared 'static'?

A454: No, it is globally visible.

Q455: What is the return type of 'BSP\_LED\_Off' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c'?

A455: It returns 'void'.

Q456: How many parameters does 'BSP\_LED\_Off' accept?

A456: It takes 1 parameter.

Q457: List the parameters for 'BSP\_LED\_Off'.

A457: Led\_TypeDef Led

Q458: Where in the project is 'BSP\_LED\_Off' implemented?

A458: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c' near line 189.

Q459: Is 'BSP\_LED\_Off' declared 'static'?

A459: No, it is globally visible.

Q460: What is the return type of 'BSP\_NFCTAG\_IsDeviceReady' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c'?

A460: It returns 'int32\_t'.

Q461: How many parameters does 'BSP\_NFCTAG\_IsDeviceReady' accept?

A461: It takes 2 parameters.

Q462: List the parameters for 'BSP\_NFCTAG\_IsDeviceReady'.

A462: uint32\_t Instance, const uint32\_t Trials

Q463: Where in the project is 'BSP\_NFCTAG\_IsDeviceReady' implemented?

A463: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c' near line 148.

Q464: Is 'BSP\_NFCTAG\_IsDeviceReady' declared 'static'?

A464: No, it is globally visible.

Q465: What is the return type of 'Buzzer\_IRQHandler' defined in

'Assignment2-AY2526S1/Core/Src/buzzer.c'?

A465: It returns 'void'.

Q466: How many parameters does 'Buzzer\_IRQHandler' accept?

A466: It takes no parameters.

Q467: List the parameters for 'Buzzer\_IRQHandler'.

A467: None; the parameter list is empty.

Q468: Where in the project is 'Buzzer\_IRQHandler' implemented?

A468: In 'Assignment2-AY2526S1/Core/Src/buzzer.c' near line 137.

Q469: Is 'Buzzer\_IRQHandler' declared 'static'?

A469: No, it is globally visible.

Q470: What is the return type of 'HT16K33\_Update' defined in

'Assignment2-AY2526S1/Core/Src/ht16k33.c'?

A470: It returns 'HAL\_StatusTypeDef'.

Q471: How many parameters does 'HT16K33\_Update' accept?

A471: It takes 1 parameter.

Q472: List the parameters for 'HT16K33\_Update'.

A472: const HT16K33\_HandleTypeDef \*h

Q473: Where in the project is 'HT16K33\_Update' implemented?

A473: In 'Assignment2-AY2526S1/Core/Src/ht16k33.c' near line 55.

Q474: Is 'HT16K33\_Update' declared 'static'?

A474: No, it is globally visible.

Q475: What is the return type of 'GameOver\_Trigger' defined in

'Assignment2-AY2526S1/Core/Src/main.c'?

A475: It returns 'void'.

Q476: How many parameters does 'GameOver\_Trigger' accept?

A476: It takes 2 parameters.

Q477: List the parameters for 'GameOver\_Trigger'.

A477: game\_t game, const char \*message

Q478: Where in the project is 'GameOver\_Trigger' implemented?

A478: In 'Assignment2-AY2526S1/Core/Src/main.c' near line 298.

Q479: Is 'GameOver\_Trigger' declared 'static'?

A479: Yes, it is declared 'static'.

Q480: What is the return type of 'set\_sequence\_time' defined in

'Assignment2-AY2526S1/Core/Src/menu\_system.c'?

A480: It returns 'void'.

Q481: How many parameters does 'set\_sequence\_time' accept?

A481: It takes 1 parameter.

Q482: List the parameters for 'set\_sequence\_time'.

A482: float value

Q483: Where in the project is 'set\_sequence\_time' implemented?

A483: In 'Assignment2-AY2526S1/Core/Src/menu\_system.c' near line 78.

Q484: Is 'set\_sequence\_time' declared 'static'?

A484: Yes, it is declared 'static'.

Q485: What is the return type of 'GroveMultiSwitch\_GetDevID' defined in 'Assignment2-AY2526S1/Core/Src/multi\_switch.c'?

A485: It returns 'uint32\_t'.

Q486: How many parameters does 'GroveMultiSwitch\_GetDevID' accept?

A486: It takes 1 parameter.

Q487: List the parameters for 'GroveMultiSwitch\_GetDevID'.

A487: GroveMultiSwitch\_t \*handle

Q488: Where in the project is 'GroveMultiSwitch\_GetDevID' implemented?

A488: In 'Assignment2-AY2526S1/Core/Src/multi\_switch.c' near line 152.

Q489: Is 'GroveMultiSwitch\_GetDevID' declared 'static'?

A489: No, it is globally visible.

Q490: What is the return type of 'SSD1306\_GotoXY' defined in

'Assignment2-AY2526S1/Core/Src/ssd1306.c'?

A490: It returns 'void'.

Q491: How many parameters does 'SSD1306\_GotoXY' accept?

A491: It takes 2 parameters.

Q492: List the parameters for 'SSD1306\_GotoXY'.

A492: uint16\_t x, uint16\_t y

Q493: Where in the project is 'SSD1306\_GotoXY' implemented?

A493: In 'Assignment2-AY2526S1/Core/Src/ssd1306.c' near line 125.

Q494: Is 'SSD1306\_GotoXY' declared 'static'?

A494: No, it is globally visible.

Q495: What is the return type of 'SVC\_Handler' defined in

'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c'?

A495: It returns 'void'.

Q496: How many parameters does 'SVC\_Handler' accept?

A496: It takes no parameters.

Q497: List the parameters for 'SVC\_Handler'.

A497: None; the parameter list is empty.

Q498: Where in the project is 'SVC\_Handler' implemented?

A498: In 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c' near line 144.

Q499: Is 'SVC\_Handler' declared 'static'?

A499: No, it is globally visible.

Q500: What is the return type of '\_fstat' defined in

'Assignment2-AY2526S1/Core/Src/syscalls.c'?

A500: It returns 'int'.

Q501: How many parameters does '\_fstat' accept?

A501: It takes 2 parameters.

Q502: List the parameters for '\_fstat'.

A502: int file, struct stat \*st

Q503: Where in the project is '\_fstat' implemented?

A503: In 'Assignment2-AY2526S1/Core/Src/syscalls.c' near line 94.

Q504: Is '\_fstat' declared 'static'?

A504: No, it is globally visible.

Q505: What is the return type of 'BSP\_LED\_Toggle' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c'?

A505: It returns 'void'.

Q506: How many parameters does 'BSP\_LED\_Toggle' accept?

A506: It takes 1 parameter.

Q507: List the parameters for 'BSP\_LED\_Toggle'.

A507: Led\_TypeDef Led

Q508: Where in the project is 'BSP\_LED\_Toggle' implemented?

A508: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c' near line 200.

Q509: Is 'BSP\_LED\_Toggle' declared 'static'?

A509: No, it is globally visible.

Q510: What is the return type of 'BSP\_NFCTAG\_ConfigIT' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c'?

A510: It returns 'int32\_t'.

Q511: How many parameters does 'BSP\_NFCTAG\_ConfigIT' accept?

A511: It takes 2 parameters.

Q512: List the parameters for 'BSP\_NFCTAG\_ConfigIT'.

A512: uint32\_t Instance, const uint16\_t ITConfig

Q513: Where in the project is 'BSP\_NFCTAG\_ConfigIT' implemented?

A513: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c' near line 166.

Q514: Is 'BSP\_NFCTAG\_ConfigIT' declared 'static'?

A514: No, it is globally visible.

Q515: What is the return type of 'HAL\_TIM\_PeriodElapsedCallback' defined in 'Assignment2-AY2526S1/Core/Src/buzzer.c'?

A515: It returns 'void'.

Q516: How many parameters does 'HAL\_TIM\_PeriodElapsedCallback' accept?

A516: It takes 1 parameter.

Q517: List the parameters for 'HAL\_TIM\_PeriodElapsedCallback'.

A517: TIM\_HandleTypeDef \*htim

Q518: Where in the project is 'HAL\_TIM\_PeriodElapsedCallback' implemented?

A518: In 'Assignment2-AY2526S1/Core/Src/buzzer.c' near line 142.

Q519: Is 'HAL\_TIM\_PeriodElapsedCallback' declared 'static'?

A519: No, it is globally visible.

Q520: What is the return type of 'HT16K33\_Clear' defined in 'Assignment2-AY2526S1/Core/Src/ht16k33.c'?

A520: It returns 'void'.

Q521: How many parameters does 'HT16K33\_Clear' accept?

A521: It takes 1 parameter.

Q522: List the parameters for 'HT16K33\_Clear'.

A522: HT16K33\_HandleTypeDef \*h

Q523: Where in the project is 'HT16K33\_Clear' implemented?

A523: In 'Assignment2-AY2526S1/Core/Src/ht16k33.c' near line 66.

Q524: Is 'HT16K33\_Clear' declared 'static'?

A524: No, it is globally visible.

Q525: What is the return type of 'GameReset\_Attempt' defined in 'Assignment2-AY2526S1/Core/Src/main.c'?

A525: It returns 'uint8\_t'.

Q526: How many parameters does 'GameReset\_Attempt' accept?

A526: It takes 3 parameters.

Q527: List the parameters for 'GameReset\_Attempt'.

A527: game\_t game, uint32\_t now, int catch\_level

Q528: Where in the project is 'GameReset\_Attempt' implemented?

A528: In 'Assignment2-AY2526S1/Core/Src/main.c' near line 364.

Q529: Is 'GameReset\_Attempt' declared 'static'?

A529: Yes, it is declared 'static'.

Q530: What is the return type of 'Menu\_Init' defined in 'Assignment2-AY2526S1/Core/Src/menu\_system.c'?

A530: It returns 'void'.

Q531: How many parameters does 'Menu\_Init' accept?

A531: It takes 3 parameters.

Q532: List the parameters for 'Menu\_Init'.

A532: menu\_handle\_t \*menu, Grove5Way\_Handle \*switch\_handle, uint8\_t game\_id

Q533: Where in the project is 'Menu\_Init' implemented?

A533: In 'Assignment2-AY2526S1/Core/Src/menu\_system.c' near line 87.

Q534: Is 'Menu\_Init' declared 'static'?

A534: No, it is globally visible.

Q535: What is the return type of 'GroveMultiSwitch\_GetDevVer' defined in 'Assignment2-AY2526S1/Core/Src/multi\_switch.c'?

A535: It returns 'const char\*'.

Q536: How many parameters does 'GroveMultiSwitch\_GetDevVer' accept?

A536: It takes 1 parameter.

Q537: List the parameters for 'GroveMultiSwitch\_GetDevVer'.

A537: GroveMultiSwitch\_t \*handle

Q538: Where in the project is 'GroveMultiSwitch\_GetDevVer' implemented?

A538: In 'Assignment2-AY2526S1/Core/Src/multi\_switch.c' near line 162.

Q539: Is 'GroveMultiSwitch\_GetDevVer' declared 'static'?

A539: No, it is globally visible.

Q540: What is the return type of 'SSD1306\_Putc' defined in 'Assignment2-AY2526S1/Core/Src/ssd1306.c'?

A540: It returns 'char'.

Q541: How many parameters does 'SSD1306\_Putc' accept?

A541: It takes 3 parameters.

Q542: List the parameters for 'SSD1306\_Putc'.

A542: char ch, FontDef\_t\* Font, SSD1306\_COLOR\_t color

Q543: Where in the project is 'SSD1306\_Putc' implemented?

A543: In 'Assignment2-AY2526S1/Core/Src/ssd1306.c' near line 130.

Q544: Is 'SSD1306\_Putc' declared 'static'?

A544: No, it is globally visible.

Q545: What is the return type of 'DebugMon\_Handler' defined in

'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c'?

A545: It returns 'void'.

Q546: How many parameters does 'DebugMon\_Handler' accept?

A546: It takes no parameters.

Q547: List the parameters for 'DebugMon\_Handler'.

A547: None; the parameter list is empty.

Q548: Where in the project is 'DebugMon\_Handler' implemented?

A548: In 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c' near line 157.

Q549: Is 'DebugMon\_Handler' declared 'static'?

A549: No, it is globally visible.

Q550: What is the return type of '\_isatty' defined in

'Assignment2-AY2526S1/Core/Src/syscalls.c'?

A550: It returns 'int'.

Q551: How many parameters does '\_isatty' accept?

A551: It takes 1 parameter.

Q552: List the parameters for '\_isatty'.

A552: int file

Q553: Where in the project is '\_isatty' implemented?

A553: In 'Assignment2-AY2526S1/Core/Src/syscalls.c' near line 100.

Q554: Is '\_isatty' declared 'static'?

A554: No, it is globally visible.

Q555: What is the return type of 'BSP\_PB\_Init' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c'?

A555: It returns 'void'.

Q556: How many parameters does 'BSP\_PB\_Init' accept?

A556: It takes 2 parameters.

Q557: List the parameters for 'BSP\_PB\_Init'.

A557: Button\_TypeDef Button, ButtonMode\_TypeDef ButtonMode

Q558: Where in the project is 'BSP\_PB\_Init' implemented?

A558: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c' near line 216.

Q559: Is 'BSP\_PB\_Init' declared 'static'?

A559: No, it is globally visible.

Q560: What is the return type of 'BSP\_NFCTAG\_GetITStatus' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c'?

A560: It returns 'int32\_t'.

Q561: How many parameters does 'BSP\_NFCTAG\_GetITStatus' accept?

A561: It takes 2 parameters.

Q562: List the parameters for 'BSP\_NFCTAG\_GetITStatus'.

A562: uint32\_t Instance, uint16\_t \* const ITConfig

Q563: Where in the project is 'BSP\_NFCTAG\_GetITStatus' implemented?

A563: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c' near line 183.

Q564: Is 'BSP\_NFCTAG\_GetITStatus' declared 'static'?

A564: No, it is globally visible.

Q565: What is the return type of 'Buzzer\_TIM\_Init' defined in 'Assignment2-AY2526S1/Core/Src/buzzer.c'?

A565: It returns 'void'.

Q566: How many parameters does 'Buzzer\_TIM\_Init' accept?

A566: It takes no parameters.

Q567: List the parameters for 'Buzzer\_TIM\_Init'.

A567: None; the parameter list is empty.

Q568: Where in the project is 'Buzzer\_TIM\_Init' implemented?

A568: In 'Assignment2-AY2526S1/Core/Src/buzzer.c' near line 151.

Q569: Is 'Buzzer\_TIM\_Init' declared 'static'?

A569: Yes, it is declared 'static'.

Q570: What is the return type of 'HT16K33\_SetRow' defined in 'Assignment2-AY2526S1/Core/Src/ht16k33.c'?

A570: It returns 'void'.

Q571: How many parameters does 'HT16K33\_SetRow' accept?

A571: It takes 3 parameters.

Q572: List the parameters for 'HT16K33\_SetRow'.

A572: HT16K33\_HandleTypeDef \*h, uint8\_t row, uint8\_t pattern

Q573: Where in the project is 'HT16K33\_SetRow' implemented?

A573: In 'Assignment2-AY2526S1/Core/Src/ht16k33.c' near line 74.

Q574: Is 'HT16K33\_SetRow' declared 'static'?

A574: No, it is globally visible.

Q575: What is the return type of 'CalibrateGyroscope' defined in 'Assignment2-AY2526S1/Core/Src/main.c'?

A575: It returns 'void'.

Q576: How many parameters does 'CalibrateGyroscope' accept?

A576: It takes no parameters.

Q577: List the parameters for 'CalibrateGyroscope'.

A577: None; the parameter list is empty.

Q578: Where in the project is 'CalibrateGyroscope' implemented?

A578: In 'Assignment2-AY2526S1/Core/Src/main.c' near line 405.

Q579: Is 'CalibrateGyroscope' declared 'static'?

A579: No, it is globally visible.

Q580: What is the return type of 'Menu\_SetGame' defined in

'Assignment2-AY2526S1/Core/Src/menu\_system.c'?

A580: It returns 'void'.

Q581: How many parameters does 'Menu\_SetGame' accept?

A581: It takes 2 parameters.

Q582: List the parameters for 'Menu\_SetGame'.

A582: menu\_handle\_t \*menu, uint8\_t game\_id

Q583: Where in the project is 'Menu\_SetGame' implemented?

A583: In 'Assignment2-AY2526S1/Core/Src/menu\_system.c' near line 98.

Q584: Is 'Menu\_SetGame' declared 'static'?

A584: No, it is globally visible.

Q585: What is the return type of 'GroveMultiSwitch\_SetDevAddr' defined in

'Assignment2-AY2526S1/Core/Src/multi\_switch.c'?

A585: It returns 'void'.

Q586: How many parameters does 'GroveMultiSwitch\_SetDevAddr' accept?

A586: It takes 2 parameters.

Q587: List the parameters for 'GroveMultiSwitch\_SetDevAddr'.

A587: GroveMultiSwitch\_t \*handle, uint8\_t addr

Q588: Where in the project is 'GroveMultiSwitch\_SetDevAddr' implemented?

A588: In 'Assignment2-AY2526S1/Core/Src/multi\_switch.c' near line 186.

Q589: Is 'GroveMultiSwitch\_SetDevAddr' declared 'static'?

A589: No, it is globally visible.

Q590: What is the return type of 'SSD1306\_Puts' defined in

'Assignment2-AY2526S1/Core/Src/ssd1306.c'?

A590: It returns 'char'.

Q591: How many parameters does 'SSD1306\_Puts' accept?

A591: It takes 3 parameters.

Q592: List the parameters for 'SSD1306\_Puts'.

A592: char\* str, FontDef\_t\* Font, SSD1306\_COLOR\_t color

Q593: Where in the project is 'SSD1306\_Puts' implemented?

A593: In 'Assignment2-AY2526S1/Core/Src/ssd1306.c' near line 151.

Q594: Is 'SSD1306\_Puts' declared 'static'?

A594: No, it is globally visible.

Q595: What is the return type of 'PendSV\_Handler' defined in

'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c'?

A595: It returns 'void'.

Q596: How many parameters does 'PendSV\_Handler' accept?

A596: It takes no parameters.



Q597: List the parameters for 'PendSV\_Handler'.

A597: None; the parameter list is empty.

Q598: Where in the project is 'PendSV\_Handler' implemented?

A598: In 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c' near line 170.

Q599: Is 'PendSV\_Handler' declared 'static'?

A599: No, it is globally visible.

Q600: What is the return type of '\_lseek' defined in 'Assignment2-AY2526S1/Core/Src/syscalls.c'?

A600: It returns 'int'.

Q601: How many parameters does '\_lseek' accept?

A601: It takes 3 parameters.

Q602: List the parameters for '\_lseek'.

A602: int file, int ptr, int dir

Q603: Where in the project is '\_lseek' implemented?

A603: In 'Assignment2-AY2526S1/Core/Src/syscalls.c' near line 105.

Q604: Is '\_lseek' declared 'static'?

A604: No, it is globally visible.

Q605: What is the return type of 'BSP\_PB\_DeInit' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c'?

A605: It returns 'void'.

Q606: How many parameters does 'BSP\_PB\_DeInit' accept?

A606: It takes 1 parameter.

Q607: List the parameters for 'BSP\_PB\_DeInit'.

A607: Button\_TypeDef Button

Q608: Where in the project is 'BSP\_PB\_DeInit' implemented?

A608: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c' near line 257.

Q609: Is 'BSP\_PB\_DeInit' declared 'static'?

A609: No, it is globally visible.

Q610: What is the return type of 'BSP\_NFCTAG\_ReadData' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c'?

A610: It returns 'int32\_t'.

Q611: How many parameters does 'BSP\_NFCTAG\_ReadData' accept?

A611: It takes 4 parameters.

Q612: List the parameters for 'BSP\_NFCTAG\_ReadData'.

A612: uint32\_t Instance, uint8\_t \* const pData, const uint16\_t TarAddr, const uint16\_t Size

Q613: Where in the project is 'BSP\_NFCTAG\_ReadData' implemented?

A613: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c' near line 201.

Q614: Is 'BSP\_NFCTAG\_ReadData' declared 'static'?

A614: No, it is globally visible.

Q615: What is the return type of 'Buzzer\_Set' defined in

'Assignment2-AY2526S1/Core/Src/buzzer.c'?

A615: It returns 'void'.

Q616: How many parameters does 'Buzzer\_Set' accept?

A616: It takes 1 parameter.

Q617: List the parameters for 'Buzzer\_Set'.

A617: uint8\_t on

Q618: Where in the project is 'Buzzer\_Set' implemented?

A618: In 'Assignment2-AY2526S1/Core/Src/buzzer.c' near line 178.

Q619: Is 'Buzzer\_Set' declared 'static'?

A619: Yes, it is declared 'static'.

Q620: What is the return type of 'HT16K33\_DrawBitmap64' defined in 'Assignment2-AY2526S1/Core/Src/ht16k33.c'?

A620: It returns 'void'.

Q621: How many parameters does 'HT16K33\_DrawBitmap64' accept?

A621: It takes 2 parameters.

Q622: List the parameters for 'HT16K33\_DrawBitmap64'.

A622: HT16K33\_HandleTypeDef \*h, uint64\_t bitmap

Q623: Where in the project is 'HT16K33\_DrawBitmap64' implemented?

A623: In 'Assignment2-AY2526S1/Core/Src/ht16k33.c' near line 82.

Q624: Is 'HT16K33\_DrawBitmap64' declared 'static'?

A624: No, it is globally visible.

Q625: What is the return type of 'MX\_I2C1\_Init' defined in 'Assignment2-AY2526S1/Core/Src/main.c'?

A625: It returns 'void'.

Q626: How many parameters does 'MX\_I2C1\_Init' accept?

A626: It takes no parameters.

Q627: List the parameters for 'MX\_I2C1\_Init'.

A627: None; the parameter list is empty.

Q628: Where in the project is 'MX\_I2C1\_Init' implemented?

A628: In 'Assignment2-AY2526S1/Core/Src/main.c' near line 436.

Q629: Is 'MX\_I2C1\_Init' declared 'static'?

A629: No, it is globally visible.

Q630: What is the return type of 'get\_param\_value' defined in 'Assignment2-AY2526S1/Core/Src/menu\_system.c'?

A630: It returns 'float'.

Q631: How many parameters does 'get\_param\_value' accept?

A631: It takes 1 parameter.

Q632: List the parameters for 'get\_param\_value'.

A632: param\_id\_t param\_id

Q633: Where in the project is 'get\_param\_value' implemented?

A633: In 'Assignment2-AY2526S1/Core/Src/menu\_system.c' near line 113.

Q634: Is 'get\_param\_value' declared 'static'?

A634: Yes, it is declared 'static'.

Q635: What is the return type of 'GroveMultiSwitch\_GetSwitchCount' defined in 'Assignment2-AY2526S1/Core/Src/multi\_switch.c'?

A635: It returns 'int'.

Q636: How many parameters does 'GroveMultiSwitch\_GetSwitchCount' accept?

A636: It takes 1 parameter.

Q637: List the parameters for 'GroveMultiSwitch\_GetSwitchCount'.

A637: GroveMultiSwitch\_t \*handle

Q638: Where in the project is 'GroveMultiSwitch\_GetSwitchCount' implemented?

A638: In 'Assignment2-AY2526S1/Core/Src/multi\_switch.c' near line 204.

Q639: Is 'GroveMultiSwitch\_GetSwitchCount' declared 'static'?

A639: No, it is globally visible.

Q640: What is the return type of 'SSD1306\_DrawLine' defined in 'Assignment2-AY2526S1/Core/Src/ssd1306.c'?

A640: It returns 'void'.

Q641: How many parameters does 'SSD1306\_DrawLine' accept?

A641: It takes 5 parameters.

Q642: List the parameters for 'SSD1306\_DrawLine'.

A642: uint16\_t x0, uint16\_t y0, uint16\_t x1, uint16\_t y1, SSD1306\_COLOR\_t c

Q643: Where in the project is 'SSD1306\_DrawLine' implemented?

A643: In 'Assignment2-AY2526S1/Core/Src/ssd1306.c' near line 161.

Q644: Is 'SSD1306\_DrawLine' declared 'static'?

A644: No, it is globally visible.

Q645: What is the return type of 'SysTick\_Handler' defined in 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c'?

A645: It returns 'void'.

Q646: How many parameters does 'SysTick\_Handler' accept?

A646: It takes no parameters.

Q647: List the parameters for 'SysTick\_Handler'.

A647: None; the parameter list is empty.

Q648: Where in the project is 'SysTick\_Handler' implemented?

A648: In 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c' near line 183.

Q649: Is 'SysTick\_Handler' declared 'static'?

A649: No, it is globally visible.

Q650: What is the return type of '\_open' defined in 'Assignment2-AY2526S1/Core/Src/syscalls.c'?

A650: It returns 'int'.

Q651: How many parameters does '\_open' accept?

A651: It takes 3 parameters.

Q652: List the parameters for '\_open'.

A652: char \*path, int flags, ...

Q653: Where in the project is '\_open' implemented?

A653: In 'Assignment2-AY2526S1/Core/Src/syscalls.c' near line 110.

Q654: Is '\_open' declared 'static'?

A654: No, it is globally visible.

Q655: What is the return type of 'BSP\_PB\_GetState' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c'?

A655: It returns 'uint32\_t'.

Q656: How many parameters does 'BSP\_PB\_GetState' accept?

A656: It takes 1 parameter.

Q657: List the parameters for 'BSP\_PB\_GetState'.

A657: Button\_TypeDef Button

Q658: Where in the project is 'BSP\_PB\_GetState' implemented?

A658: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c' near line 274.

Q659: Is 'BSP\_PB\_GetState' declared 'static'?

A659: No, it is globally visible.

Q660: What is the return type of 'BSP\_NFCTAG\_WriteData' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c'?

A660: It returns 'int32\_t'.

Q661: How many parameters does 'BSP\_NFCTAG\_WriteData' accept?

A661: It takes 4 parameters.

Q662: List the parameters for 'BSP\_NFCTAG\_WriteData'.

A662: uint32\_t Instance, const uint8\_t \* const pData, const uint16\_t TarAddr, const uint16\_t Size

Q663: Where in the project is 'BSP\_NFCTAG\_WriteData' implemented?

A663: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c' near line 219.

Q664: Is 'BSP\_NFCTAG\_WriteData' declared 'static'?

A664: No, it is globally visible.

Q665: What is the return type of 'Buzzer\_Stop' defined in 'Assignment2-AY2526S1/Core/Src/buzzer.c'?

A665: It returns 'void'.

Q666: How many parameters does 'Buzzer\_Stop' accept?

A666: It takes no parameters.

Q667: List the parameters for 'Buzzer\_Stop'.

A667: None; the parameter list is empty.

Q668: Where in the project is 'Buzzer\_Stop' implemented?

A668: In 'Assignment2-AY2526S1/Core/Src/buzzer.c' near line 184.

Q669: Is 'Buzzer\_Stop' declared 'static'?

A669: Yes, it is declared 'static'.

Q670: What is the return type of 'HT16K33\_DisplayBitmap64' defined in 'Assignment2-AY2526S1/Core/Src/ht16k33.c'?

A670: It returns 'HAL\_StatusTypeDef'.

Q671: How many parameters does 'HT16K33\_DisplayBitmap64' accept?

A671: It takes 2 parameters.

Q672: List the parameters for 'HT16K33\_DisplayBitmap64'.

A672: HT16K33\_HandleTypeDef \*h, uint64\_t bitmap

Q673: Where in the project is 'HT16K33\_DisplayBitmap64' implemented?

A673: In 'Assignment2-AY2526S1/Core/Src/ht16k33.c' near line 92.

Q674: Is 'HT16K33\_DisplayBitmap64' declared 'static'?

A674: No, it is globally visible.

Q675: What is the return type of 'I2C\_Scan' defined in 'Assignment2-AY2526S1/Core/Src/main.c'?

A675: It returns 'void'.

Q676: How many parameters does 'I2C\_Scan' accept?

A676: It takes 1 parameter.

Q677: List the parameters for 'I2C\_Scan'.

A677: I2C\_HandleTypeDef \*hi2c

Q678: Where in the project is 'I2C\_Scan' implemented?

A678: In 'Assignment2-AY2526S1/Core/Src/main.c' near line 452.

Q679: Is 'I2C\_Scan' declared 'static'?

A679: Yes, it is declared 'static'.

Q680: What is the return type of 'set\_param\_value' defined in

'Assignment2-AY2526S1/Core/Src/menu\_system.c'?

A680: It returns 'void'.

Q681: How many parameters does 'set\_param\_value' accept?

A681: It takes 2 parameters.

Q682: List the parameters for 'set\_param\_value'.

A682: param\_id\_t param\_id, float value

Q683: Where in the project is 'set\_param\_value' implemented?

A683: In 'Assignment2-AY2526S1/Core/Src/menu\_system.c' near line 134.

Q684: Is 'set\_param\_value' declared 'static'?

A684: Yes, it is declared 'static'.

Q685: What is the return type of 'GroveMultiSwitch\_GetEvent' defined in

'Assignment2-AY2526S1/Core/Src/multi\_switch.c'?

A685: It returns 'ButtonEvent\_t\*'.

Q686: How many parameters does 'GroveMultiSwitch\_GetEvent' accept?

A686: It takes 1 parameter.

Q687: List the parameters for 'GroveMultiSwitch\_GetEvent'.

A687: GroveMultiSwitch\_t \*handle

Q688: Where in the project is 'GroveMultiSwitch\_GetEvent' implemented?

A688: In 'Assignment2-AY2526S1/Core/Src/multi\_switch.c' near line 225.

Q689: Is 'GroveMultiSwitch\_GetEvent' declared 'static'?

A689: No, it is globally visible.

Q690: What is the return type of 'SSD1306\_DrawRectangle' defined in

'Assignment2-AY2526S1/Core/Src/ssd1306.c'?

A690: It returns 'void'.

Q691: How many parameters does 'SSD1306\_DrawRectangle' accept?

A691: It takes 5 parameters.

Q692: List the parameters for 'SSD1306\_DrawRectangle'.

A692: uint16\_t x, uint16\_t y, uint16\_t w, uint16\_t h, SSD1306\_COLOR\_t c

Q693: Where in the project is 'SSD1306\_DrawRectangle' implemented?

A693: In 'Assignment2-AY2526S1/Core/Src/ssd1306.c' near line 177.

Q694: Is 'SSD1306\_DrawRectangle' declared 'static'?

A694: No, it is globally visible.

Q695: What is the return type of 'EXTI9\_5\_IRQHandler' defined in

'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c'?

A695: It returns 'void'.

Q696: How many parameters does 'EXTI9\_5\_IRQHandler' accept?

A696: It takes no parameters.

Q697: List the parameters for 'EXTI9\_5\_IRQHandler'.

A697: None; the parameter list is empty.

Q698: Where in the project is 'EXTI9\_5\_IRQHandler' implemented?

A698: In 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c' near line 204.

Q699: Is 'EXTI9\_5\_IRQHandler' declared 'static'?

A699: No, it is globally visible.

Q700: What is the return type of '\_wait' defined in 'Assignment2-AY2526S1/Core/Src/syscalls.c'?

A700: It returns 'int'.

Q701: How many parameters does '\_wait' accept?

A701: It takes 1 parameter.

Q702: List the parameters for '\_wait'.

A702: int \*status

Q703: Where in the project is '\_wait' implemented?

A703: In 'Assignment2-AY2526S1/Core/Src/syscalls.c' near line 116.

Q704: Is '\_wait' declared 'static'?

A704: No, it is globally visible.

Q705: What is the return type of 'BSP\_COM\_Init' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c'?

A705: It returns 'void'.

Q706: How many parameters does 'BSP\_COM\_Init' accept?

A706: It takes 2 parameters.

Q707: List the parameters for 'BSP\_COM\_Init'.

A707: COM\_TypeDef COM, UART\_HandleTypeDef \*huart

Q708: Where in the project is 'BSP\_COM\_Init' implemented?

A708: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c' near line 287.

Q709: Is 'BSP\_COM\_Init' declared 'static'?

A709: No, it is globally visible.

Q710: What is the return type of 'BSP\_NFCTAG\_ReadRegister' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c'?

A710: It returns 'int32\_t'.

Q711: How many parameters does 'BSP\_NFCTAG\_ReadRegister' accept?

A711: It takes 4 parameters.

Q712: List the parameters for 'BSP\_NFCTAG\_ReadRegister'.

A712: uint32\_t Instance, uint8\_t \* const pData, const uint16\_t TarAddr, const uint16\_t Size

Q713: Where in the project is 'BSP\_NFCTAG\_ReadRegister' implemented?

A713: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c' near line 237.

Q714: Is 'BSP\_NFCTAG\_ReadRegister' declared 'static'?

A714: No, it is globally visible.

Q715: What is the return type of 'Buzzer\_PlayToneInternal' defined in 'Assignment2-AY2526S1/Core/Src/buzzer.c'?

A715: It returns 'void'.

Q716: How many parameters does 'Buzzer\_PlayToneInternal' accept?

A716: It takes 3 parameters.

Q717: List the parameters for 'Buzzer\_PlayToneInternal'.

A717: float frequency\_hz, uint32\_t duration\_ms, uint32\_t gap\_ms\_after

Q718: Where in the project is 'Buzzer\_PlayToneInternal' implemented?

A718: In 'Assignment2-AY2526S1/Core/Src/buzzer.c' near line 194.

Q719: Is 'Buzzer\_PlayToneInternal' declared 'static'?

A719: Yes, it is declared 'static'.

Q720: What is the return type of 'HT16K33\_PlayFrames' defined in 'Assignment2-AY2526S1/Core/Src/ht16k33.c'?

A720: It returns 'HAL\_StatusTypeDef'.

Q721: How many parameters does 'HT16K33\_PlayFrames' accept?

A721: It takes 5 parameters.

Q722: List the parameters for 'HT16K33\_PlayFrames'.

A722: HT16K33\_HandleTypeDef \*h, const uint64\_t \*frames, size\_t frame\_count, uint32\_t frame\_duration\_ms, uint32\_t repeat

Q723: Where in the project is 'HT16K33\_PlayFrames' implemented?

A723: In 'Assignment2-AY2526S1/Core/Src/ht16k33.c' near line 99.

Q724: Is 'HT16K33\_PlayFrames' declared 'static'?

A724: No, it is globally visible.

Q725: What is the return type of 'MX\_GPIO\_Init' defined in 'Assignment2-AY2526S1/Core/Src/main.c'?

A725: It returns 'void'.

Q726: How many parameters does 'MX\_GPIO\_Init' accept?

A726: It takes no parameters.

Q727: List the parameters for 'MX\_GPIO\_Init'.

A727: None; the parameter list is empty.

Q728: Where in the project is 'MX\_GPIO\_Init' implemented?

A728: In 'Assignment2-AY2526S1/Core/Src/main.c' near line 464.

Q729: Is 'MX\_GPIO\_Init' declared 'static'?

A729: Yes, it is declared 'static'.

Q730: What is the return type of 'get\_next\_param' defined in 'Assignment2-AY2526S1/Core/Src/menu\_system.c'?

A730: It returns 'param\_id\_t'.

Q731: How many parameters does 'get\_next\_param' accept?

A731: It takes 2 parameters.

Q732: List the parameters for 'get\_next\_param'.

A732: menu\_handle\_t \*menu, int8\_t direction

Q733: Where in the project is 'get\_next\_param' implemented?

A733: In 'Assignment2-AY2526S1/Core/Src/menu\_system.c' near line 172.

Q734: Is 'get\_next\_param' declared 'static'?

A734: Yes, it is declared 'static'.

Q735: What is the return type of 'GroveMultiSwitch\_SetEventMode' defined in 'Assignment2-AY2526S1/Core/Src/multi\_switch.c'?

A735: It returns 'bool'.

Q736: How many parameters does 'GroveMultiSwitch\_SetEventMode' accept?

A736: It takes 2 parameters.

Q737: List the parameters for 'GroveMultiSwitch\_SetEventMode'.

A737: GroveMultiSwitch\_t \*handle, bool enable

Q738: Where in the project is 'GroveMultiSwitch\_SetEventMode' implemented?

A738: In 'Assignment2-AY2526S1/Core/Src/multi\_switch.c' near line 267.

Q739: Is 'GroveMultiSwitch\_SetEventMode' declared 'static'?

A739: No, it is globally visible.

Q740: What is the return type of 'SSD1306\_DrawFilledRectangle' defined in 'Assignment2-AY2526S1/Core/Src/ssd1306.c'?

A740: It returns 'void'.

Q741: How many parameters does 'SSD1306\_DrawFilledRectangle' accept?

A741: It takes 5 parameters.

Q742: List the parameters for 'SSD1306\_DrawFilledRectangle'.

A742: uint16\_t x, uint16\_t y, uint16\_t w, uint16\_t h, SSD1306\_COLOR\_t c

Q743: Where in the project is 'SSD1306\_DrawFilledRectangle' implemented?

A743: In 'Assignment2-AY2526S1/Core/Src/ssd1306.c' near line 184.

Q744: Is 'SSD1306\_DrawFilledRectangle' declared 'static'?

A744: No, it is globally visible.

Q745: What is the return type of 'EXTI15\_10\_IRQHandler' defined in 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c'?

A745: It returns 'void'.



Q746: How many parameters does 'EXTI15\_10\_IRQHandler' accept?

A746: It takes no parameters.

Q747: List the parameters for 'EXTI15\_10\_IRQHandler'.

A747: None; the parameter list is empty.

Q748: Where in the project is 'EXTI15\_10\_IRQHandler' implemented?

A748: In 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c' near line 221.

Q749: Is 'EXTI15\_10\_IRQHandler' declared 'static'?

A749: No, it is globally visible.

Q750: What is the return type of '\_unlink' defined in 'Assignment2-AY2526S1/Core/Src/syscalls.c'?

A750: It returns 'int'.

Q751: How many parameters does '\_unlink' accept?

A751: It takes 1 parameter.

Q752: List the parameters for '\_unlink'.

A752: char \*name

Q753: Where in the project is '\_unlink' implemented?

A753: In 'Assignment2-AY2526S1/Core/Src/syscalls.c' near line 122.

Q754: Is '\_unlink' declared 'static'?

A754: No, it is globally visible.

Q755: What is the return type of 'BSP\_COM\_DeInit' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c'?

A755: It returns 'void'.

Q756: How many parameters does 'BSP\_COM\_DeInit' accept?

A756: It takes 2 parameters.

Q757: List the parameters for 'BSP\_COM\_DeInit'.

A757: COM\_TypeDef COM, UART\_HandleTypeDef \*huart

Q758: Where in the project is 'BSP\_COM\_DeInit' implemented?

A758: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c' near line 325.

Q759: Is 'BSP\_COM\_DeInit' declared 'static'?

A759: No, it is globally visible.

Q760: What is the return type of 'BSP\_NFCTAG\_WriteRegister' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c'?

A760: It returns 'int32\_t'.

Q761: How many parameters does 'BSP\_NFCTAG\_WriteRegister' accept?

A761: It takes 4 parameters.

Q762: List the parameters for 'BSP\_NFCTAG\_WriteRegister'.

A762: uint32\_t Instance, const uint8\_t \* const pData, const uint16\_t TarAddr, const uint16\_t Size

Q763: Where in the project is 'BSP\_NFCTAG\_WriteRegister' implemented?

A763: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c' near line 251.

Q764: Is 'BSP\_NFCTAG\_WriteRegister' declared 'static'?

A764: No, it is globally visible.

Q765: What is the return type of 'Buzzer\_SequenceAdvance' defined in 'Assignment2-AY2526S1/Core/Src/buzzer.c'?

A765: It returns 'void'.

Q766: How many parameters does 'Buzzer\_SequenceAdvance' accept?

A766: It takes 1 parameter.

Q767: List the parameters for 'Buzzer\_SequenceAdvance'.

A767: uint32\_t now\_ms

Q768: Where in the project is 'Buzzer\_SequenceAdvance' implemented?

A768: In 'Assignment2-AY2526S1/Core/Src/buzzer.c' near line 227.

Q769: Is 'Buzzer\_SequenceAdvance' declared 'static'?

A769: Yes, it is declared 'static'.

Q770: What is the return type of 'UART1\_Init' defined in 'Assignment2-AY2526S1/Core/Src/main.c'?

A770: It returns 'void'.

Q771: How many parameters does 'UART1\_Init' accept?

A771: It takes no parameters.

Q772: List the parameters for 'UART1\_Init'.

A772: None; the parameter list is empty.

Q773: Where in the project is 'UART1\_Init' implemented?

A773: In 'Assignment2-AY2526S1/Core/Src/main.c' near line 478.

Q774: Is 'UART1\_Init' declared 'static'?

A774: Yes, it is declared 'static'.

Q775: What is the return type of 'menu\_render\_selected' defined in 'Assignment2-AY2526S1/Core/Src/menu\_system.c'?

A775: It returns 'void'.

Q776: How many parameters does 'menu\_render\_selected' accept?

A776: It takes 1 parameter.

Q777: List the parameters for 'menu\_render\_selected'.

A777: menu\_handle\_t \*menu

Q778: Where in the project is 'menu\_render\_selected' implemented?

A778: In 'Assignment2-AY2526S1/Core/Src/menu\_system.c' near line 188.

Q779: Is 'menu\_render\_selected' declared 'static'?

A779: Yes, it is declared 'static'.

Q780: What is the return type of 'GroveMultiSwitch\_SetAutoSleep' defined in 'Assignment2-AY2526S1/Core/Src/multi\_switch.c'?

A780: It returns 'bool'.

Q781: How many parameters does 'GroveMultiSwitch\_SetAutoSleep' accept?

A781: It takes 2 parameters.

Q782: List the parameters for 'GroveMultiSwitch\_SetAutoSleep'.

A782: GroveMultiSwitch\_t \*handle, bool enable

Q783: Where in the project is 'GroveMultiSwitch\_SetAutoSleep' implemented?

A783: In 'Assignment2-AY2526S1/Core/Src/multi\_switch.c' near line 285.

Q784: Is 'GroveMultiSwitch\_SetAutoSleep' declared 'static'?

A784: No, it is globally visible.

Q785: What is the return type of 'SSD1306\_DrawTriangle' defined in 'Assignment2-AY2526S1/Core/Src/ssd1306.c'?

A785: It returns 'void'.

Q786: How many parameters does 'SSD1306\_DrawTriangle' accept?

A786: It takes 7 parameters.

Q787: List the parameters for 'SSD1306\_DrawTriangle'.

A787: uint16\_t x1, uint16\_t y1, uint16\_t x2, uint16\_t y2, uint16\_t x3, uint16\_t y3, SSD1306\_COLOR\_t color

Q788: Where in the project is 'SSD1306\_DrawTriangle' implemented?

A788: In 'Assignment2-AY2526S1/Core/Src/ssd1306.c' near line 190.

Q789: Is 'SSD1306\_DrawTriangle' declared 'static'?

A789: No, it is globally visible.

Q790: What is the return type of 'TIM2\_IRQHandler' defined in 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c'?

A790: It returns 'void'.

Q791: How many parameters does 'TIM2\_IRQHandler' accept?

A791: It takes no parameters.

Q792: List the parameters for 'TIM2\_IRQHandler'.

A792: None; the parameter list is empty.

Q793: Where in the project is 'TIM2\_IRQHandler' implemented?

A793: In 'Assignment2-AY2526S1/Core/Src/stm32l4xx\_it.c' near line 240.

Q794: Is 'TIM2\_IRQHandler' declared 'static'?

A794: No, it is globally visible.

Q795: What is the return type of '\_times' defined in 'Assignment2-AY2526S1/Core/Src/syscalls.c'?

A795: It returns 'int'.

Q796: How many parameters does '\_times' accept?

A796: It takes 1 parameter.

Q797: List the parameters for '\_times'.

A797: struct tms \*buf

Q798: Where in the project is '\_times' implemented?

A798: In 'Assignment2-AY2526S1/Core/Src/syscalls.c' near line 128.

Q799: Is '\_times' declared 'static'?

A799: No, it is globally visible.

Q800: What is the return type of 'I2Cx\_Msplnit' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c'?

A800: It returns 'void'.

Q801: How many parameters does 'I2Cx\_Msplnit' accept?

A801: It takes 1 parameter.

Q802: List the parameters for 'I2Cx\_MspInit'.

A802: I2C\_HandleTypeDef \*i2c\_handler

Q803: Where in the project is 'I2Cx\_MspInit' implemented?

A803: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c' near line 352.

Q804: Is 'I2Cx\_MspInit' declared 'static'?

A804: Yes, it is declared 'static'.

Q805: What is the return type of 'BSP\_NFCTAG\_GetByteSize' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c'?

A805: It returns 'uint32\_t'.

Q806: How many parameters does 'BSP\_NFCTAG\_GetByteSize' accept?

A806: It takes 1 parameter.

Q807: List the parameters for 'BSP\_NFCTAG\_GetByteSize'.

A807: uint32\_t Instance

Q808: Where in the project is 'BSP\_NFCTAG\_GetByteSize' implemented?

A808: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c' near line 270.

Q809: Is 'BSP\_NFCTAG\_GetByteSize' declared 'static'?

A809: No, it is globally visible.

Q810: What is the return type of 'Buzzer\_SequenceStart' defined in

'Assignment2-AY2526S1/Core/Src/buzzer.c'?

A810: It returns 'void'.

Q811: How many parameters does 'Buzzer\_SequenceStart' accept?

A811: It takes 2 parameters.

Q812: List the parameters for 'Buzzer\_SequenceStart'.

A812: const buzzer\_step\_t \*steps, uint8\_t count

Q813: Where in the project is 'Buzzer\_SequenceStart' implemented?

A813: In 'Assignment2-AY2526S1/Core/Src/buzzer.c' near line 245.

Q814: Is 'Buzzer\_SequenceStart' declared 'static'?

A814: Yes, it is declared 'static'.

Q815: What is the return type of 'NFC\_Init' defined in 'Assignment2-AY2526S1/Core/Src/main.c'?

A815: It returns 'void'.

Q816: How many parameters does 'NFC\_Init' accept?

A816: It takes no parameters.

Q817: List the parameters for 'NFC\_Init'.

A817: None; the parameter list is empty.

Q818: Where in the project is 'NFC\_Init' implemented?

A818: In 'Assignment2-AY2526S1/Core/Src/main.c' near line 503.

Q819: Is 'NFC\_Init' declared 'static'?

A819: No, it is globally visible.

Q820: What is the return type of 'menu\_render\_adjust' defined in

'Assignment2-AY2526S1/Core/Src/menu\_system.c'?

A820: It returns 'void'.

Q821: How many parameters does 'menu\_render\_adjust' accept?

A821: It takes 2 parameters.

Q822: List the parameters for 'menu\_render\_adjust'.

A822: menu\_handle\_t \*menu, const char \*header

Q823: Where in the project is 'menu\_render\_adjust' implemented?

A823: In 'Assignment2-AY2526S1/Core/Src/menu\_system.c' near line 212.

Q824: Is 'menu\_render\_adjust' declared 'static'?

A824: Yes, it is declared 'static'.

Q825: What is the return type of 'SSD1306\_DrawCircle' defined in

'Assignment2-AY2526S1/Core/Src/ssd1306.c'?

A825: It returns 'void'.

Q826: How many parameters does 'SSD1306\_DrawCircle' accept?

A826: It takes 4 parameters.

Q827: List the parameters for 'SSD1306\_DrawCircle'.

A827: int16\_t x0, int16\_t y0, int16\_t r, SSD1306\_COLOR\_t c

Q828: Where in the project is 'SSD1306\_DrawCircle' implemented?

A828: In 'Assignment2-AY2526S1/Core/Src/ssd1306.c' near line 197.

Q829: Is 'SSD1306\_DrawCircle' declared 'static'?

A829: No, it is globally visible.

Q830: What is the return type of '\_stat' defined in 'Assignment2-AY2526S1/Core/Src/syscalls.c'?

A830: It returns 'int'.

Q831: How many parameters does '\_stat' accept?

A831: It takes 2 parameters.

Q832: List the parameters for '\_stat'.

A832: char \*file, struct stat \*st

Q833: Where in the project is '\_stat' implemented?

A833: In 'Assignment2-AY2526S1/Core/Src/syscalls.c' near line 133.

Q834: Is '\_stat' declared 'static'?

A834: No, it is globally visible.

Q835: What is the return type of 'I2Cx\_MspDeInit' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c'?

A835: It returns 'void'.

Q836: How many parameters does 'I2Cx\_MspDeInit' accept?

A836: It takes 1 parameter.

Q837: List the parameters for 'I2Cx\_MspDeInit'.

A837: I2C\_HandleTypeDef \*i2c\_handler

Q838: Where in the project is 'I2Cx\_MspDeInit' implemented?

A838: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c' near line 394.

Q839: Is 'I2Cx\_MspDeInit' declared 'static'?

A839: Yes, it is declared 'static'.

Q840: What is the return type of 'BSP\_NFCTAG\_ReadICRev' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c'?

A840: It returns 'int32\_t'.

Q841: How many parameters does 'BSP\_NFCTAG\_ReadICRev' accept?

A841: It takes 2 parameters.

Q842: List the parameters for 'BSP\_NFCTAG\_ReadICRev'.

A842: uint32\_t Instance, uint8\_t \* const piCRev

Q843: Where in the project is 'BSP\_NFCTAG\_ReadICRev' implemented?

A843: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c' near line 284.

Q844: Is 'BSP\_NFCTAG\_ReadICRev' declared 'static'?

A844: No, it is globally visible.

Q845: What is the return type of 'Buzzer\_PlayFailureTune' defined in 'Assignment2-AY2526S1/Core/Src/buzzer.c'?

A845: It returns 'void'.

Q846: How many parameters does 'Buzzer\_PlayFailureTune' accept?

A846: It takes no parameters.

Q847: List the parameters for 'Buzzer\_PlayFailureTune'.

A847: None; the parameter list is empty.

Q848: Where in the project is 'Buzzer\_PlayFailureTune' implemented?

A848: In 'Assignment2-AY2526S1/Core/Src/buzzer.c' near line 264.

Q849: Is 'Buzzer\_PlayFailureTune' declared 'static'?

A849: No, it is globally visible.

Q850: What is the return type of 'NFC\_BlinkIfCard' defined in 'Assignment2-AY2526S1/Core/Src/main.c'?

A850: It returns 'void'.

Q851: How many parameters does 'NFC\_BlinkIfCard' accept?

A851: It takes no parameters.

Q852: List the parameters for 'NFC\_BlinkIfCard'.

A852: None; the parameter list is empty.

Q853: Where in the project is 'NFC\_BlinkIfCard' implemented?

A853: In 'Assignment2-AY2526S1/Core/Src/main.c' near line 510.

Q854: Is 'NFC\_BlinkIfCard' declared 'static'?

A854: No, it is globally visible.

Q855: What is the return type of 'Menu\_Process' defined in 'Assignment2-AY2526S1/Core/Src/menu\_system.c'?

A855: It returns 'bool'.

Q856: How many parameters does 'Menu\_Process' accept?

A856: It takes 1 parameter.

Q857: List the parameters for 'Menu\_Process'.

A857: menu\_handle\_t \*menu

Q858: Where in the project is 'Menu\_Process' implemented?

A858: In 'Assignment2-AY2526S1/Core/Src/menu\_system.c' near line 243.

Q859: Is 'Menu\_Process' declared 'static'?

A859: No, it is globally visible.

Q860: What is the return type of 'SSD1306\_DrawFilledCircle' defined in 'Assignment2-AY2526S1/Core/Src/ssd1306.c'?

A860: It returns 'void'.

Q861: How many parameters does 'SSD1306\_DrawFilledCircle' accept?

A861: It takes 4 parameters.

Q862: List the parameters for 'SSD1306\_DrawFilledCircle'.

A862: int16\_t x0, int16\_t y0, int16\_t r, SSD1306\_COLOR\_t c

Q863: Where in the project is 'SSD1306\_DrawFilledCircle' implemented?

A863: In 'Assignment2-AY2526S1/Core/Src/ssd1306.c' near line 230.

Q864: Is 'SSD1306\_DrawFilledCircle' declared 'static'?

A864: No, it is globally visible.

Q865: What is the return type of '\_link' defined in 'Assignment2-AY2526S1/Core/Src/syscalls.c'?

A865: It returns 'int'.

Q866: How many parameters does '\_link' accept?

A866: It takes 2 parameters.

Q867: List the parameters for '\_link'.

A867: char \*old, char \*new

Q868: Where in the project is '\_link' implemented?

A868: In 'Assignment2-AY2526S1/Core/Src/syscalls.c' near line 139.

Q869: Is '\_link' declared 'static'?

A869: No, it is globally visible.

Q870: What is the return type of 'I2Cx\_Init' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c'?

A870: It returns 'void'.

Q871: How many parameters does 'I2Cx\_Init' accept?

A871: It takes 1 parameter.

Q872: List the parameters for 'I2Cx\_Init'.

A872: I2C\_HandleTypeDef \*i2c\_handler

Q873: Where in the project is 'I2Cx\_Init' implemented?

A873: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c' near line 413.

Q874: Is 'I2Cx\_Init' declared 'static'?

A874: Yes, it is declared 'static'.

Q875: What is the return type of 'BSP\_NFCTAG\_ReadITPulse' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c'?

A875: It returns 'int32\_t'.

Q876: How many parameters does 'BSP\_NFCTAG\_ReadITPulse' accept?

A876: It takes 2 parameters.

Q877: List the parameters for 'BSP\_NFCTAG\_ReadITPulse'.

A877: uint32\_t Instance, ST25DV\_PULSE\_DURATION \* const pITime

Q878: Where in the project is 'BSP\_NFCTAG\_ReadITPulse' implemented?

A878: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c' near line 296.

Q879: Is 'BSP\_NFCTAG\_ReadITPulse' declared 'static'?

A879: No, it is globally visible.

Q880: What is the return type of 'Buzzer\_PlaySuccessTune' defined in 'Assignment2-AY2526S1/Core/Src/buzzer.c'?

A880: It returns 'void'.

Q881: How many parameters does 'Buzzer\_PlaySuccessTune' accept?

A881: It takes no parameters.

Q882: List the parameters for 'Buzzer\_PlaySuccessTune'.

A882: None; the parameter list is empty.

Q883: Where in the project is 'Buzzer\_PlaySuccessTune' implemented?

A883: In 'Assignment2-AY2526S1/Core/Src/buzzer.c' near line 283.

Q884: Is 'Buzzer\_PlaySuccessTune' declared 'static'?

A884: No, it is globally visible.

Q885: What is the return type of 'main' defined in 'Assignment2-AY2526S1/Core/Src/main.c'?

A885: It returns 'int'.

Q886: How many parameters does 'main' accept?

A886: It takes no parameters.

Q887: List the parameters for 'main'.

A887: None; the parameter list is empty.

Q888: Where in the project is 'main' implemented?

A888: In 'Assignment2-AY2526S1/Core/Src/main.c' near line 526.

Q889: Is 'main' declared 'static'?

A889: No, it is globally visible.

Q890: What is the return type of 'Menu\_GetState' defined in 'Assignment2-AY2526S1/Core/Src/menu\_system.c'?

A890: It returns 'menu\_state\_t'.

Q891: How many parameters does 'Menu\_GetState' accept?

A891: It takes 1 parameter.

Q892: List the parameters for 'Menu\_GetState'.

A892: menu\_handle\_t \*menu

Q893: Where in the project is 'Menu\_GetState' implemented?

A893: In 'Assignment2-AY2526S1/Core/Src/menu\_system.c' near line 362.

Q894: Is 'Menu\_GetState' declared 'static'?

A894: No, it is globally visible.

Q895: What is the return type of 'ssd1306\_I2C\_Init' defined in 'Assignment2-AY2526S1/Core/Src/ssd1306.c'?



A895: It returns 'void'.

Q896: How many parameters does 'ssd1306\_I2C\_Init' accept?

A896: It takes no parameters.

Q897: List the parameters for 'ssd1306\_I2C\_Init'.

A897: None; the parameter list is empty.

Q898: Where in the project is 'ssd1306\_I2C\_Init' implemented?

A898: In 'Assignment2-AY2526S1/Core/Src/ssd1306.c' near line 260.

Q899: Is 'ssd1306\_I2C\_Init' declared 'static'?

A899: No, it is globally visible.

Q900: What is the return type of '\_fork' defined in 'Assignment2-AY2526S1/Core/Src/syscalls.c'?

A900: It returns 'int'.

Q901: How many parameters does '\_fork' accept?

A901: It takes no parameters.

Q902: List the parameters for '\_fork'.

A902: None; the parameter list is empty.

Q903: Where in the project is '\_fork' implemented?

A903: In 'Assignment2-AY2526S1/Core/Src/syscalls.c' near line 145.

Q904: Is '\_fork' declared 'static'?

A904: No, it is globally visible.

Q905: What is the return type of 'I2Cx\_DeInit' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c'?

A905: It returns 'void'.

Q906: How many parameters does 'I2Cx\_DeInit' accept?

A906: It takes 1 parameter.

Q907: List the parameters for 'I2Cx\_DeInit'.

A907: I2C\_HandleTypeDef \*i2c\_handler

Q908: Where in the project is 'I2Cx\_DeInit' implemented?

A908: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c' near line 438.

Q909: Is 'I2Cx\_DeInit' declared 'static'?

A909: Yes, it is declared 'static'.

Q910: What is the return type of 'BSP\_NFCTAG\_WriteITPulse' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c'?

A910: It returns 'int32\_t'.

Q911: How many parameters does 'BSP\_NFCTAG\_WriteITPulse' accept?

A911: It takes 2 parameters.

Q912: List the parameters for 'BSP\_NFCTAG\_WriteITPulse'.

A912: uint32\_t Instance, const ST25DV\_PULSE\_DURATION ITtime

Q913: Where in the project is 'BSP\_NFCTAG\_WriteITPulse' implemented?

A913: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c' near line 308.

Q914: Is 'BSP\_NFCTAG\_WriteITPulse' declared 'static'?

A914: No, it is globally visible.

Q915: What is the return type of 'Arrow\_InitDigits' defined in 'Assignment2-AY2526S1/Core/Src/main.c'?

A915: It returns 'void'.

Q916: How many parameters does 'Arrow\_InitDigits' accept?

A916: It takes no parameters.

Q917: List the parameters for 'Arrow\_InitDigits'.

A917: None; the parameter list is empty.

Q918: Where in the project is 'Arrow\_InitDigits' implemented?

A918: In 'Assignment2-AY2526S1/Core/Src/main.c' near line 856.

Q919: Is 'Arrow\_InitDigits' declared 'static'?

A919: Yes, it is declared 'static'.

Q920: What is the return type of 'Menu\_Open' defined in 'Assignment2-AY2526S1/Core/Src/menu\_system.c'?

A920: It returns 'void'.

Q921: How many parameters does 'Menu\_Open' accept?

A921: It takes 1 parameter.

Q922: List the parameters for 'Menu\_Open'.

A922: menu\_handle\_t \*menu

Q923: Where in the project is 'Menu\_Open' implemented?

A923: In 'Assignment2-AY2526S1/Core/Src/menu\_system.c' near line 367.

Q924: Is 'Menu\_Open' declared 'static'?

A924: No, it is globally visible.

Q925: What is the return type of 'ssd1306\_I2C\_Write' defined in 'Assignment2-AY2526S1/Core/Src/ssd1306.c'?

A925: It returns 'void'.

Q926: How many parameters does 'ssd1306\_I2C\_Write' accept?

A926: It takes 3 parameters.

Q927: List the parameters for 'ssd1306\_I2C\_Write'.

A927: uint8\_t address, uint8\_t reg, uint8\_t data

Q928: Where in the project is 'ssd1306\_I2C\_Write' implemented?

A928: In 'Assignment2-AY2526S1/Core/Src/ssd1306.c' near line 264.

Q929: Is 'ssd1306\_I2C\_Write' declared 'static'?

A929: No, it is globally visible.

Q930: What is the return type of '\_execve' defined in 'Assignment2-AY2526S1/Core/Src/syscalls.c'?

A930: It returns 'int'.

Q931: How many parameters does '\_execve' accept?

A931: It takes 3 parameters.

Q932: List the parameters for '\_execve'.

A932: char \*name, char \*\*argv, char \*\*env

Q933: Where in the project is '\_execve' implemented?

A933: In 'Assignment2-AY2526S1/Core/Src/syscalls.c' near line 151.

Q934: Is '\_execve' declared 'static'?

A934: No, it is globally visible.

Q935: What is the return type of 'I2Cx\_ReadMultiple' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c'?

A935: It returns 'HAL\_StatusTypeDef'.

Q936: How many parameters does 'I2Cx\_ReadMultiple' accept?

A936: It takes 6 parameters.

Q937: List the parameters for 'I2Cx\_ReadMultiple'.

A937: I2C\_HandleTypeDef \*i2c\_handler, uint8\_t Addr, uint16\_t Reg, uint16\_t MemAddress, uint8\_t \*Buffer, uint16\_t Length

Q938: Where in the project is 'I2Cx\_ReadMultiple' implemented?

A938: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c' near line 454.

Q939: Is 'I2Cx\_ReadMultiple' declared 'static'?

A939: Yes, it is declared 'static'.

Q940: What is the return type of 'BSP\_NFCTAG\_ReadUID' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c'?

A940: It returns 'int32\_t'.

Q941: How many parameters does 'BSP\_NFCTAG\_ReadUID' accept?

A941: It takes 2 parameters.

Q942: List the parameters for 'BSP\_NFCTAG\_ReadUID'.

A942: uint32\_t Instance, ST25DV\_UID \* const pUid

Q943: Where in the project is 'BSP\_NFCTAG\_ReadUID' implemented?

A943: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c' near line 319.

Q944: Is 'BSP\_NFCTAG\_ReadUID' declared 'static'?

A944: No, it is globally visible.

Q945: What is the return type of 'Arrow\_ShowDigit' defined in

'Assignment2-AY2526S1/Core/Src/main.c'?

A945: It returns 'void'.

Q946: How many parameters does 'Arrow\_ShowDigit' accept?

A946: It takes 1 parameter.

Q947: List the parameters for 'Arrow\_ShowDigit'.

A947: uint8\_t digit

Q948: Where in the project is 'Arrow\_ShowDigit' implemented?

A948: In 'Assignment2-AY2526S1/Core/Src/main.c' near line 880.

Q949: Is 'Arrow\_ShowDigit' declared 'static'?

A949: Yes, it is declared 'static'.

Q950: What is the return type of 'Menu\_Close' defined in

'Assignment2-AY2526S1/Core/Src/menu\_system.c'?

A950: It returns 'void'.

Q951: How many parameters does 'Menu\_Close' accept?

A951: It takes 1 parameter.

Q952: List the parameters for 'Menu\_Close'.

A952: menu\_handle\_t \*menu

Q953: Where in the project is 'Menu\_Close' implemented?

A953: In 'Assignment2-AY2526S1/Core/Src/menu\_system.c' near line 383.

Q954: Is 'Menu\_Close' declared 'static'?

A954: No, it is globally visible.

Q955: What is the return type of 'ssd1306\_I2C\_WriteMulti' defined in 'Assignment2-AY2526S1/Core/Src/ssd1306.c'?

A955: It returns 'void'.

Q956: How many parameters does 'ssd1306\_I2C\_WriteMulti' accept?

A956: It takes 4 parameters.

Q957: List the parameters for 'ssd1306\_I2C\_WriteMulti'.

A957: uint8\_t address, uint8\_t reg, uint8\_t \*data, uint16\_t count

Q958: Where in the project is 'ssd1306\_I2C\_WriteMulti' implemented?

A958: In 'Assignment2-AY2526S1/Core/Src/ssd1306.c' near line 271.

Q959: Is 'ssd1306\_I2C\_WriteMulti' declared 'static'?

A959: No, it is globally visible.

Q960: What is the return type of 'I2Cx\_WriteMultiple' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c'?

A960: It returns 'HAL\_StatusTypeDef'.

Q961: How many parameters does 'I2Cx\_WriteMultiple' accept?

A961: It takes 6 parameters.

Q962: List the parameters for 'I2Cx\_WriteMultiple'.

A962: I2C\_HandleTypeDef \*i2c\_handler, uint8\_t Addr, uint16\_t Reg, uint16\_t MemAddress, uint8\_t \*Buffer, uint16\_t Length

Q963: Where in the project is 'I2Cx\_WriteMultiple' implemented?

A963: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c' near line 480.

Q964: Is 'I2Cx\_WriteMultiple' declared 'static'?

A964: Yes, it is declared 'static'.

Q965: What is the return type of 'BSP\_NFCTAG\_ReadDSFID' defined in

'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c'?

A965: It returns 'int32\_t'.

Q966: How many parameters does 'BSP\_NFCTAG\_ReadDSFID' accept?

A966: It takes 2 parameters.

Q967: List the parameters for 'BSP\_NFCTAG\_ReadDSFID'.

A967: uint32\_t Instance, uint8\_t \* const pDsfid

Q968: Where in the project is 'BSP\_NFCTAG\_ReadDSFID' implemented?

A968: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c' near line 330.

Q969: Is 'BSP\_NFCTAG\_ReadDSFID' declared 'static'?

A969: No, it is globally visible.

Q970: What is the return type of 'Arrow\_Stop' defined in 'Assignment2-AY2526S1/Core/Src/main.c'?

A970: It returns 'void'.

Q971: How many parameters does 'Arrow\_Stop' accept?

A971: It takes no parameters.

Q972: List the parameters for 'Arrow\_Stop'.

A972: None; the parameter list is empty.

Q973: Where in the project is 'Arrow\_Stop' implemented?

A973: In 'Assignment2-AY2526S1/Core/Src/main.c' near line 897.

Q974: Is 'Arrow\_Stop' declared 'static'?

A974: Yes, it is declared 'static'.

Q975: What is the return type of 'Menu\_GetDisplayString' defined in 'Assignment2-AY2526S1/Core/Src/menu\_system.c'?

A975: It returns 'void'.

Q976: How many parameters does 'Menu\_GetDisplayString' accept?

A976: It takes 3 parameters.

Q977: List the parameters for 'Menu\_GetDisplayString'.

A977: menu\_handle\_t \*menu, char \*buffer, size\_t buffer\_size

Q978: Where in the project is 'Menu\_GetDisplayString' implemented?

A978: In 'Assignment2-AY2526S1/Core/Src/menu\_system.c' near line 399.

Q979: Is 'Menu\_GetDisplayString' declared 'static'?

A979: No, it is globally visible.

Q980: What is the return type of 'SSD1306\_DrawBitmap' defined in 'Assignment2-AY2526S1/Core/Src/ssd1306.c'?

A980: It returns 'void'.

Q981: How many parameters does 'SSD1306\_DrawBitmap' accept?

A981: It takes 6 parameters.

Q982: List the parameters for 'SSD1306\_DrawBitmap'.

A982: int16\_t x, int16\_t y, const unsigned char\* bitmap, int16\_t w, int16\_t h, uint16\_t color

Q983: Where in the project is 'SSD1306\_DrawBitmap' implemented?

A983: In 'Assignment2-AY2526S1/Core/Src/ssd1306.c' near line 280.

Q984: Is 'SSD1306\_DrawBitmap' declared 'static'?

A984: No, it is globally visible.

Q985: What is the return type of 'I2Cx\_IsDeviceReady' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c'?

A985: It returns 'HAL\_StatusTypeDef'.

Q986: How many parameters does 'I2Cx\_IsDeviceReady' accept?

A986: It takes 3 parameters.

Q987: List the parameters for 'I2Cx\_IsDeviceReady'.

A987: I2C\_HandleTypeDef \*i2c\_handler, uint16\_t DevAddress, uint32\_t Trials

Q988: Where in the project is 'I2Cx\_IsDeviceReady' implemented?

A988: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01.c' near line 503.

Q989: Is 'I2Cx\_IsDeviceReady' declared 'static'?

A989: Yes, it is declared 'static'.

Q990: What is the return type of 'BSP\_NFCTAG\_ReadDsfidRFProtection' defined in 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c'?

A990: It returns 'int32\_t'.

Q991: How many parameters does 'BSP\_NFCTAG\_ReadDsfidRFProtection' accept?

A991: It takes 2 parameters.

Q992: List the parameters for 'BSP\_NFCTAG\_ReadDsfidRFProtection'.

A992: uint32\_t Instance, ST25DV\_LOCK\_STATUS \* const pLockDsfid

Q993: Where in the project is 'BSP\_NFCTAG\_ReadDsfidRFProtection' implemented?

A993: In 'Assignment2-AY2526S1/Drivers/BSP/B-L4S5I-IOT01/stm32l4s5i\_iot01\_nfctag.c' near line 341.

Q994: Is 'BSP\_NFCTAG\_ReadDsfidRFProtection' declared 'static'?

A994: No, it is globally visible.

Q995: What is the return type of 'Arrow\_RenderSequence' defined in 'Assignment2-AY2526S1/Core/Src/main.c'?

A995: It returns 'void'.

Q996: How many parameters does 'Arrow\_RenderSequence' accept?

A996: It takes no parameters.

Q997: List the parameters for 'Arrow\_RenderSequence'.

A997: None; the parameter list is empty.

Q998: Where in the project is 'Arrow\_RenderSequence' implemented?

A998: In 'Assignment2-AY2526S1/Core/Src/main.c' near line 911.

Q999: Is 'Arrow\_RenderSequence' declared 'static'?

A999: Yes, it is declared 'static'.

Q1000: What is the return type of 'SSD1306\_ScrollRight' defined in 'Assignment2-AY2526S1/Core/Src/ssd1306.c'?

A1000: It returns 'void'.