$R \cdot I \cdot T$	Title: Trion Phantom RIE		
Semiconductor & Microsystems			
Fabrication Laboratory	Revision: D	Rev Date: 02/03/2021	
Approved by:  / / Process Engineer	/ / Equipment Engineer		

#### 1 SCOPE

The purpose of this document is to detail the use of the TRION Phantom RIE. All users are expected to have read and understood this document. It is not a substitute for in-person training on the system and is not sufficient to qualify a user on the system. Failure to follow guidelines in this document may result in loss of privileges.

#### 2 REFERENCE DOCUMENTS

- Safety Data Sheets for process gasses
- Appropriate Tool Manuals

### 3 <u>DEFINITIONS</u>

n/a

### 4 <u>TOOLS AND MATERIALS</u>

#### 4.1 General Description

The TRION RIE is a single chamber reactive ion etcher for processing involving SF6, CF4, CHF3 and O2. The RIE will etch Nitride, Poly and several metals like moly with fluorine etching. The system has a Windows XP based operating system and the latest software available from Trion Technologies. It is not the same as the Trion Minilock and qualification on the Minilock does not qualify you on this tool.

### 5 <u>SAFETY PRECAUTIONS</u>

#### 5.1 Hazards to the Operator

5.1.1 This system uses hazardous gases and RF plasma to process wafers. If you have problems operating the system or suspect there is a problem with the machine, at any time contact a technician to correct the problem before continuing.

RIT SMFL Page 1 of 9

# **Semiconductor & Microsystems**

Fabrication Laboratory Revision: D Rev Date: 02/03/2021

5.1.2 Mechanical Hazards – There are pinch points on the tool. Lid opens and closes automatically.

#### 5.2 Hazards to the Tool

- 5.2.1 Wafer size This tool is only intended for 6" or 8" wafers and 6" or 8" carriers.
- 5.2.2 Recipes Do not edit any recipes that begin with the letters "FAC." These are reserved for the factory class.
- 5.2.3 Contamination Do not process wafers with gold or copper on them. This tool is not to be used for III-V substrates either.

#### **6** INSTRUCTIONS

#### 6.1 Initial State Check

6.1.1 In the service chase #2715, ensure the N<sub>2</sub> manifold (located immediately on your right hand side as you enter the service chase) labeled "Trion Phantom" is on. The pressure should read at least 15 PSI.




- 6.1.2 In the Service Chase ensure that the **POWER** on the Trion Phantom Main Power Panel is on.
- 6.1.3 In service chase 17-2715 turn on the **ROUGH PUMP** and **ROOTS BLOWER**.
- 6.1.4 In service chase 17-2715 make sure the chiller is on and full. Ensure the set point of the 50/50 Propylene Glycol/D.I. water controller is set for 35°C.
- 6.1.5 Make sure that the tool is swiped in on card swipe 1.

RIT SMFL Page 2 of 9


# **Semiconductor & Microsystems**

Fabrication Laboratory Revision: D Rev Date: 02/03/2021

6.1.6 If the computer is in sleep mode touch the screen or press the space bar. This should show "STANDBY MODE".



6.1.7 Hit "CANCEL". The MAIN Screen should appear. Press "LOG ON" at the bottom left corner.




RIT SMFL Page 3 of 9


# **Semiconductor & Microsystems**

Fabrication Laboratory Revision: D Rev Date: 02/03/2021

6.1.8 Type **Process** for user name and **proc** as password. Press "Enter". This logs you in.



6.1.9 To load a recipe press LOAD/EDIT RECIPE.




RIT SMFL Page 4 of 9

R·I·T Title: Trion Phantom RIE


# **Semiconductor & Microsystems**

Fabrication Laboratory Revision: D Rev Date: 02/03/2021

6.1.10 This brings up the "**RECIPE PARAMENTER**" screen. Look for the recipe name in the **WHITE** block at the top of the screen. If this is the recipe you want adjust the time by touching the process time and a numeric touch screen appears. Type in the desired time for your etch in seconds and press "**ENTER**".



6.1.11 Press **EXIT** and the **MAIN** Screen should appear with **TRION** at the top. Press "**VENT REACTOR**" and 5 pump purge cycles will start to ensure no process gas is released, then the chamber will vent and open (about 5 minutes). Load the wafer on the platen. Take care to use coated tweezers as to not scratch the platen




RIT SMFL Page 5 of 9

### **Semiconductor & Microsystems**

**Fabrication Laboratory Revision**: D Rev Date: 02/03/2021

TRION

6.1.12 Press "CLOSE LID". The lid will close automatically.



#### **6.2 Etching a Wafer**


NOTE: DO NOT ETCH WAFERS WITH PHOTORESIST THAT HAVE NOT BEEN HARD BAKED. CONTAMINATION, POOR FEATURE QUALITY AND BURNED RESIST MAY RESULT IF NOT HARD BAKED.

**RIT SMFL** Page 6 of 9

# **Semiconductor & Microsystems**

Fabrication Laboratory Revision: D Rev Date: 02/03/2021

6.2.1 Press "AUTOMATIC SINGLE PROCESS". If you use lot codes to control your processing enter it here as well as comments or notes in the bottom box. Press "ENTER" (even if you entered nothing). Your process will start.



6.2.2 Press "OK" when the END OF PROCESS NOTIFICATION screen appears.




RIT SMFL Page 7 of 9

# **Semiconductor & Microsystems**

Fabrication Laboratory Revision: D Rev Date: 02/03/2021

#### 6.3 Unloading Wafer

6.3.1 Press "VENT REACTOR". The 5 pump and purge cycles will start and the chamber will automatically vent and open when complete.



- 6.3.2 Use coated tweezers and remove your wafer. Take care not to scratch the platen.
- 6.3.3 If you are running multiple wafers with the same recipe and time, load the new wafer and repeat from step 6.1.11.
- 6.3.4 If you need to change the etch time or select a different recipe press "LOAD / EDIT RECIPE" and repeat step 6.1.9 through 6.3.2.

#### 6.4 Shutdown

- 6.4.1 Once you are done processing wafers, Press "CLOSE LID" and it returns to the TRION main screen.
- 6.4.2 Press "LOG OFF".
- 6.4.3 Press "STANDBY MODE".
- 6.4.4 Card swipe out. Leave the tool running.

#### 6.5 Errors during Run

RIT SMFL Page 8 of 9

# **Semiconductor & Microsystems**

Fabrication Laboratory Revision: D Rev Date: 02/03/2021

6.5.1 Unknown at this time.

### 7 APPROPRIATE USES OF THE TOOL

- 7.1 This tool is only intended for 6" or 8" wafers and carriers.
- 7.2 Do not process wafers with gold or copper on them. III-V and like substrates should not be processed in this tool,

### 8 ATTACHMENTS

### **REVISION RECORD**

Summary of Changes	Originator	Rev/Date
Original Issue	Zak Kogut	A-11/01/2018
Updated service chase set up and added note for hard bake	Bruce Tolleson	B-06/20/2019
Updated text;	S. Blondell	C-02/06/2020
Updated with comments from P. Meller	T. Grimsley	D - 2/3/21

RIT SMFL Page 9 of 9