i.MX28 EVK Board, Rev. D

Table of Contents

Cover
Revision History
Block Diagram
CPU_Power&JTAG&ADC&USB
CPU_EMI&LCD
CPU_GPMI&ENET&UART&SSP&SAIF
DDR2
NAND & SD Card
Audio&SPDIF
Ethernet
USB
UART
CAN
Power Supply
Boot&UI&ID
JTAG&ETM
LCD Connector&Expansion Port
RIB&SPI&I2C&ADC



Revision History

REVA: 11/04/2009

Original Release

REVB: 04/15/2010

- 1.Changed all the boot mode resistors (R244, R246, R248, R250, R345, R346, R347, R352, R336, R337, R335, R338) to 10
- Kohms.

 2.C180 (reset pin external capacitor) changed to 0.01uF. This is to ensure the reset persistent bit is reset properly to 0 after startup
- 3.Change the USB5V and WALL 5V selection method to use S16 to switch the sources onto the VDD5V pin.
 4.Changed the LCD Backlight supply to be powered from VDD4P2 by default. Added a FET (switched by VDD 5V) from
- LI-ION_BATTERY to VDD4P2 to improve efficiency. Also added an option to power the LCD backlight from WALL_5V_IN for very large displays (with very high backlight current requirements).
- 5.Changed the 5V reset circuit to disconnect the 5V supply from the VDD5V pin when the RESET pin is pressed.
- 6.Changed the COM pin of the LTC2495 to 1/2 of the VCC_ID supply by adding a 47K resistor divider circuit between VDD_ID and COM and GND and COM. This is to fix the ADC readings and to increase the ADC range to the full supply voltage.
- 7.On U63, connected pins 7 and 8 (VREF2 and EN) together and then connected these two pins to the VDDIO_ID net with a 200k resistor. If pins 7 and 8 (VREF2 and EN) are connected directly to VDDIO_ID. U63 could potentially back-power the VDDIO_3V3 rail.
- 8.The current GND test points are small and alligator clips easily fall off. Changed TP12, TP14, TP11, and TP13 to larger GND test
- points and labeled as "GND" on the top silkscreen with large font. Added one GND test point in the middle of the board 9.Added 0.02 ohm (1%) resistors in series with the main power supply signals for current measurement.
- 11.Added GPMI_CE2, GPMI_CE3, GPMI_READY2, and GPMI_READY3 signal connections to NAND flash connector, J93.

 12.Changed USB Host and USB OTG power from WALL 5V net to 5V net. This is to meet the software debugging requirement so

- Taching ed Sub-rasian CoSI or power inform VALCOV inter or or her. This is to meet ne sometide dedugging requirement the system is able to provide a Host SV supply (from USB)) when connected to a battery power supply (no WALL SV supply). 13. Rotated the NAND flash connector 180 degrees to be compatible with the legacy NAND flash d-cards. 14. Changed to the LTC249S, it dehannel ADC, (same as on the Armadillo 2 board) so that the CPU_ID0 and CPU_ID1 ADC
- channels could be added. In addition, a 10K pull-down resistor was added on the CPU_ID1 (ADC channel 13), to identify the board as the MX28 DDR2 rev B EVK.
- 15.Added a 5 pin header (J96) to allow the customer to test various types of 4 and 5 wire resistive touch panels.
- 16.Added the same DC adapter overvoltage protection circuit as on the Armadillo 2 main board.

 17.Add TVS diodes at the VDD5V input pin of the MX28 and at the 5V adapter input for transient overvoltage protection.
- 18. Connected the following pins on the NAND flash connector (J93) to GND: 1, 2, 11, 12, 21, 22, 31, 32, 41, 42, 51, 52. 19. Added a 10K pull-up resistor to USB0_ID.
- 20.Added GPMI_READY2, READY3, CE2, CE3 connections to the MX28 (shared with CAN0 and CAN1 pins).

REV C: 6/11/2010

- 1. Added common mode choke and EMI capacitive filter at the input of the 5V DC adapter for EMI suppression.
- Swapped the pin 1 and 3 connections on J85.

- Swapped the jin and o Ginderons or rous.
 Increased the virtual or acting of C159 to avoid damaging the capacitor when a high voltage adapter is plugged in.
 Added additional 10uF capacitor on the WALL_5V. Thin et after C15.
 Added a ferrite bead on the HEADPHONE_DETECT line of J80 to reduce the board radiated emissions. 6. Changed the FB1-FB6 ferrite beads to higher impedance and wider bandwidth frequency performance ferrites to reduce the board radiated emissions.
- Added a ferrite bead on the USB_0_ID signal near the USB OTG connector (J82).
- Added ferrite beads on the RS232 port connector signals.

REV D: 8/04/2010

1. Connected pin 5 of J83 to GND.















































