



1


Measure the thickness of the cabinet door where you need to install the handle or knob.

**2**


Measure the depth of the screw holes using the supplied short screws.

**3**


Estimate the length needed based on the depth of the screw hole for the short screw test.

**4**

Certify the appropriate length for the breakaway screw, ensuring it meets the ensuing criteria: Cabinet door thickness + 5 millimeters ≤ Screw length < Cabinet door thickness + installation hole depth.

**5**

Make sure the actual length and make a dent on the breaking point before the cut. Use a plier to hold the screw above the breaking point from the side of the screw. Hold just below the breaking point with another plier. The two pliers are at 90° angles. Bend the screw end upward or down to break it off. Do not twist the screw within the grip of the pliers.

**6**

Conclude the installation process. Lay the handle or knob onto the cabinet door and insert the breakaway screw through the previously marked center point. Then, apply a screwdriver or wrench to fasten the screw securely.

