


# BANQIN


## Step 1

Measure the thickness of the cabinet door where you need to install the handle or knob.




## Step 2

Measure the depth of the screw holes using the supplied short screws.




## Step 3

Estimate the length needed based on the depth of the screw hole for the short screw test.




## Step 4

Confirm the required length of the breakaway screw. ensuring that it meets the following criteria: Cabinet door thickness + 5 millimeters ≤ Screw length < Cabinet door thickness + installation hole depth.



## Step 5

Make sure the actual length and make a dent on the breaking point before the cut. Use a plier to hold the screw above the breaking point from the side of the screw. Hold just below the breaking point with another plier. The two pliers are at 90° angles. Bend the screw end upward or down to break it off. Do not twist the screw within the grip of the pliers.



## Step 6

Successful installation. Place the handle or knob on the cabinet door and insert the breakaway screw through the marked center position. Then, use a screwdriver or wrench to tighten the screw.

