






Haliwu

 <p>Cabinet door thickness</p> <p>mm 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15</p>	
<p>1 Measure the thickness of the cabinet door where you need to install the handle or knob.</p>  <p>Installation hole depth</p> <p>mm 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15</p>	<p>2 Measure the depth of the screw holes using the supplied short screws.</p>  <p>Cabinet door thickness + 5mm ≤ Length of screws used < Cabinet door thickness + Installation hole depth</p>
<p>3 Estimate the length needed based on the depth of the screw hole for the short screw test.</p>	<p>4 Certify the appropriate length for the breakaway screw, ensuring it meets the ensuing criteria: Cabinet door thickness + 5 millimeters ≤ Screw length < Cabinet door thickness + installation hole depth.</p>
 <p>Make a dent before cut</p>	
<p>5 Make sure the actual length and make a dent on the breaking point before the cut. Use a plier to hold the screw above the breaking point from the side of the screw. Hold just below the breaking point with another plier. The two pliers are at 90° angles. Bend the screw end upward or down to break it off. Do not twist the screw within the grip of the pliers.</p>	<p>6 Successful installation. Place the handle or knob on the cabinet door and insert the breakaway screw through the marked center position. Then, use a screwdriver or wrench to tighten the screw.</p>