

Installation Guide (Part 1)

Size: 120*120*60

01



Top plate
Right side panel
Left panel
Base plate

Place the top plate, bottom plate, left side plate and right side plate as shown in the figure. Please pay attention to the position of the labels. The arrow on the labels points as shown in the figure.

02



Turn the base plate as shown in the picture so that the label is on the bottom and the arrow points upwards.

03



Turn the left panel as shown in the picture upside down. The label is on the bottom and the arrow points upwards.

04



Turn the right panel as shown in the picture upside down. The label is on the bottom and the arrow points upwards.

05



Turn the right panel as shown in the picture upside down. The label is on the bottom and the arrow points upwards. Use a 4CM yellow long nail to tighten the screws from the base plate to the side plate.

06



Turn the top plate as shown in the picture. The label is on the bottom and the arrow points upwards. Use a 4CM yellow long nail to tighten the screws from the top plate to the side plate.

07



Hinge hole
Hinge hole
Lock hole
Hinge hole
Hinge hole

After the frame is assembled, the labels of the top plate and side plates are located at the lower part on the outside. The hinge holes and lock holes are located at the lower part on the inside.

08



Left back panel
Right back panel
Base plate

Standing at the base position, the back panel is divided into left and right parts and is fixed to the frame. The back panel is fastened with medium-sized screws. Since there are no pre-drilled holes on the side panel, pre-drilling might cause the installation to be unstable. Instead, use screws directly.

09



The wheels are fitted with the smallest screws. There are no pre-drilled holes on the base plate. Pre-drilling holes may cause the installation to be unstable. Simply attach the screws to the four corners of the base plate.

10



Remove the cat head board and the cat bed base board. Align the nail holes on the cat head with those on the side of the cat bed base board, facing the inner side of the base board. Use 4CM screws to connect them.

11



First, connect the middle small jump platform and the support, then fix it on the cat head board.

12



Fix the brackets at both ends of the cat scratching post with 4CM yellow nails. After that, it will look like the picture below.

13



The layer board labels are facing upwards. The arrows point to the back panel. Use 4CM long nails to fix them in the reserved holes on the side panel and the back panel.

14



The cat bed on the left is fixed at the upper left corner. It is secured by 4CM-long nails that are inserted into the reserved holes on the top plate, side plate and back plate.

15



The cat bed on the right is fixed at the upper right corner. It is secured by 4CM-long nails inserted into the reserved holes on the top board, side board and back board.

16



Fix the cat scratching post with 2.5CM nails at any position on the side panel. Installation can be done according to personal preference.

Installation Guide (Part 2)

Size:120*120*60

17



Secure the rounded top of the small jump with four nails, using the smallest nails available, driven from the outside of the back panel.

18



Secure the fence to the side of the shelf using 4 cm nails; fix it from the top of the ladder by passing 4 cm screws through the shelf; at the bottom, use 2.5 cm custom fixings; the bottom does not need to be secured.

19



For safety reasons, it is best to wear gloves during installation. Start by using the smallest screw to fit the hinge into the round hole in the door frame.

20



When installing the door, you can place a piece of cardboard underneath to leave some space for movement at the bottom.

21



Ensure the mesh door is closed and flush with the doorway, then secure it to the side panel using the smallest screws.

22



Once both doors have been fitted, if either door is out of alignment, you can adjust the screw in the centre of the hinge, checking the door's position as you go.

23



Once the door is in the correct position, start by fitting the bottom door stop

24



Next, fit the top door stop; this can be positioned between the two doors to prevent them from being pushed inwards.

25



Once the door is closed, secure the latch using the smallest screw

26



Peel off the adhesive backing from the handle and stick it to the cupboard door

27



The cupboard is now all fitted

