Hangzhou Hikrobot Technology Co.,Ltd.

Hikrobot Event Configuration Tool

User Manual

HIKROBOT

Contents

Chapter 1 Legal Information 1
Chapter 2 Disclaimer 3
2.1 Get Support 3
2.2 Symbol Conventions 3
Chapter 3 Release Notes 4
Chapter 4 Tool Introduction 5
Chapter 5 Configure the Event 7

Chapter 1 Legal Information

© 2024 Hangzhou Hikrobot Co., Ltd. All rights reserved.

About this Manual

The Manual includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of this Manual at the Hikrobot website (***https://en.hikrobotics.com***).
Please use this Manual with the guidance and assistance of professionals trained in supporting the Product.

Trademarks

HIKROBOT and other Hikrobot's trademarks and logos are the properties of Hikrobot in various jurisdictions.
Other trademarks and logos mentioned are the properties of their respective owners.

Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS MANUAL AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKROBOT MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKROBOT BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY, OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKROBOT HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.
YOU ACKNOWLEDGE THAT THE NATURE OF THE INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKROBOT SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER-ATTACK, HACKER ATTACK, VIRUS INFECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKROBOT WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. ESPECIALLY, YOU ARE RESPONSIBLE, FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS. YOU SHALL NOT USE THIS PRODUCT

FOR ANY PROHIBITED END-USES, INCLUDING THE DEVELOPMENT OR PRODUCTION OF WEAPONS OF MASS DESTRUCTION, THE DEVELOPMENT OR PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSIVE OR UNSAFE NUCLEAR FUEL-CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES.

THE PERFORMANCE DATA IN THIS PUBLICATION IS BASED ON HIKROBOT'S INTERNAL RESEARCH/EVALUATION. ACTUAL DATA MAY VARY DEPENDING ON SPECIFIC CONFIGURATIONS AND OPERATING CONDITIONS AND HIKROBOT SHALL NOT BEAR THE CONSEQUENCES ARISING THEREFROM.

IN THE EVENT OF ANY CONFLICTS BETWEEN THIS MANUAL AND THE APPLICABLE LAW, THE LATTER PREVAILS.

Chapter 2 Disclaimer

The manual guides you to establish and configure the Software. To ensure the properness of usage and stability of the Software, refer to the contents below and read the manual carefully before installation and operation.
As GIFs and videos cannot be played in PDF document, you are recommended to read the online document.

2.1 Get Support

You can get support from us in the following ways:
- **Official Website**: visit ***https://en.hikrobotics.com/*** to get other related documents.
- **Email**: global.support@hikrobotics.com.

2.2 Symbol Conventions

The symbols that might be found in this document are defined as follows.

Symbol	Description
Note	Provides additional information to emphasize or supplement important points of the main text.
Caution	Indicates a potentially hazardous situation which, if not avoided, could result in equipment damage, data loss, performance degradation, or unexpected results.
Danger	Indicates a hazardous situation which, if not avoided, will or could result in death or serious injury.

Chapter 3 Release Notes

Key updates of each version are as follows.

V4.4.0

This version was released on August, 2024.

- Adds **Event Monitor** in the main UI for quick event viewing. For details, see ***Configure the Event***.
- Supports copying node name through keyboard shortcut. For details, see ***Configure the Event***.
- Adds shortcut entry to Event monitor. See ***Tool Introduction***.

V4.3.0

This version was released on November, 2023.
Added the function of importing/exporting events.

V4.2.0

This version was released on June, 2023.
Provided reference for viewing and configuring frame grabbers' events.

Chapter 4 Tool Introduction

This tool provides reference for viewing and configuring frame grabbers' events.
The Tool supports the following types of frame grabbers:

- Camera Link frame grabber
- Coax Press frame grabber
- GigE frame grabber
- 10 GigE frame grabber (support some models)
- XoFLink frame grabber

The main window of the Tool is shown below.



Figure 4-1 Event Configuration Tool Main Window

No.	Name	Description
1	Menu Bar	• Click **Help** to switch the tool language to Chinese or English, view the user manual, and view the tool version. • Click **File** to import/export events of frame grabbers.

2	Basic Configuration	● Select a device to conf ● Set the user level as **Re** **Recommended** is selec
3	Configuring Result	The result of event config
4	Event Type	Display all event types of
5	Event Details	Display channels and all t different types.
6	Operations	Select all events, deselec and view event via **Event**

Chapter 5 Configure the Event

With this tool, you can set the events of frame grabbers to display, or import/export the events.

Steps

1. On the top left, click **Select Device** to select a frame grabber to configure events.
   Once connected, the Tool displays all available event types on the left pane.
2. Optional: Modify **User Level**.

   Note

   Guru mode supports more event types than **Recommended**.

3. Select specific required events on the right.

   Note

   - You can hover on the event to view node name and enumeration value.
   - When you select one event, you can press "ctrl+c" to copy the node name of the event.

   - Check a channel of an event type to select all events in the channel.
   - Check an event type to check all events in all channels of the type.
   - On the lower right, click **Check All** to select all events of the frame grabber; click **Cancel All** to cancel selecting all events.
4. Click **Apply** on the lower right.

   For failed attempts, the Tool prompts **Failed Application**.
5. Optional: Click **Enabled Event List** on the top right to view applied events.



Figure 5-1 Enabled Event List

6. Optional: Import or export events.
   – Click **File** → **Import**, select an etc file to open it.

   Note

   - The tool only supports importing etc file of the same frame grabber model.
   - Once imported, the events' status will be automatically checked and the events will be applied by default.

   – Click **File** → **Export**, select a saving path, and click **Save**. By default, the file will be saved in C:\Users\Administrator\MVS\Data\EventTool.
7. Optional: Click **Event Monitor** to view event result. You can also open the event monitor through MVS Client. For details, see *Event Monitor* in user manual.

HIKROBOT

SHAPE OUR FUTURE INTELLIGENTLY

Hangzhou Hikrobot Technology Co.,Ltd.

Tel: 400-989-7998

Website: www.hikrobotics.com