


PlotBridge - WiFi(TCP 9100) to RS-232 bridge for HPGL plotters

UART: 9600-8-N-1, no flow control. GPIO0=TX -> MAX3232 RX, GPIO7=RX <- MAX3232 TX

GPIO8 = onboard LED (LOW=ON), GPIO9 = onboard BOOT button (10s long-press = WiFi reset)



NOTE: verify the MAX3232 module supports 3.3V VCC before connecting power.

NOTE: RS-232 is on the module's own DB9. Cross-connect: MAX3232 TX -> plotter RX, RX <- plotter TX.