## **User Guide:**

- \* Stand close to an art piece to hear about it. The audio guide works the best when the user is facing the art piece.
- \* If the user wishes to pause the audio, press the pause button at the center of the screen.

## **Maintaining Suggestions:**

- \* Restart the app before handing to a new user —> clears the cached music progress data from the previous user.
- \* Restart all 5 anchors every morning, by turning off and on anchors starting from anchor 0 (the anchor near the door) —> sometimes small accuracy issues may come up and make the audio guide jump among art pieces, and usually restarting anchors fixes the issue.