



User Manual

TR 50448 TPMS Reset Tool



Enter Learning Mode

- 1. Make the gear in P position.
- 2. Use cruise to choose TPMS re-learn mode in the dashboard settings
- 3. Horn will ring once and TPMS indicator flashes, then learning mode has been entered successfully. If equipped, the message center will display the front left (LF) tire.





To Rest TPMS Sensors

- 1.Starting relearn process from left front tire, point antenna on correct position. Press & release power button. Once the speaker chirped, move to the next tire.
- 2.Follow this order to rest TPMS sensors: Front left, front right, rear right, rear left.
- 3.After all sensors reseted, the car horns twice means TPMS re-learn finished.



Tips for user:

1.Please make sure antenna fit in CORRECT position.



2.Please make sure the 9V battery is with enough power.



Note: Battery not included

3.Sensors should be original OEM sensors which well programmed.

