# lab7 引导装载程序

- lab7 引导装载程序
  - 。 实验目的
  - 。 实验器材
    - 硬件
    - 软件
  - 。 实验原理
    - IAP(in-application programming)
    - Xmodem
    - STM32的RAM和FLASH
    - 连接电路图
  - 。 实验步骤
    - 连线
    - IAP程序
    - APP程序
    - 运行测试结果:
  - 。 实验心得

## 实验目的

- 理解bootloader的一般功能和基本工作原理;
- 掌握调整编译链接参数以形成定制的编译结果的方法。

# 实验器材

## 硬件

- STM32F103核心板1块;
- ST-Link 1个;
- CP2102
- 杜邦线
- 按钮1个;
- 面包板1块。

## 软件

- STM32CubeIDE;
- SecureCRT

# 实验原理


IAP(in-application programming)

• IAP, 即应用程序内编程。对于大多数基于闪存的系统,一个重要的要求是能够在最终产品中安装固件时进行更新。STM32微控制器可以运行用户特定的固件来对微控制器中嵌入的闪存执行IAP。由于不限制通信接口协议等,只要能通过任意通信接口拿到新版固件包数据(bin文件),就能自己升级固件。这就能

做到添加 外部无线模块(4G模块、wifi)做到OTA升级。也可以使用U盘或TF卡等外部存储设备做到OTG升级。U盘升级的IAP官方有模板程序叫: FWupgrade\_Standalone。


### • IAP执行原理

。 正常程序上电执行流程:




- 从Flash相对0地址即STM32的0x8000000地址开始执行,存储的是栈顶地址。再偏移4个字节找到中断向量表起始地址,即复位中断向量,存储这复位中断程序入口,跳转到复位中断程序入口执行复位中断服务函数Reset\_Handle(void)。 - 复位中断服务函数Reset\_Handle(void)执行完会跳转到main函数,main函数循环运行。 - main函数死循环时,发生中断请求,然后PC指针会跳转到中断向量表寻找对应的中断向量。 - 找到对应的中断向量后执行对应的中断服务函数xxx\_Handler(void). - 执行中断服务函数完成后,返回main函数循环运行。

### ■ 加入IAP后的上电程序执行流程




- 加入IAP后其实就把芯片内的Flash分成了两个程序。IAP过程前是一个程序,IAP后是一个程序。
- 由于是两个程序,我们一般会把放在flash相对的0地址的程序叫bootloader引导启动程序,后面的都叫APP用户程序。
- 如上图的IAP程序就占用了flash的M个字节大小,然后通过跳转后APP程序的中断向量表也往后偏移了M个字节。
- bootloader到APP的跳转是通过函数指针跳转。跳转前需要关闭所有的中断后取消外设功能,跳转后需要更新中断向量表。

• 在Flash运行的IAP的简单框图



。 将芯片内部flash分区两个区域,分别存放bootloader和APP程序。



● IAP工作简单路程图

### **Xmodem**

- XModem是一种在串口通信中广泛使用的异步文件传输协议,分为XModem和1k-XModem协议两种,前者使用128字节的数据块,后者使用1024字节即1k字节的数据块。
- XModem信息包格式
  - 。 XModem协议最早由Ward Christensen在20世纪70年代提出并实现的,传输数据单位为信息包,信息包格式如下:

| Byte1           | Byte2         | Byte3            | Byte4~Byte131 | Byte132-Byte133 |
|-----------------|---------------|------------------|---------------|-----------------|
| Start Of Header | Packet Number | ~(Packet Number) | Packet Data   | 16Bit CRC       |

- 校验方式
  - 。 CRC16校验

#### • 传输流程

| בוטולנמד או                        |               |                         |
|------------------------------------|---------------|-------------------------|
| SENDER                             |               | RECIEVER                |
| I                                  | \ <           | 'c'                     |
| I                                  |               | Time out after 3 second |
| I                                  | <             | NAK                     |
| I                                  |               | Time out after 3 second |
| I                                  | <             | 'c'                     |
| I                                  |               | Time out after 3 second |
| I                                  | <             | NAK                     |
| SOH 0x01 0xFE Data[0~127] CheckSum | >             |                         |
| I                                  | <             | ACK                     |
| SOH 0x02 0xFD Data[0~127] CheckSum | >             |                         |
| I                                  | \ <           | NAK                     |
| SOH 0x02 0xFD Data[0~127] CheckSum | >             |                         |
| I                                  | \ <           | ACK                     |
| SOH 0x03 0xFC Data[0~127] CheckSum | >             |                         |
| I                                  | <             | ACK                     |
| I +                                |               |                         |
| I +                                |               |                         |
| T +                                |               |                         |
| I                                  | <             | ACK                     |
| EOT                                | >             |                         |
| I                                  | <b>  &lt;</b> | ACK                     |
|                                    |               |                         |
|                                    |               |                         |

。 当接收方要求发送方以CRC16校验方式发送数据时以C来请求,发送方对此做出应答,流程就如上 图所示。当发送方仅仅支持校验和方式时,则接收方要发送NAK来请求,要求以校验和方式来发送 数据,如果仅仅支持CRC16校验方式,则只能发送C来请求。如果两者都支持的话,优先发送C来 请求。

## STM32的RAM和FLASH

- STM32有两个存储空间,一个是片上的FLASH,一个是片上的RAM。
- 在烧写程序的时候,需要烧写bin文件或者hex文件到STM32的flash中,被烧写的文件可以称为映像文件 image。Image的内容包含三部分: code、RO-data和RW-data。
- STM32上电启动后,CPU根据boot0和boot1的硬件引脚决定从FLASH还是RAM中启动,默认是从FLASH中启动,启动之后会搬运RW-data到RAM,但是不会搬运code,也就是说CPU执行的代码是在FLASH中读取的,而不是在RAM中。
- 但是可以通过修改连接配置的.ld文件改变code的存放位置。

## 连接电路图

• CP2102连接


| 103 | CP2102 | 颜色 | 意义         |
|-----|--------|----|------------|
| A9  | RXD    | 黄色 | 103发送数据给PC |

| 103 | CP2102 | 颜色 | 意义         |
|-----|--------|----|------------|
| A10 | TXD    | 绿色 | PC发送数据给103 |
| GND | GND    | 黑色 |            |


# 实验步骤

# 连线

• 连线示意图



## • 连线实物图



### IAP程序

```
/* ram */
// 写RAM
ram_status ram_write(uint32_t address, uint32_t *data, uint32_t length)
   ram_status status = RAM_OK;
   uint32_t i;
   for (i = 0u; (i < length) && (RAM_OK == status); i++)
       // 判断是否越界
       if (RAM_APP_END_ADDRESS <= address)</pre>
           status |= RAM ERROR SIZE;
       }
              // 写RAM
       else
       {
           *(__IO uint32_t *)(address) = data[i];
           if (((data[i])) != (*(volatile uint32_t *)address))
               status = HAL_ERROR;
           address += 4u;
       }
   return status;
}
// FLASH中的bootloader跳转到RAM中的APP
void ram jump to app(uint32 t address)
{
   // 函数指针,指向bootloader将跳转到要运行的APP程序地址
   fnc ptr jump to app;
   jump_to_app = (fnc_ptr)(*(volatile uint32_t*) (address+4u));
   HAL DeInit();
    __set_MSP(*(volatile uint32_t*)address);
   for(int i = 0; i < 8; i++)
       NVIC->ICER[i] = 0xFFFFFFFF; // 关闭中断
       NVIC->ICPR[i] = 0xFFFFFFFF; // 清除中断标志位
   jump_to_app();
}
/* Xmodem */
/* Xmodem (128 bytes) packet format
* Byte 0: Header
 * Byte 1:
               Packet number
           Packet number complement
 * Byte 2:
 * Bytes 3-130: Data
* Bytes 131-132: CRC
/* Xmodem (1024 bytes) packet format
```

```
* Byte 0:
                   Header
 * Byte 1:
                  Packet number
 * Byte 2:
                 Packet number complement
* Bytes 3-1026: Data
 * Bytes 1027-1028: CRC
*/
// xmodem接收
void xmodem receive(uint32 t addr)
{
   volatile xmodem_status status = X_OK;
   uint8_t error_number = 0u;
   x_first_packet_received = false;
   xmodem_packet_number = 1u;
   xmodem_actual_ram_address = addr;
   while (X OK == status)
       uint8_t header = 0x00u;
       uart_status comm_status = uart_receive(&header, 1u); // 获得报头
       if ((UART_OK != comm_status) && (false == x_first_packet_received))
       {
           (void)uart_transmit_ch(X_C); // 使用CRC16-Xmodem
       }
       else if ((UART_OK != comm_status) && (true == x_first_packet_received))
           status = xmodem_error_handler(&error_number, X_MAX_ERRORS);
       /* 报头可以是 SOH, STX, EOT, CAN. */
       switch (header)
           xmodem_status packet_status = X_ERROR;
       case X_SOH:
       case X STX:
           packet_status = xmodem_handle_packet(header);  // 解包
           if (X_OK == packet_status) // 解包顺利,发送ACK
               (void)uart_transmit_ch(X_ACK);
           else if (X ERROR RAM == packet status) // 写入RAM异常导致解包异常
               error number = X MAX ERRORS;
               status = xmodem error handler(&error number, X MAX ERRORS);
           }
           else // 其他异常
           {
               status = xmodem_error_handler(&error_number, X_MAX_ERRORS);
           }
           break;
       case X EOT: // 传输结束
           (void)uart_transmit_ch(X_ACK);
           (void)uart_transmit_str((uint8_t *)"\n\rEnd of load command. \n\r");
           break;
```

```
case X_CAN:
            status = X_ERROR;
           break;
        default:
           if (UART OK == comm status)
               status = xmodem_error_handler(&error_number, X_MAX_ERRORS);
            }
           break;
        }
   }
}
// xmodem 解包
static xmodem_status xmodem_handle_packet(uint8_t header)
    xmodem_status status = X_OK;
    uint16_t size = 0u;
    uint8_t received_packet_number[X_PACKET_NUMBER_SIZE];
    uint8_t received_packet_data[X_PACKET_1024_SIZE];
    uint8_t received_packet_crc[X_PACKET_CRC_SIZE];
    if (X_SOH == header)
    {
        size = X_PACKET_128_SIZE; // 128字节格式
    else if (X_STX == header)
       size = X_PACKET_1024_SIZE; // 1024字节格式
    }
    else
        status |= X_ERROR;
    }
    uart_status comm_status = UART_OK;
    comm_status |= uart_receive(&received_packet_number[0u],
X PACKET NUMBER SIZE); // 获得包序号
    comm_status |= uart_receive(&received_packet_data[Ou], size); // 获得包数据
    comm_status |= uart_receive(&received_packet_crc[0u], X_PACKET_CRC_SIZE);
获得CRC校验
    uint16 t crc received =
((uint16_t)received_packet_crc[X_PACKET_CRC_HIGH_INDEX] << 8u) |</pre>
                                                         // 大小端规则转化
((uint16 t)received packet crc[X PACKET CRC LOW INDEX]);
    uint16 t crc calculated = CalcCRC16(&received packet data[Ou], size); // CRC
校验
   if (UART OK != comm status)
        status |= X_ERROR_UART;
    if ((X_OK == status) && (false == x_first_packet_received))
        x first packet received = true;
```

```
if (X_OK == status)
        if (xmodem_packet_number != received_packet_number[0u])
            status |= X_ERROR_NUMBER;
        if (255u != (received_packet_number[X_PACKET_NUMBER_INDEX] +
received_packet_number[X_PACKET_NUMBER_COMPLEMENT_INDEX]))
        {
            status |= X_ERROR_NUMBER;
        if (crc_calculated != crc_received)
            status |= X_ERROR_CRC;
    }
    // 写入RAM
    if ((X_OK == status) && (RAM_OK != ram_write(xmodem_actual_ram_address,
(uint32_t *)&received_packet_data[Ou], (uint32_t)size / 4u)))
    {
        /* RAM error. */
        status |= X_ERROR_RAM;
    /* Raise the packet number and the address counters (if there weren't any
errors). */
    if (X_OK == status)
    {
        xmodem_packet_number++;
        xmodem_actual_ram_address += size;
    return status;
}
/* main.c */
uint8_t ch;
int number;
uart_transmit_str("Lab is running !\r\n");
while (1)
{
/* USER CODE END WHILE */
    ch = 0;
    number = 0;
/* USER CODE BEGIN 3 */
    uint8_t str[100], length;
    uint8_t output[100];
    // 输入指令
    uart_transmit_str("Command\r\n");
    while(1)
        if(uart_receive(&ch, 1) == HAL_OK)
        {
            Receive_Buffer[number++] = ch;
        if(number == BUFFER SIZE || ch == '\r') // 以回车分割指令
```

```
recv_end_flag = 1;
           break;
        }
    // 指令分析
   if (recv_end_flag == 1)
        i = 0;
       // 分离指令
       while (Receive_Buffer[i] != ' ')
           Instruction[i] = Receive_Buffer[i];
           i++;
        }
       // peek指令分析
       if (!strcmp(Instruction, "peek"))
            // 获得地址
           j = 7;
           while (j > 0)
               i++;
               if ((Receive_Buffer[i] == '0' && Receive_Buffer[i + 1] == 'x') ||
Receive_Buffer[i] == 'x')
                   continue;
               else
                   Addr[j--] = Receive_Buffer[i];
           Addr[0] = Receive_Buffer[++i];
            // peek
           int addr = Array_to_Hex(Addr);
           sprintf((char *)Data, "%08X\r\n", *((int *)addr));
           uart_transmit_str(Data);
       // poke指令分析
       else if (!strcmp(Instruction, "poke"))
           // 获得地址
           j = 7;
           while (j > 0)
               if ((Receive_Buffer[i] == '0' && Receive_Buffer[i + 1] == 'x') ||
Receive Buffer[i] == 'x')
                    continue;
               else
                   Addr[j--] = Receive_Buffer[i];
           Addr[0] = Receive_Buffer[++i];
           int addr = Array_to_Hex(Addr);
           // 获得数据
            i += 2;
            j = 7;
```


```
while (j > 0)
                if ((Receive_Buffer[i] == '0' && Receive_Buffer[i + 1] == 'x') ||
Receive_Buffer[i] == 'x')
                    i++;
                    continue;
                }
                else
                    Data[j--] = Receive_Buffer[i];
                i++;
            }
            Data[0] = Receive_Buffer[i++];
            int data = Array_to_Hex(Data);
            // poke
            *((int *)addr) = data;
        }
        // print指令分析
        else if (!strcmp(Instruction, "print"))
        {
            // 获得地址
            j = 7;
            while (j > 0)
            {
                i++;
                if ((Receive_Buffer[i] == '0' && Receive_Buffer[i + 1] == 'x') ||
Receive_Buffer[i] == 'x')
                    continue;
                else
                    Addr[j--] = Receive_Buffer[i];
            Addr[0] = Receive_Buffer[++i];
            int addr = Array_to_Hex(Addr);
            // print
            sprintf(output, "%s\r\n", addr);
            uart_transmit_str(output);
        }
        // load指令分析
        else if (!strcmp(Instruction, "load"))
        {
            // 获得地址
            j = 7;
            while (j > 0)
                i++;
                if ((Receive_Buffer[i] == '0' && Receive_Buffer[i + 1] == 'x') ||
Receive_Buffer[i] == 'x')
                    continue;
                else
                    Addr[j--] = Receive_Buffer[i];
            }
            Addr[0] = Receive_Buffer[++i];
            uint32_t addr = Array_to_Hex(Addr);
            uart transmit str("Load Begin!\r\n");
```

```
// load
            xmodem_receive(addr);
        }
        // run指令分析
        else if (!strcmp(Instruction, "run"))
        {
            // 获得地址
            j = 7;
            while (j > 0)
                i++;
                if ((Receive_Buffer[i] == '0' && Receive_Buffer[i + 1] == 'x') ||
Receive_Buffer[i] == 'x')
                   continue;
                else
                    Addr[j--] = Receive_Buffer[i];
            Addr[0] = Receive Buffer[++i];
            uint32_t addr = Array_to_Hex(Addr);
            uart_transmit_str("Run Begin!\r\n");
            // run
            ram_jump_to_app(addr);
        }
       // 还原初始化
       for (i = 0; i < 5; i++)
            Instruction[i] = 0;
       for(i = 0; i < number; i++)
            Receive Buffer[i] = 0;
        recv_end_flag = 0;
   }
}
```

### APP程序


```
BtnState = 0;
if(BtnState != last_BtnState && BtnState == 1)
    HAL_GPIO_TogglePin(LED_GPIO_Port, LED_Pin);
last_BtnState = BtnState;
```


## 运行测试结果:




• SecureCRT配置

• 键入load指令后,使用SecureCRT以Xmodem协议发送.bin文件






• 键入peek指令查看.bin文件是否写入。键入run运行APP程序



- 。 结果是运行成功
- 按下板子上的reset按钮重启后,键入peek指令读取写入APP程序的位置,发现程序依然存在,所以可以确定APP程序写入了RAM中。



# 实验心得

- 本次实验可以说是难度最大的一个实验,需要了解的内容非常繁杂,而方向也比较模糊。实验后总结主要有以下几点
  - 。 IAP的概念和原理
  - Xmodem协议或者Zmodem协议
  - 。 RAM和FLASH与链接的关系
- 经过这次实验,对STM32的工作原理、IAP升级以及两种协议有了较深的认识。比较遗憾的是自己尝试写的Zmodem协议没能成功运行,由于调试无从下手,加上时间紧迫,无奈放弃修改。查阅资料使用了

Xmodem协议。不过对协议工作原理的学习应该会有助于此后大作业中对Kiss-Modem等协议的使用。