
DARA / EIGHT OUTER PHOTO OPENINGS

Numbering viewed from the FRONT of the finished piece.



Print the following pages at 100% / Actual size. Disable Fit to page.


Each template fits one US Letter sheet. Check its 100 mm scale line.

Cut photo and backing on the solid line. Dashed line is the visible opening.

Templates show the photo FRONT. Keep this orientation when installing.

OUTER_01 / PHOTO + CARD BACKING

Actual size - print at 100%, with Fit to page OFF.



Cut outline: 169.38 x 169.67 mm. Solid line = CUT; dashed = visible area.


The 6 mm border is hidden behind the knot. TOP of photo is up this page.

This line must measure exactly 100 mm after printing.

Test with paper first. Add card shims if needed for a snug 1.6 mm pocket.

OUTER_02 / PHOTO + CARD BACKING

Actual size - print at 100%, with Fit to page OFF.



Cut outline: 169.58 x 169.61 mm. Solid line = CUT; dashed = visible area.


The 6 mm border is hidden behind the knot. TOP of photo is up this page.

This line must measure exactly 100 mm after printing.

Test with paper first. Add card shims if needed for a snug 1.6 mm pocket.

OUTER_03 / PHOTO + CARD BACKING

Actual size - print at 100%, with Fit to page OFF.



Cut outline: 169.48 x 169.52 mm. Solid line = CUT; dashed = visible area.


The 6 mm border is hidden behind the knot. TOP of photo is up this page.

This line must measure exactly 100 mm after printing.

Test with paper first. Add card shims if needed for a snug 1.6 mm pocket.

OUTER_04 / PHOTO + CARD BACKING

Actual size - print at 100%, with Fit to page OFF.



Cut outline: 169.48 x 169.58 mm. Solid line = CUT; dashed = visible area.


The 6 mm border is hidden behind the knot. TOP of photo is up this page.

This line must measure exactly 100 mm after printing.

Test with paper first. Add card shims if needed for a snug 1.6 mm pocket.

OUTER_05 / PHOTO + CARD BACKING

Actual size - print at 100%, with Fit to page OFF.



Cut outline: 169.49 x 169.56 mm. Solid line = CUT; dashed = visible area.


The 6 mm border is hidden behind the knot. TOP of photo is up this page.

This line must measure exactly 100 mm after printing.

Test with paper first. Add card shims if needed for a snug 1.6 mm pocket.

OUTER_06 / PHOTO + CARD BACKING

Actual size - print at 100%, with Fit to page OFF.



Cut outline: 169.52 x 169.30 mm. Solid line = CUT; dashed = visible area.


The 6 mm border is hidden behind the knot. TOP of photo is up this page.

This line must measure exactly 100 mm after printing.

Test with paper first. Add card shims if needed for a snug 1.6 mm pocket.

OUTER_07 / PHOTO + CARD BACKING

Actual size - print at 100%, with Fit to page OFF.



Cut outline: 169.46 x 169.22 mm. Solid line = CUT; dashed = visible area.


The 6 mm border is hidden behind the knot. TOP of photo is up this page.

This line must measure exactly 100 mm after printing.

Test with paper first. Add card shims if needed for a snug 1.6 mm pocket.

OUTER_08 / PHOTO + CARD BACKING

Actual size - print at 100%, with Fit to page OFF.



Cut outline: 169.49 x 169.56 mm. Solid line = CUT; dashed = visible area.

The 6 mm border is hidden behind the knot. TOP of photo is up this page.

This line must measure exactly 100 mm after printing.

Test with paper first. Add card shims if needed for a snug 1.6 mm pocket.