

Note: You can use many other microcontroller boards such as Arduino
Just pick something which is VERY predictable
may want to use a driver even with an arduino which can output 5V logic

Note: Ideally I'd drive each gate driver individually, and read the pulse sent back from the gate−driver boards
They send short pulses at rising and falling edges to acknowledge each pulse sent to them
This can also be used to indicate Error and Fault conditions of the IGBT drivers

Note: Gate Drivers have Fiber Receivers and Transmitters Integrated
I just drew them this way to try to separate the fiber signals

Note: This section of the circuit needs to handle a few thousand amp pulses
I've labeled what I used for conductors for each section
Such as 2AWG Welding Cable or 1/8inch aluminum Buss−Bar

Zach McGinty Garage Medical
Sheet: /
File: TMS_IGBT_And_Gate_Drive.kicad_sch
Title: OpenTMS
Size: A2
Date: 2026−08−17
Rev: 0.0.1
KiCad E.D.A. 10.0.5
Id: 1/1