Asterix category 065 - SDPS Service Status Reports

category: 065

edition: 1.5

date: 2020-06-18

Preamble

Surveillance data exchange.

Description of standard data items

I065/000 - Message Type

definition: This Data Item allows for a more convenient handling of the messages at the receiver side by further defining the type of transaction.

Element
bit size: 8
Values:

- **1:** SDPS Status
- **2:** End of Batch
- **3:** Service Status Report

Notes:

- In application where transactions of various types are exchanged, the Message Type Data Item facilitates the proper message handling at the receiver side.

I065/010 - Data Source Identifier

definition: Identification of the system sending the data.

Group

I065/010/SAC - System Area Code

Element
bit size: 8
Raw Content

I065/010/SIC - System Identification Code

Element
bit size: 8
Raw Content

Note:

- The up-to-date list of SACs is published on the EUROCONTROL Web Site (http://www.eurocontrol.int/asterix).

I065/015 - Service Identification

definition: Identification of the service provided to one or more users.

Element
bit size: 8
Raw Content

Note:

- The service identification is allocated by the SDPS.

I065/020 - Batch Number

definition: A number indicating the completion of a service for that batch of track data, from 0 to N-1, N being the number of batches used to make one complete processing cycle.

Element
bit size: 8
Unsigned integer

I065/030 - Time of Message

definition: Absolute time stamping of the message, in the form of elapsed time since last midnight, expressed as UTC.

Element
bit size: 24
Unsigned quantity
LSB = $1/2^7$ s ≈ $7.8125e-3$ s
unit: ”s”

Note:

- The time is reset to zero at every midnight.

I065/040 - SDPS Configuration and Status

definition: Status of an SDPS.

Group

I065/040/NOGO

Element
bit size: 2
Values:

- **0:** Operational
- **1:** Degraded
- **2:** Not currently connected
- **3:** Unknown

I065/040/OVL

Element
bit size: 1
Values:

- **0:** Default
- **1:** Overload

I065/040/TSV

Element
bit size: 1
Values:

- **0:** Default
- **1:** Invalid Time Source

I065/040/PSS - Processing System Status

Element
bit size: 2
Values:

0: Not applicable
1: SDPS-1 selected
2: SDPS-2 selected
3: SDPS-3 selected

I065/040/STTN - Track Re-numbering Indication

Element
bit size: 1
Raw Content

The STTN bit indicates when track numbering has been restarted. The STTN bit is a toggle bit that changes its value whenever the SDPS system starts re-numbering its tracks. Re-numbering of the track takes place either after SDPS start-up (cold or hot start-up) or when a configuration set has been changed (please note that the latter case is ARTAS specific behaviour and may be different in another SDPS).

Spare bits: 1

I065/050 - Service Status Report

definition: Report sent by the SDPS related to a service

Element
bit size: 8
Values:

1: Service degradation
2: Service degradation ended
3: Main radar out of service
4: Service interrupted by the operator
5: Service interrupted due to contingency
6: Ready for service restart after contingency
7: Service ended by the operator
8: Failure of user main radar
9: Service restarted by the operator
10: Main radar becoming operational
11: Main radar becoming degraded
12: Service continuity interrupted due to disconnection with adjacent unit
13: Service continuity restarted
14: Service synchronised on backup radar
15: Service synchronised on main radar
16: Main and backup radar, if any, failed

I065/RE - Reserved Expansion Field

definition: Expansion

Explicit (ReservedExpansion)

I065/SP - Special Purpose Field

definition: Special Purpose Field

Explicit (SpecialPurpose)

User Application Profile

- 1: `I065/010` - Data Source Identifier
- 2: `I065/000` - Message Type
- 3: `I065/015` - Service Identification

- 4: `I065/030` - Time of Message
- 5: `I065/020` - Batch Number
- 6: `I065/040` - SDPS Configuration and Status
- 7: `I065/050` - Service Status Report
- (FX) - Field extension indicator
- *Spare*
- *Spare*
- *Spare*
- *Spare*
- *Spare*
- 13: `I065/RE` - Reserved Expansion Field
- 14: `I065/SP` - Special Purpose Field
- (FX) - Field extension indicator