

D O R N I E R I



SENDING GRIPPER - DORNIER I



L01



L02



L03


L04



L05




L06



L07



L08



L09



L10



L11



L12



L13



L14



L15



L16



L17



RECEIVING GRIPPER - DORNIER I



R01

R02



R03

R04



R05

R06

R07

R08



R09



R10



R11



R12



R13



R14



R15

PART NO	MM	NO	PART NO	MM	NO
L02	M4	1	L14	M3X16	1
L03	M3X7	2	L15	M3	1
	M3	1	L15	M3X3	1
L05	M3X4	2		M4	1

PART NO	MM	NO	PART NO	MM	NO
R02	M3X7	2	R15	M4X4	1
R03	M4	1		M4	1
R15	M3X16	1			
	M3	1			

D O R N I E R II



SENDING GRIPPER - DORNIER II



L 01



L 02



L 03

L 04



L 05

L 06



L 07



L 08




L 09



L 10




L 11



L 12



L 13



L 14

PART NO	MM	NO	PART NO	MM	NO
L 02	M4	1	L 11	M3X7	2
L 08	M3X12	1		M3	1
	M3	1			
	M4X4	1			
	M4X6	1			



RECEIVING GRIPPER - DORNIER II



R 01



R 02



R 03

R 04



R 05

R 06



R 07



R 08




R 09



R 10



R 11




R 12



R 13



R 14



R 15

PART NO	MM	NO	PART NO	MM	NO
R 02	M4	1			
R 08	M3X7	2			
R 09	M3X12	1			
	M3	1			
	M4X4	1			
	M4X6	1			

D O R N I E R I I



SENDING GRIPPER-DORNIER III



L 01



L 02

L 03

L 04


L 05



L 06



L 07



L 08

L 09

L 10

L 11

L 12



L 13 L 14 L 15 L 16

L 17 L 18 L 19 L 20



RECEIVING GRIPPER-DORNIER III



R 01



R 02

R 03

R 04

R 05



R 06

R 07

R 08

R 09

R 10

R 11

R 12

R 13

R 14

R 15

R 16

PART NO	MM	NO	PART NO	MM	NO
L 05	M3X8	1	R 05	M3X10	1
L 06	M4X10	1	R 14	M4X10	1
L 07	M3X10	1	R 14	M4X4	1
L 13	M3X17	1	R 14	M3X8	1
L 18	M3X3	1			

D
O
R
N
I
E
R

M
I
S
C
E
L
L
A
N
E
O
U
S



RDR 1



RDR 2



RDR 3



RDR 4



RDR 5



RDR 6



RDR 7



RDR 8



RDR 10



RDR 11



RDR 12



RDR 13



RDR 9