

**S
U
L
Z
E
R

R
A
P
I
E
R

G 6200**



SENDING GRIPPER- G 6200 I



L01



L02



L03



L04



L05



L06



L07

PART NO	MM	NO
L03	M2X6	2
L07	M2X4	1



RECEIVING GRIPPER- G 6200 I



R01

R02



R03



R04



R05



R06



R07



R08

PART NO	MM	NO
R08	M2X4	2
R09	M2X7	1



R09



R10

SULZER RAPIER

G 6300



SENDING GRIPPER - G 6300



L 01

L 02



L 03



L 04



L 05



L 06



L 07



L 08



L 09



RECEIVING GRIPPER - G 6300



R 01




R 02



R 03



R 04



R 05



R 06



R 07



R 08



R 09



R 10



R 11



R 12



R 13



R 14

PART NO	MM	NO	PART NO	MM	NO
L 02	M2X2.5	2	R 04	M2X4	4
	M2X3	2	R 05	M2X3.5	2
L 04	M1.6X2	1			

SULZER RAPIER MISCELLANEOUS



RSR 1



RSR 2



RSR 3



RSR 4



RSR 5