#### **Assembly Language and Microcomputer Interface**

# Chapter 4: Data Movement Instructions

Ming Cai

cm@zju.edu.cn

College of Computer Science and Technology Zhejiang University

#### Introduction

- This chapter concentrates on the data movement instructions.
- The data movement instructions include MOV, MOVSX, MOVZX, PUSH, POP, BSWAP, XCHG, XLAT, IN, OUT, LEA, LDS, LES, LFS, LGS, LSS, LAHF, SAHF.
- String instructions: MOVS, LODS, STOS, INS, and OUTS.
- Data movement instructions do not affect flags.

#### **Chapter Objectives**

Upon completion of this chapter, you will be able to:

- Explain the operation of each data movement instruction with applicable addressing modes.
- Explain the purposes of the assembly language pseudo-operations and key words such as ALIGN, ASSUME, DB, DD, DW, END, ENDS, ENDP, EQU, .MODEL, OFFSET, ORG, PROC, PTR, SEGMENT, USEI6, USE32, and USES.

#### **Chapter Objectives**

(cont.)

Upon completion of this chapter, you will be able to:

- Select the appropriate assembly language instruction to accomplish a specific data movement task.
- Determine the symbolic opcode, source, destination, and addressing mode for a hexadecimal machine language instruction.
- Use the assembler to set up a data segment, stack segment, and code segment.

#### **Chapter Objectives**

(cont.)

Upon completion of this chapter, you will be able to:

- Show how to set up a procedure using PROC and ENDP.
- Explain the difference between memory models and full-segment definitions for the MASM assembler.

#### 4-1 MOV Revisited

- In this chapter, the MOV instruction introduces machine language instructions available with various addressing modes and instructions.
- It may be necessary to interpret machine language programs generated by an assembler.
- Occasionally, machine language patches are made by using the DEBUG program available with DOS and Visual for Windows.

## **Machine Language**

- Native binary code microprocessor uses as its instructions to control its operation.
  - instructions vary in length from 1 to 15 bytes
- Over 100,000 variations of machine language instructions.
  - there is no complete list of these variations
- Some bits in a machine language instruction are given; remaining bits are determined for each variation of the instruction.

Figure 4–1 The formats of the 8086–Core2 instructions. (a) The 16-bit form and (b) the 32-bit form. A D/B flag in prefix indicates 16-bit or 32-bit 16-bit instruction mode MOD-REG-R/M Opcode Displacement **Immediate** Instruction Prefixes 1-2 bytes 0-1 bytes 0-1 bytes 0-2 bytes 1 byte each (a) 32-bit instruction mode (80386 through Pentium 4 only) Register size Address size : Opcode MOD-REG-R/M Scaled-index Displacement **Immediate** Instruction Prefixes 0-1 bytes 0-1 bytes 0-1 bytes 1-2 bytes 0-1 bytes 0-4 bytes 0-4 bytes 1 byte each

 80386 and above assume all instructions are 16bit mode instructions when the machine is operated in the *real mode* (*DOS*).


(b)

 in protected mode (Windows), the upper byte of the descriptor contains the D-bit that selects either the 16- or 32-bit instruction mode

#### **Instruction Stored in Memory**

- Instructions are stored in memory in little-endian order. The first byte of an instruction is stored at the lowest memory address.
- Since instructions are strings of bytes, they may start at any memory address.
- The total instruction length must be less than or equal to 15. If this limit is exceeded, a general-protection exception results.


Legacy encoding including optional REX Prefix



## The Opcode-Byte 1

- Selects the operation (addition, subtraction, etc.,) performed by the microprocessor.
  - either 1 or 2 bytes long for most instructions
- Figure 4–2 illustrates the general form of the first opcode byte of many instructions.
  - first 6 bits of the first byte are the binary opcode
  - remaining 2 bits indicate the direction (D) of the data flow, and indicate the data size (W) (a byte or a word)

**Figure 4–2** Byte 1 of many machine language instructions, showing the position of the D- and W-bits.



- If the direction bit D=1, data flow to the register REG field from the R/M field.
- If the direction bit D=0, data flow to the R/M field from the REG field.

Chapter 4

11

#### The Opcode-Byte 1

- If the W-bit=1, the data size is a word or doubleword.
- If the W-bit=0, the data size is always a byte.
- The W-bit appears in most instructions, while the D-bit appears mainly with the MOV and some instructions.

	16-bit m	<u> </u>	register-size ride prefix)
Code	W = 0 (Byte)	W = 1 (Word)	W = 1 (Doubleword)
000	AL	AX	EAX
001	CL	CX	ECX
010	DL	DX	EDX
011	BL	BX	EBX
100	AH	SP	ESP
101	CH	BP	EBP
110	DH	SI	ESI
111	BH	DI	EDI

#### MOD Field-Byte 2

**Figure 4–3** Byte 2 of many machine language instructions, showing the position of the MOD, REG, and R/M fields.

MOD	REG	R/M
L : L	<u> </u>	

MOD	Function	
00	No displacement	
01	8-bit sign-extended displacement	
10	16-bit signed displacement	
11	R/M is a register	

MOD field for the 16-bit instruction mode

- The MOD field specifies the addressing mode (MOD) for the selected instruction.
- The MOD field selects the type of addressing and whether a displacement is present with the selected type.

## MOD Field-Byte 2

- Specifies addressing mode (MOD) and whether a displacement is present with the selected type.
  - If MOD field contains an 11, it selects the registeraddressing mode
  - Register addressing specifies a register instead of a memory location, using the R/M field
- If the MOD field contains a 00, 01, or 10, the R/M field selects one of the data memoryaddressing modes.


- All 8-bit displacements are sign-extended into 16-bit displacements when the processor executes the instruction.
  - if the 8-bit displacement is 00H–7FH (positive),
     it is sign-extended to 0000H–007FH before
     adding to the offset address
  - if the 8-bit displacement is 80H–FFH (negative),
     it is sign-extended to FF80H–FFFFH
- Some assembler programs do not use the 8bit displacements and in place default to all 16-bit displacements.

## Register Assignments

- Suppose a 2-byte instruction, 8BECH, appears in a machine language program.
  - neither a 67H (operand address-size override prefix) nor a 66H (register-size override prefix) appears as the first byte, thus the first byte is the opcode
- In 16-bit mode, this instruction is converted to binary and placed in the instruction format of bytes 1 and 2, as illustrated in Figure 4–4.

Figure 4–4 The 8BEC instruction placed into bytes 1 and 2 formats from Figures 4–2

and 4–3. This instruction is a MOV BP,SP.



MOD REG R/M

1 1 1 0 1 1 0 0

Opcode = MOV

D = Transfer to register (REG)

W = Word

MOD = R/M is a register

REG = BP

R/M = SP


– opcode 100010: MOV

Code	W=1 (Word)
101	BP
100	SP

- D and W bits are a logic 1, so a word moves into the destination register specified in the REG field
- REG field contains 101, indicating register BP, so the MOV instruction moves data into register BP

- Because the MOD field contains a 11, the R/M field also indicates a register.
- R/M = 100(SP); therefore, this instruction moves data from SP into BP.
  - written in symbolic form as a MOV BP,SP instruction
- The assembler program keeps track of the register- and address-size prefixes and the mode of operation.


- Suppose that a 668BE8H instruction appears in an 80386, operated in the 16-bit instruction mode.
  - The first byte (66H) is the register-size override prefix that selects 32-bit register operands for the 16-bit instruction.
  - 10001011 (8BH):opcode:100010 (MOV); D=1; W=1
  - 11101000 (E8H): MOD: 11; REG: 101; R/M: 000



Code	W=1 (Doubleword)
000	EAX
101	EBP

This instruction is a MOV EBP, EAX.

- The same instruction (668BE8H) becomes a MOV BP,AX instruction in the 80386 and above if it is operated in the 32-bit instruction mode.
  - The first byte (66H) is the register-size override prefix that selects 16-bit register operands for the 32-bit instruction.
  - 10001011 (8BH):opcode:100010 (MOV); D=1; W=1
  - 11101000 (E8H): MOD: 11; REG: 101; R/M: 000




Code	W=1 (Word)
000	AX
101	BP

This instruction is a MOV BP,AX.


## R/M Memory Addressing

- If the MOD field contains a 00, 01, or 10, the R/M field takes on a new meaning.
- Figure 4–5 illustrates the machine language version of the 16-bit instruction MOV DL,[DI] or instruction (8AI5H).
- This instruction is 2 bytes long and has an opcode 100010, D=1 (to REG from R/M), W=0 (byte), MOD=00 (no displacement), REG=010 (DL), and R/M=101 ([DI]).

**Figure 4–5** A MOV DL,[DI] instruction (8A15H)converted to its machine language form.




- If the instruction changes to MOV DL, [DI+1], the MOD field changes to 01 for 8-bit displacement
- first 1 byte of the instruction remains the same
- instruction now becomes 8A5501H instead of 8A15H



## Special Addressing Mode


- A special addressing mode occurs when memory data are referenced by only the displacement mode of addressing for 16-bit instructions.
- Examples are the MOV [1000H], DL and MOV NUMB, DL instructions.
  - first instruction moves contents of register DL into data segment memory location 1000H
  - second moves register DL into symbolic data segment memory location NUMB


- When an instruction has only a displacement,
   MOD field is always 00; R/M field always 110.
  - You cannot actually use addressing mode [BP]
     without a displacement in machine language





 If the individual translating this symbolic instruction into machine language does not know about the special addressing mode, the instruction would incorrectly translate to a MOV [BP],DL instruction.

Figure 4–6 The MOV [1000H], DL instruction uses the special addressing mode.












Opcode = MOV
D = Transfer from register (REG)
W = Byte
MOD = because R/M is [BP] (special addressing)
REG = DL
R/M = DS:[BP]
Displacement = 1000H

 bit pattern required to encode the MOV [1000H],DL instruction in machine language

Figure 4–7 The MOV [BP], DL instruction converted to binary machine language.







Opcode = MOV

D = Transfer from register (REG)

W = Byte

MOD = because R/M is [BP] (special addressing)

REG = DL

R/M = DS:[BP]

Displacement = 00H

- actual form of the MOV [BP], DL instruction
- a 3-byte instruction with a displacement of 00H

#### 32-Bit Addressing Modes

- Found in 80386 and above.
  - by running in 32-bit instruction mode or
  - In 16-bit mode by using address-size prefix 67H

R/M Code	Addressing Mode	_	R/M Code	Function
000 001 010 011 100 101 110	DS:[BX+SI] DS:[BX+DI] SS:[BP+SI] SS:[BP+DI] DS:[SI] DS:[DI] SS:[BP]* DS:[BX]		000 001 010 011 100 101 110	DS:[EAX] DS:[ECX] DS:[EDX] DS:[EBX] Uses scaled-index byte SS:[EBP]* DS:[ESI] DS:[EDI]

16-bit instruction mode uses base or index register to address the memory, e.g., MOV DX,[BX + DI]

32-bit instruction mode allows the combination of any two 32-bit registers except ESP, e.g., MOV DL,[EAX+EBX]

#### 32-Bit Addressing Modes

 When R/M=100, an additional byte called a scaled-index byte appears in the instruction.

 A <u>scaled-index byte</u> indicates additional forms of scaledindex addressing.

R/M Code	Function
000	DS:[EAX]
001	DS:[ECX]
010	DS:[EDX]
011	DS:[EBX]
100	Uses scaled-index byte
101	↑ SS:[EBP]*
110	DS:[ESI]
111	DS:[EDI]

Address size 0–1 bytes Register size 0–1 bytes Opcode 1–2 bytes

MOD-REG-R/M 0-1 bytes Scaled-index 0-1 bytes


Displacement 0-4 bytes Immediate 0-4 bytes

- Over 32,000 variations of the MOV instruction alone in the 80386 - Core2 microprocessors.
- Figure 4–8 shows the format of the scaledindex byte as selected by a value of 100 in the R/M field of an instruction when the 80386 and above use a 32-bit address.
- The leftmost 2 bits select a scaling factor (multiplier) of 1x, 2x, 4x, 8x.
- Scaled-index addressing can also use a single register multiplied by a scaling factor.

Figure 4–8 The scaled-index byte.

 $10 = \times 4$ 

 $11 = \times 8$ 




- If the microprocessor operates in the 32-bit instruction mode, The instruction
  - MOV EAX,[EBX+4\*ECX] is encoded as 8B048BH.
    - First byte (8BH):100010 11 → MOV
    - Second byte (04H): 00 000 100 → EAX, scaled-index
    - Third byte (8BH):  $10\ 001\ 011 \rightarrow \times 4$ , ECX, EBX

#### An Immediate Instruction

- An example of a 16-bit instruction using immediate addressing.
  - MOV WORD PTR [BX+1000H] ,1234H moves a 1234H into a word-sized memory location addressed by sum of 1000H, BX, and DS × 10H
- 6-byte instruction
  - 2 bytes for the opcode, W, MOD, and R/M fields;
     2 bytes are the displacement of 1000H;
     2 bytes are the data of 1234H
- Figure 4–9 shows the binary bit pattern for each byte of this instruction.

**Figure 4–9** A MOV WORD PTR [BX+1000H], 1234H instruction converted to binary machine language.



- This instruction, in symbolic form, includes WORD PTR.
  - directive indicates to the assembler that the instruction uses a word-sized memory pointer
- If the instruction moves a byte of immediate data, BYTE PTR replaces WORD PTR.
  - if a doubleword of immediate data, the DWORD
     PTR directive replaces BYTE PTR
- Instructions referring to memory through a pointer do not need the BYTE PTR, WORD PTR, or DWORD PTR directives.

#### Segment MOV Instructions


 If contents of a segment register are moved by MOV, PUSH, or POP instructions, a special bits (REG field) select the segment register.

Code	Segment Register
segment register 000	ES CS*
selection 010	SS DS
100 101	FS GS

- the opcode for this type of MOV instruction is different for the prior MOV instructions
- an immediate segment register MOV is not available in the instruction set

 To load a segment register with immediate data, first load another register with the data and move it to a segment register.

Figure 4–10 A MOV BX,CS instruction converted to binary machine language.



- Figure 4–10 shows a MOV BX,CS instruction converted to binary.
- Segment registers can be moved between any 16-bit register or 16-bit memory location.

- A program written in symbolic assembly language (assembly language) is rarely assembled by hand into binary machine language.
- An assembler program converts symbolic assembly language into machine language.

# The 64-Bit Mode for the Pentium 4 and Core2


- In 64-bit mode, a prefix called REX (*register extension*) is added to enable use of the register and operand size extensions.
- REX is not a single unique value, but occupies a range (40h to 4Fh), following other prefixes and placing before the opcode.
- Purpose is to modify reg and r/m fields in the second byte of the instruction.
  - REX is needed to be able to address registers R8 through R15

REX contains five fields. The upper nibble is unique to the REX prefix and identifies it is as such. The lower nibble is divided into four 1-bit fields (W, R, X, and B).

Mnemonic	Bit Position(s)	Definition
_	7:4	0100 (4h)
REX.W	3	0 = Default operand size 1 = 64-bit operand size
REX.R	2	1-bit (msb) extension of the ModRM reg field <sup>1</sup> , permitting access to 16 registers.
REX.X	1	1-bit (msb) extension of the SIB <i>index</i> field <sup>1</sup> , permitting access to 16 registers.
REX.B	0	1-bit (msb) extension of the ModRM <i>r/m</i> field <sup>1</sup> , SIB <i>base</i> field <sup>1</sup> , or opcode <i>reg</i> field, permitting access to 16 registers.

- Figure 4–11 illustrates the structure and application of REX to the second byte of the opcode.
- The reg field can only contain register assignments as in other modes of operation
- The r/m field contains either a register or memory assignment.
- Figure 4–12 shows the scaled-index byte with the REX prefix for more complex addressing modes and also for using a scaling factor in the 64-bit mode of operation.


Figure 4–11 The application of REX without scaled index.



W = 1 (64 bits)

W = 0 (CS descriptor)

Figure 4–12 The scaled-index byte and REX prefix for 64-bit operations.



### **Operand-Size Override Prefix**

- In 64-bit mode, instructions default to a 32-bit operand size.
- The prefix allows mixing of 16, 32, and 64-bit data:
  - a REX (REX.W) prefix can specify a 64-bit operand size
  - a 66h prefix specifies a 16-bit operand size
  - the REX prefix takes precedence over the 66h prefix.

Operating Mode		Default	Effective Operand	Instruction Prefix <sup>1</sup>		
		Operand Size (Bits)	Size (Bits)	66h	REX.W <sup>3</sup>	
	64 Di4		64	don't care	yes	
	64-Bit Mode	32 <sup>2</sup>	32	no	no	
			16	yes	no	
Mode Compati Mode		32	32	no		
	Compatibility	32	16	yes		
	Mode	16	32	yes		
		10	16	no	Not Appli-	
Legacy Mode (Protected, Virtual-8086, or Real Mode)		32	32	no	cable	
		32	16	yes		
		16	32	yes		
		10	16	no		

Operand-Size Overrides

#### **Address-Size Override Prefix**

- The default address size is 64 bits in 64-bit mode. The size can be overridden to 32 bits, but 16-bit addresses are not supported in 64-bit mode.
- The address-size override prefix (67h) selects the non-default address size.

Operating Mode		Default Address Size (Bits)	Effective Address Size (Bits)	Address- Size Prefix (67h) <sup>1</sup> Required?
	64-Bit	64	64	no
	Mode	0.1	32	yes
Long Mode	Compatibility Mode	32	32	no
			16	yes
		16	32	yes
		10	16	no
Legacy Mode (Protected, Virtual-8086, or Real Mode)		32	32	no
		32	16	yes
		16	32	yes
		10	16	no

Address-Size Overrides

## **Escape Sequence/Opcode**

- Since there are more than 256 instructions defined by the architecture, multiple different opcode maps must be defined.
- Escape sequence is used to expand the coding space by using one escape opcode byte (0FH) or two-byte escape (0F38H, 0F3AH) to provide another opcodes.

Primary
Opcode Map

Nibble <sup>1</sup>	8	9	Α	В	С	D	E	F
0	OR					PUSH CS <sup>3</sup>	escape to secondary	
	Eb, Gb	Ev, Gv	Gb, Eb	Gv, Ev	AL, Ib	rAX, Iz	CS	opcode map
1	SBB					PUSH	POP	
'	Eb, Gb	Ev, Gv	Gb, Eb	Gv, Ev	AL, Ib	rAX, Iz	DS <sup>3</sup>	DS <sup>3</sup>
_	SUB						- 9	

Secondary Opcode Map

-		SUB							9	
Prefix	Nibble <sup>1</sup>	8	9	Α	В	С	D	E	F	سر
							Group P <sup>2</sup>		3DNow!	V
n/a	0	INVD	WBINVD (F3) WBNOINVD		UD2		PREFETCH	FEMMS	See "3DNow!™ Opcodes" on page 491	
n/a	1	Group 16 <sup>2</sup>	NOP <sup>3</sup>	NOP <sup>3</sup>	NOP <sup>3</sup>	NOP <sup>3</sup>	NOP <sup>3</sup>	NOP <sup>3</sup>	NOP <sup>3</sup>	
nono		MOV	/APS	CVTPI2PS	MOVNTPS	CVTTPS2PI	CVTPS2PI	UCOMISS	COMISS	
none		Vps, Wps	Wps, Vps	Vps, Qpj	Mo, Vps	Ppj, Wps	Ppj, Wps	Vss, Wss	Vss, Wss	
F3				CVTSI2SS	MOVNTSS	CVTTSS2SI	CVTSS2SI			
	2			Vss, Ey	Md, Vss	Gy, Wss	Gy, Wss			
66	2	MOV	/APD	CVTPI2PD	MOVNTPD	CVTTPD2PI	CVTPD2PI	UCOMISD	COMISD	
		Vpd, Wpd	Wpd, Vpd	Vpd, Qpj	Mo, Vpd	Ppj, Wpd	Ppj, Wpd	Vsd, Wsd	Vsd, Wsd	
F2				CVTSI2SD	MOVNTSD	CVTTSD2SI	CVTSD2SI			
' -				Vsd, Ey	Mq, Vsd	Gy, Wsd	Gy, Wsd			
	•	Escape to		Escape to						
n/a	3	0F_38h		0F_3Ah						
		opcode map		opcode map	A					ł

## **Escape Sequence/Opcode**

- For example:
  - 0F AF is the opcode of IMUL r32, r/m32
  - 0F B6 is the opcode of MOVZX r32, r/m8
- These common instructions were introduced after the original 8086, and there was no coding-space left to give them single-byte opcodes.

Opcode	Instruction
F6 /5	IMUL r/m8*
F7 /5	IMUL r/m16
F7 /5	IMUL r/m32
REX.W + F7 /5	IMUL r/m64
OF AF /r	IMUL r16, r/m16
OF AF /r	IMUL r32, r/m32

Opcode	Instruction	64-Bit Mode
0F B6 /r	MOVZX r16, r/m8	Valid
0F B6 /r	MOVZX r32, r/m8	Valid
REX.W + 0F B6 /r	MOVZX r64, r/m8*	Valid
0F B7 /r	MOVZX <i>r32, r/m16</i>	Valid
REX.W + 0F B7 /r	MOVZX r64, r/m16	Valid

IMUL—Signed Multiply

MOVZX—Move with Zero-Extend

#### **Lock Prefix**

- The LOCK prefix causes certain kinds of memory read-modify-write instructions to perform atomic operation.
- The prefix is intended to give the processor exclusive use of shared memory in a multiprocessor system.
- The LOCK prefix can only be used with following instructions that write a memory operand: BTC, BTR, BTS, ADC, ADD, AND, DEC, INC, NEG, NOT, OR, SBB, SUB, XOR, CMPXCHG, CMPXCHG8B, CMPXCHG16B, XADD and XCHG.
- An undefined opcode exception (#UD) occurs if the LOCK prefix is used with any other instruction.

## **Summary of Prefixes**

- Operand-size override prefix affects the operand size for general-purpose instructions.
- Address-size override prefix affects the address size of memory operands.
- Segment override prefix selects alternate segment register.
- Lock prefix forces an operation that ensures exclusive use of shared memory in a multiprocessor environment.
- Repeat prefix repeats its associated string instruction the number of times specified in the counter register (rCX).
- REX prefix can be used in 64-bit mode to access the 64-bit registers and size extensions.

#### 4-2 PUSH/POP

- Important instructions that store and retrieve data from the LIFO (last-in, first-out) stack memory.
- Six forms of the PUSH and POP instructions:
  - register, memory, immediate
  - segment register, flags, all registers
- The PUSH and POP immediate & PUSHA and POPA (all registers) available 80286 - Core2.

- Register addressing allows contents of any 16-bit register to transfer to & from the stack.
- Memory-addressing PUSH and POP instructions store contents of a 16- or 32 bit memory location on the stack or stack data into a memory location.
- Immediate addressing allows immediate data to be pushed onto the stack, but not popped off the stack.


- Segment register addressing allows contents of any segment register to be pushed onto the stack or removed from the stack.
  - CS may be pushed, but data from the stack may never be popped into CS
- The flags may be pushed or popped from that stack.
  - contents of all registers may be pushed or popped

#### **PUSH**

- Always transfers 2 bytes of data to the stack;
  - 80386 and above transfer 2 or 4 bytes
- PUSHA (**push all**) instruction copies contents of the internal register set, except the segment registers, to the stack.
- PUSHA instruction copies the registers to the stack in the following order: AX, CX, DX, BX, SP (original value), BP, SI, and DI.
- The value pushed for the SP register is its value before prior to pushing the first register.


- PUSHF (**push flags**) instruction copies the contents of the flag register to the stack.
- PUSHAD and POPAD instructions push and pop the contents of the 32-bit register set in 80386 - Pentium 4.
  - PUSHA and POPA instructions do not function in the 64-bit mode of operation for the Pentium 4

**Figure 4–13** The effect of the PUSH AX instruction on ESP and stack memory locations 37FFH and 37FEH. This instruction is shown at the point after execution.



- PUSHA instruction pushes all the internal 16bit registers onto the stack, illustrated in 4–14.
  - requires 16 bytes of stack memory space to store all eight 16-bit registers
- After all registers are pushed, the contents of the SP register are decremented by 16.
- PUSHA is very useful when the entire register set of 80286 and above must be saved.
- PUSHAD instruction places 32-bit register set on the stack in 80386 - Core2.
  - PUSHAD requires 32 bytes of stack storage

**Figure 4–14** The operation of the PUSHA instruction, showing the location and order of stack data.




#### POP

- Performs the inverse operation of PUSH.
- POP removes data from the stack and places it in a target 16-bit register, segment register, or a 16-bit memory location.
  - not available as an immediate POP
- POPF (pop flags) removes a 16-bit number from the stack and places it in the flag register;
  - POPFD removes a 32-bit number from the stack and places it into the extended flag register

- POPA (pop all) removes 16 bytes of data from the stack and places them into the following registers, in the order shown: DI, SI, BP, SP, BX, DX, CX, and AX.
  - reverse order from placement on the stack by PUSHA instruction, causing the same data to return to the same registers
- Figure 4–15 shows how the POP BX instruction removes data from the stack and places them into register BX.


**Figure 4–15** The POP BX instruction, showing how data are removed from the stack. This instruction is shown after execution.



# Initializing the Stack

- When the stack area is initialized, load both the stack segment (SS) register and the stack pointer (SP) register.
- Figure 4–16 shows how this value causes data to be pushed onto the top of the stack segment with a PUSH CX instruction.
- All segments are cyclic in nature
  - the top location of a segment is contiguous with the bottom location of the segment

**Figure 4–16** The PUSH CX instruction, showing the cyclical nature of the stack segment. This instruction is shown just before execution, to illustrate that the stack bottom is contiguous to the top.



- Assembly language stack segment setup:
  - first statement identifies start of the segment
  - last statement identifies end of the stack segment
- Assembler and linker programs place correct stack segment address in SS and the length of the segment (top of the stack) into SP.
- There is no need to load these registers in your program.
  - unless you wish to change the initial values for some reason

- If the stack is not specified, a warning will appear when the program is linked.
- Memory section is located in the program segment prefix (PSP), appended to the beginning of each program file.
- If you use more memory for the stack, you will erase information in the PSP.
  - information critical to the operation of your program and the computer
- Error often causes the program to crash.

#### 4-3 LOAD EFFECTIVE ADDRESS

- Two types of load-effective address instructions:
  - LEA: Loads a near pointer (offset)
  - LDS, LES, LFS, LGS, and LSS: Loads a far pointer (segment selector and offset)

 Load-effective address instruction set was designed to support high-level languages like C. Consider a struct representing (x, y) coordinates:

```
struct Point
     int xcoord;
     int ycoord;
};
```

Now imagine two statements:

```
// load the address of ycoord
 // load the value of ycoord
                                    int *p = &(points[i].ycoord);
 int y = points[i].ycoord;
                                    LEA ESI, [EBX + 8*EAX + 4]
MOV EDX, [EBX + 8*EAX + 4]
```

EBX is the base of array (points); EAX is for variable i; 8 is the scale factor of each point and 4 is the offset of ycoord.

#### **LEA**

- Loads a 16- or 32-bit register with the offset address of the data specified by the operand.
- By comparing LEA with MOV, we observe that:
  - LEA BX,[DI] loads the offset address specified by
     [DI] (contents of DI) into the BX register;
  - MOV BX,[DI] loads the data stored at the memory location addressed by [DI] into register BX.
- The SEG and OFFSET directive return the segment and offset value of a memory location.

## OFFSET performs same function as LEA instruction if the operand is a displacement.

**Example 4–3** is a program that loads SI with the address of DATA1 and DI with the address of DATA2. It then exchanges the contents of these memory locations. Note that the LEA and MOV with OFFSET instructions are both the same length (3 bytes).


```
;select small model
                          .MODEL SMALL
0000
                                                ;start data segment
                          . DATA
0000 2000
                 DATA1
                                 2000H
                                                ;define DATA1
                         DW
0002 3000
                 DATA2
                                 3000H
                                                ;define DATA2
                         DW
                                                ;start code segment
                          . CODE
0000
                          .STARTUP
                                                ;start program
                                                ;address DATA1 with SI
0017 BE 0000 R
                         LEA SI, DATA1
001A BF 0002 R
                         MOV DI,OFFSET DATA2
                                                ;address DATA2 with DI
                         MOV BX, [SI]
                                                ; exchange DAT1 with DATA2
001D 8B 1C
                         MOV CX, [DI]
001F 8B 0D
                         MOV [SI],CX
0021 89 0C
                         MOV [DI], BX
0023 89 1D
                          EXIT
                         END
```

- OFFSET is more efficient than LEA instruction
  - two clocks for LEA BX,LIST in 80486 microprocessor
  - one clock for MOV BX,OFFSET LIST
- The MOV BX,OFFSET LIST instruction is actually assembled as a move immediate instruction and is more efficient.
- Why is LEA instruction available if OFFSET accomplishes the same task?
  - OFFSET only functions with simple operands such as LIST, not for an operand such as [DI], LIST [SI], e.g.,
  - LEA BX,[DI] → MOV BX, DI
  - LEA SI,[BX+DI]. This instruction adds BX to DI and stores the sum in the SI register. The sum generated by this instruction is a modulo-64K sum.

# LDS, LES, LFS, LGS, and LSS

- LEA instruction loads any 16-bit register with the offset address
  - determined by the addressing mode selected
- LDS and LES load far addresses from memory
  - load a 16-bit register with offset address retrieved from a memory location
  - then load either DS or ES with a segment address retrieved from memory
- Figure 4–17 illustrates an example LDS BX,[DI] instruction.

**Figure 4–17** The LDS BX,[DI] instruction loads register BX from addresses 11000H and 11001H and register DS from locations 11002H and 11003H. This instruction is shown at the point just before DS changes to 3000H and BX changes to 127AH.



## LDS, LES, LFS, LGS, and LSS


- This instruction transfers the 32-bit number, addressed by DI in the data segment, into the BX and DS registers.
- In 80386 and above, LFS, LGS, and LSS are added to the instruction set.
- Load any 16- or 32-bit register with an offset address, and the DS, ES, FS, GS, or SS segment register with a segment address.
  - instructions use any memory-addressing modes to access a 32-bit or 48-bit memory section that contain both segment and offset address

- LDS, LES, LFS, LGS, and LSS instructions obtain a new far address from memory.
  - offset address appears first, followed by the segment address
- This format is used for storing all 32-bit memory addresses.

Assembly Language	Operation
LEA AX,NUMB	Loads AX with the offset address of NUMB
LEA EAX, NUMB	Loads EAX with the offset address of NUMB
LDS DI,LIST	Loads DS and DI with the 32-bit contents of data segment memory location LIST
LDS EDI,LIST1	Loads the DS and EDI with the 48-bit contents of data segment memory location LIST1
LES BX,CAT	Loads ES and BX with the 32-bit contents of data segment memory location CAT
LFS DI,DATA1	Loads FS and DI with the 32-bit contents of data segment memory location DATA1
LGS SI,DATA5	Loads GS and SI with the 32-bit contents of data segment memory location DATA5
LSS SP,MEM	Loads SS and SP with the 32-bit contents of data segment memory location MEM

Load-effective address instructions

- A far address can be stored in memory by the assembler. The most useful of the load instructions is the LSS instruction.
- The following program shows an example of reactivating the old stack area by loading both SS and SP with the LSS instruction.



 CLI (disable interrupt) and STI (enable interrupt) instructions must be included to disable interrupts.

### 4-4 STRING DATA TRANSFERS

- Five string data transfer instructions: LODS, STOS, MOVS, INS, and OUTS.
- Each allows data transfers as a single byte, word, or doubleword and implicitly uses DI, SI, or both registers to address memory.
- String data transfer instructions execute efficiently because they automatically repeat and increment array indexes.
- Before the string instructions are presented, a repeat prefix, the operation of the D flag-bit (direction), DI, and SI must be understood as they apply to the string instructions.

Chapter 4

### DI and SI

- During execution of string instruction, memory accesses occur through DI and SI registers.
  - DI offset address accesses data in the extra segment for all string instructions that use it
  - SI offset address accesses data by default in the data segment
- Operating in 32-bit mode EDI and ESI registers are used in place of DI and SI.
  - this allows string using any memory location in the entire 4G-byte protected mode address space

# **The Direction Flag**

- The direction flag (D, located in the flag register) selects the auto-increment or the auto-decrement operation for the DI and SI registers during string operations.
  - used only with the string instructions
- The CLD instruction clears the D flag and the STD instruction sets it.
  - CLD instruction selects the auto-increment mode
  - STD instruction selects the auto-decrement mode

# **Using a Repeat Prefix**

- A string primitive instruction processes only a single memory value or pair of values. If you add a repeat prefix, the instruction repeats, using CX or ECX as a counter.
- The repeat prefix processes an entire array using a single instruction.
- The following repeat prefixes are used:

REP	Repeat while ECX > 0
REPZ, REPE	Repeat while the Zero flag is set and ECX > 0
REPNZ, REPNE	Repeat while the Zero flag is clear and ECX > 0

# **Example: Copy a String**


- In the following example, MOVSB moves 10 bytes from string1 to string2.
- ESI and EDI are automatically incremented when MOVSB repeats. This behavior is controlled by Direction flag.

```
cld ; clear direction flag
mov esi,OFFSET string1 ; ESI points to source
mov edi,OFFSET string2 ; EDI points to target
mov ecx,10 ; set counter to 10
rep movsb ; move 10 bytes
```

### **LODS**

- The LODSB, LODSW, and LODSD instructions load AL, AX, or EAX with data at segment offset address indexed by the SI register.
- A 1 is added to or subtracted from SI for a bytesized LODS
- A 2 is added or subtracted for a word-sized LODS.
- A 4 is added or subtracted for a doublewordsized LODS.
- Figure 4–18 shows the LODSW instruction.

**Figure 4–18** The operation of the LODSW instruction if DS=1000H, D=0. This instruction is shown after AX is loaded from memory, but before SI increments by 2.



### **STOS**

- The STOSB, STOSW, and STOSD instructions store AL, AX, or EAX at the extra segment memory location addressed by the DI register.
- STOSB (stores a byte) stores the byte in AL at the extra segment memory location addressed by DI.
- STOSW (stores a word) stores AX in the memory location addressed by DI.
- After the byte (AL), word (AX), or doubleword (EAX) is stored, contents of DI increment or decrement.

### STOS with a REP

- The repeat prefix (REP) is added to any string data transfer instruction except LODS.
  - REP prefix causes CX to decrement by 1 each time the string instruction executes; after CX decrements, the string instruction repeats
- If CX reaches a value of 0, the instruction terminates and the program continues.
- If CX is loaded with 100 and a REP STOSB instruction executes, the microprocessor automatically repeats the STOSB 100 times.

### STOS with a REP

- When used with the REP prefix, these instructions are useful for filling all elements of a string or array with a single value.
- For example, the following code initializes each byte in string1 to 0FFh.

```
.data
Count = 100
string1 BYTE Count DUP(?)
.code
                                 ; value to be stored
    al,0FFh
mov
mov edi, OFFSET string1
                                  EDI points to target
     ecx, Count
                                  character count
mov
cld
                                  direction = forward
                                  fill with contents of AL
      stosb
rep
```

### **MOVS**

- One of the more useful string data transfer instructions is MOVS, because it transfers data from one memory location to another.
- This is the only memory-to-memory transfer allowed in the 8086–Pentium 4 microprocessors.
- Transfers a byte, word, or doubleword a data segment addressed by SI to extra segment location addressed by DI.
- Only the source operand (SI), located in the data segment may be overridden so another segment may be used.
- The destination operand (DI) must always be located in the extra segment.

### Example, transferring two blocks of doubleword memory

#### C++ version of example

```
void TransferBlocks (int blockSize, int* blockA, int* blockB)
      for (int a = 0; a < blockSize; a++)
         *blockB = *blockA++:
          blockB++;
void TransferBlocks (int blockSize, int* blockA, int* blockB)
      asm{
                                        ; save registers
             push es
             push edi
             push esi
             push ds
                                        ;copy DS into ES
             gog
             mov esi, blockA
                                        ;address blockA
             mov edi, blockB
                                        ;address blockB
                                        ;load count
             mov ecx, blockSize
             rep movsd
                                        ; move data
             pop esi
                  edi
             gog
                                        ;restore registers
             pop
                  es
              inline assembler of example
```

### INS

- Transfers a byte, word, or doubleword of data from an I/O device into the extra segment memory location.
  - source operand (I/O address or I/O port) is contained in the DX register.
  - destination operand is a memory location addressed by the ES:DI, ES:EDI or the RDI.
- Useful for inputting a block of data from an external I/O device directly into the memory.
- One application transfers data from a disk drive to memory.
  - disk drives are often considered and interfaced as I/O devices in a computer system

- Three basic forms of the INS:
  - INSB inputs data from an 8-bit I/O device and stores it in a memory location indexed by DI.
  - INSW instruction inputs 16-bit I/O data and stores it in a word-sized memory location.
  - INSD instruction inputs a doubleword.
- These instructions can be repeated using the REP prefix
  - allows an entire block of input data to be stored in the memory from an I/O device

### various forms of the INS instruction

Assembly Language	Operation
INSB	ES:[DI] = [DX]; DI = DI $\pm$ 1 (byte transferred)
INSW	ES:[DI] = [DX]; DI = DI $\pm$ 2 (word transferred)
INSD	ES:[DI] = [DX]; DI = DI $\pm$ 4 (doubleword transferred)
INS LIST	ES:[DI] = [DX]; DI = DI $\pm$ 1 (if LIST is a byte)
INS DATA4	ES:[DI] = [DX]; DI = DI $\pm$ 2 (if DATA4 is a word)
INS DATA5	ES:[DI] = [DX]; DI = DI $\pm$ 4 (if DATA5 is a doubleword)

 Note that in the 64-bit mode, there is no 64-bit input, but the memory address is 64 bits and located in RDI for the INS instructions. • Example 4–9 shows a sequence of instructions that inputs 50 bytes of data from an I/O device whose address is 03ACH and stores the data in extra segment memory array LISTS.

#### **EXAMPLE 4-9**

```
;Using the REP INSB to input data to a memory array
0000 BF 0000 R
                        MOV DI,OFFSET LISTS
                                                ;address array
                                                ;address I/O
0003 BA 03AC
                        MOV DX, 3ACH
0006 FC
                                                 ; auto-increment
                        CLD
                                                 ;load counter
0007 B9 0032
                        MOV CX,50
000A F3/6C
                        REP INSB
                                                 ;input data
```

### **OUTS**

- Transfers a byte, word, or doubleword of data from the data segment memory location address to an I/O device.
  - source operand is a memory location addressed by the DS:SI, DS:ESI or the RSI registers.
  - destination operand (I/O address or I/O port) is contained in the DX register as with the INS instruction
- In the 64-bit mode for Pentium 4 and Core2, there is no 64-bit output
  - but the address in RSI is 64 bits wide

### various forms of the OUTS instruction

Assembly Language	Operation
OUTSB OUTSW OUTSD OUTS DATA7 OUTS DATA8 OUTS DATA9	[DX] = DS:[SI]; SI = SI $\pm$ 1 (byte transferred) [DX] = DS:[SI]; SI = SI $\pm$ 2 (word transferred) [DX] = DS:[SI]; SI = SI $\pm$ 4 (doubleword transferred) [DX] = DS:[SI]; SI = SI $\pm$ 1 (if DATA7 is a byte) [DX] = DS:[SI]; SI = SI $\pm$ 2 (if DATA8 is a word) [DX] = DS:[SI]; SI = SI $\pm$ 4 (if DATA9 is a doubleword)

 Note that in the 64-bit mode, there is no 64-bit output, but the memory address is 64 bits and located in RDI for the OUTS instructions.  Example 4–10 shows a short sequence of instructions that transfer data from a data segment memory array (ARRAY) to an I/O device at I/O address 3ACH.

#### **EXAMPLE 4–10**

```
;Using the REP OUTSB to output data from a memory array
0000 BE 0064 R
                        MOV SI, OFFSET ARRAY
                                                ;address array
                                                ;address I/O
0003 BA 03AC
                        MOV DX, 3ACH
0006 FC
                                                 ; auto-increment
                        CLD
0007 B9 0064
                        MOV CX,100
                                                 ;load counter
000A F3/6E
                        REP OUTSB
                                                 ;output data
```

# 4–5 MISCELLANEOUS DATA TRANSFER INSTRUCTIONS

 Used in programs, data transfer instructions detailed in this section are XCHG, LAHF, SAHF, XLAT, IN, OUT, BSWAP, MOVSX, MOVZX, and CMOV.

### **XCHG**

- Exchanges contents of a register with any other register or memory location.
  - cannot exchange segment registers or memory-to-memory data
- Exchanges are byte-, word-, or doubleword and use any addressing mode except immediate addressing.
- XCHG using the 16-bit AX register with another 16-bit register, is most efficient exchange. This instruction occupies 1 byte of memory.

### various forms of the XCHG instruction

Assembly Language	Operation
XCHG AL,CL XCHG CX,BP XCHG EDX,ESI XCHG AL,DATA2 XCHG RBX,RCX	Exchanges the contents of AL with CL Exchanges the contents of CX with BP Exchanges the contents of EDX with ESI Exchanges the contents of AL with data segment memory location DATA2 Exchange the contents of RBX with RCX (64-bit mode)

- When using a memory-addressing mode and the assembler, it doesn't matter which operand addresses memory.
- The XCHG AL,[DI] instruction is identical to the XCHG [DI],AL instruction.
- XCHG is useful for implementing semaphores for process synchronization.

### acquire the spinlock

```
; lock variable. 1 = locked, 0 = unlocked.
locked dd
; Set the EAX register to 1.
spin_lock:
          eax, 1
   mov
; Atomically swap the EAX with the lock.
   xchg eax, [locked]
; Test EAX with itself.
        eax, eax
   test
; If EAX is 0, we just locked it.
; Otherwise, acquire the lock.
       spin_lock
  jnz
   ret
```

### release the spinlock

```
; Set the EAX register to 0.

spin_unlock:
    mov eax, 0

; Atomically swap the EAX register
; with the lock variable.
    xchg eax, [locked]
```

### **LAHF** and **SAHF**

- LAHF instruction transfers the lower 8 bits of the EFLAGS register into the AH register.
- AH := EFLAGS (SF:ZF:0:AF:0:PF:1:CF)
  - Load sign flag (SF), zero flag (ZF), auxiliary carry flag (AF), parity flag (PF), and carry flag (CF).
  - Set the reserved bits 1, 3, and 5 of the EFLAGS to 1, 0, and 0, respectively, in the AH register.
- The LAHF instruction is available in 64-bit mode if CPUID.80000001H:ECX.LAHF-SAHF[bit 0] = 1.

### **LAHF** and **SAHF**

- SAHF instruction transfers the SF, ZF, AF, PF, and CF flags of the EFLAGS register with values from the corresponding bits in the AH register (bits 7, 6, 4, 2, and 0, respectively).
- SAHF instruction ignores bits 1, 3, and 5 of register AH; it sets those bits in the EFLAGS register to 1, 0, and 0, respectively.
- The SAHF instruction is available in 64-bit mode if CPUID.80000001H:ECX.LAHF-SAHF[bit 0] = 1.

### **XLAT**

- The XLAT (Table Look-up Translation)
  instruction uses the unsigned integer in AL
  register as an offset into a table and copies the
  contents of the table at that location to AL
  register.
- The instruction uses seg:[BX] as the base address of the table. The value of seg defaults to the DS segment, but may be overridden by a segment prefix.

### **XLAT**


- XLAT is often used to translate data from one format (such as ASCII) to another (such as EBCDIC).
- This instruction writes AL without changing EAX[31:8].
- The workflow of XLAT instruction:
  - first adds the contents of AL to BX to form a memory address within the data segment
  - then copies the contents of this address into AL

 Suppose that a 7-segment LED display lookup table is stored in memory at address TABLE. The XLAT instruction then uses the lookup table to translate the BCD number in AL to a 7-segment code in AL.

```
TABLE DB 3FH, 06H, 5BH, 4FH ;lookup table
DB 66H, 6DH, 7DH, 27H
DB 7FH, 6FH

LOOK: MOV AL,5 ;load AL with 5 (a test number)
MOV BX,OFFSET TABLE ;address lookup table
XLAT ;convert
```


**Figure 4–19** shows the operation of aforementioned example program if TABLE = 1000H, DS = 1000H, and the initial value of AL = 05H (BCD). After the translation, AL = 6DH.



## Input ports and output ports

- External devices such as screen, display, keyboard, mouse, hard disk, and network are connected to the data bus via input ports and output ports.
- Each input or output port has a unique address just like each byte-cell in the memory has a unique address.


# Principle of output port



- An output port contains a comparator that compares the fixed address with the value on the address bus.
- A latch stores the value from the data bus if the address is equal to the port address and there is a write signal on the control bus.

Chapter 4

# Principle of input port



- Each of the inputs from the external device goes through a three-state buffer to the data bus.
- The three-state buffer is enabled when the address bus is equal to the fixed address of the input port and there is a read signal on the control bus. Chapter 4

104


### **IN and OUT**

- IN & OUT instructions perform I/O operations.
- Contents of AL, AX, or EAX are transferred only between I/O device and microprocessor.
  - an IN instruction transfers data from an external I/O device into AL, AX, or EAX
  - an OUT transfers data from AL, AX, or EAX to an external I/O device
- Only the 80386 and above contain EAX

- Often, instructions are stored in ROM.
  - a fixed-port instruction stored in ROM has its port number permanently fixed because of the nature of read-only memory
- A fixed-port address stored in RAM can be modified, but such a modification does not conform to good programming practices.
- The port address appears on the address bus during an I/O operation.

- Two forms of I/O device (port) addressing:
- Fixed-port addressing allows data transfer between AL, AX, or EAX using an 8-bit I/O port address.
  - port number is a byte-immediate value (00h to FFh) following the instruction's opcode
- Variable-port addressing allows data transfers between AL, AX, or EAX and a 16-bit port address.
  - the I/O port number is stored in register DX
     (0000h to FFFFh), which can be changed (varied) during the execution of a program.

**Figure 4–20** illustrates the execution of the OUT 19H,AX instruction, which transfers the contents of AX to I/O port 19H.



 The source register used in OUT instruction determines the size of the port (8, 16, or 32 bits).

#### In and OUT instructions

Assembly Language	Operation
IN AL,p8	8 bits are input to AL from I/O port p8
IN AX,p8	16 bits are input to AX from I/O port p8
IN EAX,p8	32 bits are input to EAX from I/O port p8
IN AL,DX	8 bits are input to AL from I/O port DX
IN AX,DX	16 bits are input to AX from I/O port DX
IN EAX,DX	32 bits are input to EAX from I/O port DX
OUT p8,AL	8 bits are output to I/O port p8 from AL
OUT p8,AX	16 bits are output to I/O port p8 from AX
OUT p8,EAX	32 bits are output to I/O port p8 from EAX
OUT DX,AL	8 bits are output to I/O port DX from AL
OUT DX,AX	16 bits are output to I/O port DX from AX
OUT DX,EAX	32 bits are output to I/O port DX from EAX

Note: p8 = an 8-bit I/O port number (0000H to 00FFH) and DX = the 16-bit I/O port number (0000H to FFFFH) held in register DX.

- A program that clicks the speaker in the computer appears in following example.
- The speaker (in DOS only) is controlled by accessing I/O port 61H. If the rightmost 2 bits of this port are set (11) and then cleared (00), a click is heard on the speaker.

```
.MODEL TINY
                       ;select tiny model
. CODE
                       ;start code segment
.STARTUP
                       ;start program
                       ;read I/O port 61H
       IN AL,61H
                       ;set rightmost two bits
       OR AL, 3
       OUT 61H, AL ; speaker on
                       ;load delay count
       MOV CX,8000H
L1:
                       ;time delay
       LOOP L1
                       ;speaker off
       IN AL,61H
       AND AL, OFCH
       OUT 61H, AL
.EXIT
END
```

## **MOVSX** and **MOVZX**


- The MOVSX (move and sign-extend) and MOVZX (move and zero-extend) instructions are found in the 80386— Pentium 4 instruction sets. For example
  - if an 8-bit 84H is sign-extended into a 16-bit number, it becomes FF84H.
  - if an 8-bit 34H is zero-extended into a 16-bit number, it becomes 0034H.

# **MOVSX** and **MOVZX**

Assembly Language	Operation
MOVSX CX,BL	Sign-extends BL into CX
MOVSX ECX,AX	Sign-extends AX into ECX
MOVSX BX,DATA1	Sign-extends the byte at DATA1 into BX
MOVSX EAX,[EDI]	Sign-extends the word at the data segment memory location addressed by EDI into EAX
MOVSX RAX,[RDI]	Sign-extends the doubleword at address RDI into RAX (64-bit mode)
MOVZX DX,AL	Zero-extends AL into DX
MOVZX EBP,DI	Zero-extends DI into EBP
MOVZX DX,DATA2	Zero-extends the byte at DATA2 into DX
MOVZX EAX, DATA3	Zero-extends the word at DATA3 into EAX
MOVZX RBX,ECX	Zero-extends ECX into RBX

- The BSWAP (byte swap) instruction reverses the byte order in a 32-bit or 64-bit register operand.
- The BSWAP instruction is used to convert data between the big and little endian forms.
- Takes the contents of any 32-bit register and swaps the first byte with the fourth, and the second with the third.

 For example, the BSWAP EAX instruction with EAX = 12345678H swaps bytes in EAX, resulting in EAX = 78563412H.



 The proper byte swapping without using BSWAP is the following:

> xchg ah, al ror eax, 16 xchg ah, al

; rotate right of eax

- BSWAP is available only in 80486— Pentium 4 microprocessors.
- In 64-bit operation for a quadword, bits 7:0 are exchanged with bits 63:56, bits 15:8 with bits 55:48, bits 23:16 with bits 47:40, and bits 31:24 with bits 39:32.

- The result of applying the BSWAP instruction to a 16-bit register is undefined.
- To swap the bytes of a 16-bit register, use the XCHG instruction.
- For example, to swap the bytes of AX, use XCHG AL, AH.

## **CMOV**

#### conditionally

- Many variations of the CMOV instruction.
  - these move the data only if the condition is true
- CMOVZ instruction moves data only if the result from some prior instruction was a zero.
  - destination is limited to only a 16- or 32-bit register,
     but the source can be a 16- or 32-bit register or
     memory location
- Because this is a new instruction, you cannot use it with the assembler unless the .686 switch is added to the program

### the conditional move instructions

Assembly Language	Flag(s) Tested	(s) Tested Operation	
CMOVB	C = 1	Move if below	
CMOVAE	C = 0	Move if above or equal	
CMOVBE	Z = 1  or  C = 1	C = 1 Move if below or equal	
CMOVA	Z = 0 and $C = 0$	Move of above	
CMOVE or CMOVZ	Z = 1	Move if equal or move if zero	
CMOVNE or CMOVNZ	Z = 0	Move if not equal or move if not zero	
CMOVL	S!= O	Move if less than	
CMOVLE	Z = 1  or  S! = O	Move if less than or equal	
CMOVG	Z = 0 and $S = O$	Move if greater than	
CMOVGE	S = O	Move if greater than or equal	
CMOVS	S = 1	Move if sign (negative)	
CMOVNS	S = 0	Move if no sign (positive)	
CMOVC	C = 1	Move if carry	
CMOVNC	C = 0	Move if no carry	
CMOVO	O = 1	Move if overflow	
CMOVNO	O = 0	Move if no overflow	
CMOVP or CMOVPE	P = 1	Move if parity or move if parity even	
CMOVNP or CMOVPO	P = 0	Move if no parity or move if parity odd	

- The purpose of CMOV is to avoid a branch.
- When a CPU sees the branch (e.g., JNE) it will take a guess about whether the branch will be taken or not taken, and then start speculatively executing instructions.

cmp eax, ebx
jne skip
mov ecx, edx
skip: xor ebx, ebx
.....

- If the guess is wrong there's a performance penalty, because the CPU has to discard any speculatively executed work and then start fetching and executing the correct path.
- For a conditional move (e.g. CMOVE eax,edx)
  the CPU doesn't need to guess which code will
  be executed and the cost of a mispredicted
  branch is avoided.

# 4–6 SEGMENT OVERRIDE PREFIX

- May be added to almost any instruction in any memory-addressing mode
  - allows the programmer to deviate from the default segment
  - only instructions that cannot be prefixed are jump and call instructions using the code segment register for address generation
  - Additional byte appended to the front of an instruction to select alternate segment register

## instructions that include segments

Assembly Language	Segment Accessed	Default Segment
MOV AX,DS:[BP]	Data	Stack
MOV AX,ES:[BP]	Extra	Stack
MOV AX,SS:[DI]	Stack	Data
MOV AX,CS:LIST	Code	Data
MOV ES:[SI],AX	Extra	Data
LODS ES:DATA1	Extra	Data
MOV EAX,FS:DATA2	FS	Data
MOV GS:[ECX],BL	GS	Data

# 4-7 ASSEMBLER DETAIL

- The assembler can be used two ways:
  - with models unique to a particular assembler
  - with full-segment definitions that allow complete control over the assembly process and are universal to all assemblers
- This section of the text presents both methods and explains how to organize a program's memory space by using the assembler.
- It also explains the purpose and use of some of the more important directives used with this assembler.

## **Directives**

- Indicate how an operand or section of a program is to be processed by the assembler.
  - some generate and store information in the memory; others do not
- The DB (define byte) directive stores bytes of data in the memory.
- BYTE PTR indicates the size of the data referenced by a pointer or index register.
- Complex sections of assembly code are still written using MASM.

Full reference: https://docs.microsoft.com/en-us/cpp/assembler/masm/directives-reference?view=vs-2019

# Storing Data in a Memory Segment

- DB (define byte), DW (define word), and DD (define doubleword) are most often used with MASM to define and store memory data.
- If a numeric coprocessor executes software in the system, the DQ (define quadword) and DT (define ten bytes) directives are also common.
- These directives label a memory location with a symbolic name and indicate its size.

- Memory is reserved for use by using a (?) as an operand for a DB, DW, or DD directive. The assembler sets aside a location and does not initialize it to any specific value.
- The DUP directive allows multiple initializations to the same value. e.g., 100 DUP(6) reserves 100 bytes of 6.
- The ALIGN directive aligns the next data element or instruction on an address that is a multiple of its parameter. The parameter must be a power of 2 (e.g., 1, 2, 4, 8) that is less than or equal to the segment alignment.

```
LIST SEG
              SEGMENT
DATA1 DB
                             ; define bytes
          1,2,3
                             ; hexadecimal
      DB
          45H
                            ; define doubleword
DATA3 DD 300H
      DD 2.123
                            ;real
      DD 3.34E+12
                            ;real
LISTA DB ?
                            ;reserve 1 byte
LISTB DB 10 DUP(?)
                            ; reserve 10 bytes
      ALIGN 2
                            ; set word boundary
LISTC DW 100H DUP(0)
                            reserve 100H words
LISTD DD 22 DUP(?)
                            ;reserve 22 doublewords
```

- It is important that word-sized data are placed at word boundaries and doubleword-sized data are placed at doubleword boundaries.
  - if not, the microprocessor spends additional time accessing these data types

# ASSUME, EQU, and ORG

- Equate directive (EQU) equates a numeric,
   ASCII, or label to another label.
  - equates make a program clearer and simplify debugging

#### **EXAMPLE 4-14**

```
;Using equate directive
;
= 000A TEN EQU 10
= 0009 NINE EQU 9
0000 B0 0A MOV AL, TEN
0002 04 09 ADD AL, NINE
```

# ASSUME, EQU, and ORG

- The assembler can only assign either a byte, word, or doubleword address to a label.
- To assign a byte label to a word, use THIS directive.
- The THIS directive always appears as THIS BYTE, THIS WORD, THIS DWORD, or THIS QWORD.

- The ORG (origin) statement can change the starting offset address of the data in the data segment or code in the code segment.
- At times, the origin of data or the code must be assigned to an absolute offset address with the ORG statement. For example, Boot Sector Entry must be assigned to 07c00h.
- ASSUME tells the assembler what names have been chosen for the code, data, extra, and stack segments.


```
;Using the THIS and ORG directives
DATA SEG
              SEGMENT
                         use ORG directive to set the location
       ORG
              300H
              THIS BYTE ← use THIS directive to assign a word
DATA1
       EQU
DATA2
       DW
                              address label to a byte label
DATA SEG
              ENDS
                                    use SEGMENT directive to
                                    define a program segment
CODE SEG
       ASSUME CS:CODE SEG, DS:DATA SEG
       MOV BL, DATA1
       MOV AX, DATA2
       MOV BH, DATA1+1
CODE SEG
              ENDS
```

## PROC and ENDP

 The PROC and ENDP directives indicate the start and end of a procedure (subroutine) that must be assigned a name.

name PROC [near/far]
statements

ret
name ENDP



**Nested Procedure Calls** 

- The PROC directive, which indicates the start of a procedure, must also be followed with a NEAR or FAR (valid only in 32-bit system).
  - A NEAR procedure is one that resides in the same code segment as the program, often considered to be *local*
  - A FAR procedure may reside at any location in the memory system, considered *global*
- Local defines a procedure that is only used by the current program.
- The term global denotes a procedure that can be used by any program.

 A procedure named SumOf calculates the sum of three 32-bit integers by passing register arguments to the procedure.

```
SumOf PROC

add eax,ebx

add eax,ecx

ret

SumOf ENDP
```

- Three integers are assigned to EAX, EBX, and ECX.
- The procedure returns the sum in EAX.

```
.data
theSum DWORD ?
.code
main PROC

mov eax,10000h
mov ebx,20000h
mov ecx,30000h
call Sumof
mov theSum,eax
```

Before calling SumOf, values are assigned to EAX, EBX, and ECX.

```
; argument
; argument
; argument
; EAX = (EAX + EBX + ECX)
; save the sum
```

After the CALL, the sum in EAX are copied to "theSum" variable.

## MACRO and ENDM

- MACRO and ENDM directives indicate a macro (a named block of assembly language statements).
- When you invoke a macro procedure, a copy of its code is inserted directly into the program at the location where it was invoked.
- This type of automatic code insertion is also known as inline expansion.

name MACRO [para1,para2,...]

statements

**ENDM** 

 A macro named mPutchar receives a input and displays it on the console by calling WriteChar.

```
mPutchar MACRO char

push eax

mov al, char ; passing arguments to the procedure

call WriteChar

pop eax

ENDM
```

- The following statement invokes mPutchar and passes it the letter A: mPutchar 'A'.
- The assembler's preprocessor expands the statement into the following code:

```
mPutchar 'A' mov al,'A'
inline call WriteChar
expansion pop eax
```

 A macro can also be used in data segment. For example, define a macro for GDT Descriptor.

```
Descriptor MACRO
                              Base, Limit, Attr
   dw Limit & 0FFFFh
                             ; Limit 1 (2 bytes)
                             ; Base 1 (2 bytes)
   dw Base & 0FFFFh
   db (Base >> 16) & 0FFh ; Base 2 (1 byte)
   dw ((Limit >> 8) & 0F00h) | (Attr & 0F0FFh); Attr 1 + Limit 2 + Attr 2
   db (Base >> 24) & 0FFh
                             ; Base 3 (1 byte)
ENDM; total 8 bytes
                                                  Allocation of GDT
GDT SEGMENT
                                                     Descriptor
      Null_desc: Descriptor
                            0, 0, 0
   Normal_desc: Descriptor 0, 0ffffh, DA_DRW
```

# **Memory Organization**

- Memory organization defines the memoryrelated attributes for the software, including size of code, data pointer, instructions encoding, segment combine type, and segment loading order, etc.
- The assembler uses two basic formats to define memory organization:
  - one method uses full-segment definitions
  - the other method uses models (.MODEL)

# **Memory Organization**

- The full-segment definitions offer better control over the assembly language task and are recommended for complex programs.
- There are many memory models available to the MASM assembler, ranging from tiny to huge, which control how the segment registers are used and the default size of pointers.
- The .MODEL directive is used to determine the size of code and data pointers.


# Full-Segment Definitions

 Full-segment definitions use SEGMENT, ENDS and ASSUME directives to define segment and inform assembler and linker.

```
name SEGMENT [readonly] [align] [combine] [use] ['class']
                           combining mode of different modules
      statements
                           use 16-bit address or 32-bit
name ENDS
 cseg SEGMENT readonly word use32 'code'
        mov ax, 10
        inc ax
        ret
```

# Controlling Segments with the ASSUME Directive

- The segment directive doesn't tell what type of segment. The assume directive provides this information to the assembler.
- When the assembler encounters an instruction (e.g., mov var,0), the first thing it does is to determine var's segment.
- If var is not declared in one of the currently assumed segments, then the assembler generates an error claiming that the program cannot access that variable.



# Models (32-bit MASM only)


- Memory models are unique to MASM.
- There are six memory models for the real mode in MASM, namely tiny, small, compact, medium, large, and huge.
- One model (flat) is available for the protected model.
- Special directives such as @DATA are used to identify various segments.
- .MODEL is not used in MASM for x64.

# Memory models

Model	Data	Code	Definition	
Tiny	near		CS=DS=SS, a single segment, containing both code and data.	
Small	near	near	DS=SS, one code segment and one data segment	
Medium	near	far	DS=SS, multiple code segments and a single data segment	
Compact	far	near	single code segment, multiple data segments	
Large	far	far	multiple code and data segments	
Huge	huge	far	multiple code and data segments; single array may be larger than a single segment (>64 KB)	

 Choose the smallest memory model available that can contain the data and code, since near references operate more efficiently than far references. Example 4–18 illustrates how the .MODEL statement defines the parameters of a short program that copies the contents of a 100-byte block of memory (LISTA) into a second 100-byte block of memory (LISTB).

#### EXAMPLE 4-18



## x86-64 Code Models

- Various programs differ in addressing (absolute versus position independent), code size, data size and address range.
- Code models define constraints for compiler to generate better code.
- The AMD provides seven different code models for programs running in 64-bit mode.
  - Small code model, Kernel code model,
  - Medium code model, Large code model
  - Small/Medium/Large position independent code model (PIC)

## x86-64 Code Models

- The small code model is the default code model, which uses the fast RIP-relative addressing modes.
- And the program and its statically defined symbols must be within 4GB of each other.

Understanding the x64 code models: https://eli.thegreenplace.net/2012/01/03/understanding-the-x64-code-models

# **Assignment**

4-2, 3, 12, 13, 16, 21, 25-27, 31, 36, 38, 40, 43, 49-51, 56, 60, 62