## 安装MQTT库

进入REPL, 执行:

```
import upip
upip.install('micropython-umqtt.simple')
```

这样umqtt.simple这个包就安装好了。

### 测试代码

```
from umqtt.simple import MQTTClient
2
    #...
 3
   client=MQTTClient("WX1","192.168.1.3")
   TOPIC = b"WX1"
5
 6
7
   while True:
8
      t = temp+','+hum+','+pres
9
10
      client.connect()
11
      client.publish(TOPIC, t)
12
      client.disconnect()
13
      print('POSTED: '+t)
14
      sleep(10)
```

### 订阅

在.3上执行:

mosquitto\_sub -t WX1

就能收到发布的内容:

22.31C,34.18%,1022.62hPa

#### 参考

http://www.1zlab.com/wiki/micropython-esp32/mqtt/

# 在PRi上安装mqtt服务器

```
sudo apt install mosquitto

sudo apt install mosquitto-clients

mosquitto_sub -t /public

mosquitto_pub -t /public -m "hello"

sudo systemctl enable mosquitto.service
```

服务器工作在默认的1883端口。