Specific electromagnetic wave therapy device

User manual

Catalog

Working principle……..……1

Composition and classification ……1

Application……..1

Contraindications ……..…2

Work conditions ……..……..……2

Storage conditions……..……..…2

Installation……..……...…2

User instruction……...…3

Attention……..5

Performance……..……5

Maitenance……..……6

★Working principle

The TDP produced by our company uses the specific electromagnetic wave radiation effect to heat the heating element (heater) and convert the thermal energy into infrared radiation energy. The radiation mainly composed of infrared spectrum is mainly distributed in the range of 2μm to 25μm electromagnetic waves in the μm wavelength range. It can produce biological effects on the human body, thereby improving various enzymes in the body to achieve repair and dredge microcirculation channels, improve blood circulation, regulate neurosecretory systems, increas immunity and achieve the goal of restoring good health.

Table 1 Model List

Model

Single/double head power timing mode desktop/vertical basic function

OH-LJ

Single head 250 VA mechanical timing vertical mechanical timing

Working style: continuous work

Timing: 0 to 60 min, Changtong

★Composition

The treatment device is mainly composed of a treatment head (including a radiant panel, a heating device and a protective cover), a telescopic arm, and a control box, the column (not applicable to the table top) and the base (the vertical base with moving casters).

★Application

This product is suitable for adjuvant treatment of diseases , such as: soft tissue injury, lumbar muscle strain, sciatica, frozen shoulder, rheumatoid arthritis, diarrhea in children etc.

★Contraindications

High fever, open tuberculosis, severe arteriosclerosis, hemorrhagic disease, malignant tumors, and skin allergies are prohibited.

Hypertensive patients should not illuminate their head or follow a doctor's advice.

★Work conditions

Power supply: a.c.220 V Frequency: 50 Hz

Rated power: 250 VA (single head), 500 VA (double head)

Temperature: + 5°C ~ + 40°C; relative humidity: ≤80%; atmospheric pressure: 700 hpa ~ 1060 hpa

★Storage conditions

The packaged therapeutic device should be stored at a temperature of -40 ° C to +55 ° C, a relative humidity of no more than 90%, and an atmospheric pressure of 700.

hPa ~ 1060 hPa, no corrosive gas and well ventilated room.

★Installation

1. After fitting the upper joint A of the treatment head with the hole B on the arm, gently screw the screw C until it stops (do not use too much force, so as not to screw the screws).

2. After fitting the upper threaded part D of the large column 3 to the hole E on the leg 4, screw it directly into the leg and tighten it.

3. After connecting the upper part of the therapeutic device 5 to the lower 6 poles of the TDP, gently screw the screw G until it stops.

4, adjustment:

a. Loosen the screw C to adjust the position of the lamp head;

b. Loosen the screw G. The surface can be rotated 360 degrees to adjust the upper part;

c. Loosen the nut H Lift the pole 6, adjust the height of the lamp.

After installed, therapeutic device control box can be rotated flexibly and smoothly at 360°.

★User instruction

Assemble the therapy device according to the installation procedure and adjust the treatment head to the desired position and angle. The treatment head rotates horizontally around the arm

The angle is not less than 270°, the vertical rotation angle is not less than 90°, and the treatment head of the vertical therapeutic device (face down) is height-adjusted from the ground.The range of the section is from 380mm to 1100mm.

Ⅰ. Mechanical timing

1. Check that the power socket is grounded reliably before use. This equipment must not be used on a power outlet that is not equipped with a protective ground.

In case of electric shock hazard.

2. Connect the power supply, plug the therapeutic device power plug into the rated power socket, the power indicator light is green, adjust the timer button, the work indicator yellow light is on, and the standby device is preheated for 10 to 15 minutes to perform irradiation treatment. Mechanical timing range 0min~60min, the timing accuracy error is not more than ±10%.

3. Irradiation site:

Exposure to the area of the lesion or related acupoints, direct exposure. Generally only one machine is used, or several machines can be used to illuminate differently at the same time part.

4. Irradiation distance:

The skin at the irradiation site is 20 to 30 cm away from the radiant panel, and the surface temperature of the skin is kept at about 40 °C or the patient feels comfortable.

5. Irradiation time:

Each irradiation is 30 to 60 minutes, 1 to 2 times a day, 7 to 10 days is a course of treatment, and the treatment interval is about three days. If the condition needs to be continuous, long-term exposure, and long-term health care is avalaible.

II．Electronic timing therapy device

1, function description

1) Function keys: “Timed min” button, “Clear” button, “Start/Pause” button;

2) Display mode: four digit display; power indicator: green; work indicator: yellow;

3) Working voltage (input/out): a.c.220V, frequency: 50Hz;

4) Working mode: a) timing; b) always-on;

5) Timing time setting range: 00:00～95:00 minutes (5 minutes is the minimum adjustment unit), which is adjusted by ″Time″ button;

The timing accuracy error is not more than ±10%;

6) Timing display mode: display by counting down mode;

7) With the accumulated timing function, the accumulated working time can be viewed, and the initial value of the accumulated time is 0 (hours). Cumulative time exceed 1000 (hours), the beep (10 seconds) prompts the replacement of the new radiant panel, and the accumulated time is automatically reset to zero;

8) When the time is up, the buzzer prompts (10 seconds) to complete the work, and the indicator light is off;

9) There is a "power" master switch.

2、Operation method

1）Check whether the power socket is grounded reliably before use. This equipment must not be used on a power outlet that is not equipped with a protective ground.

In case of electric shock hazard.

2）Turn on the power, start the “power” main switch, the “power-on indication” green light is on, and the number displayed on the LCD screen is accumulated working time. Unit: hour.

3）Press the “Start/Pause” button, the “Working Instructions” yellow light is on, and the working status is always on.

4）Press the “clear” button, the display shows: 00:00, and the working time is determined by pressing the “timing” button (minimum adjustment unit is 5 minutes), if the time is up to 45:00 (minutes: seconds), press the “Start/Pause” button again to realize the countdown work. At this moment , pressing “Start/pause” again to pause the countdown work. Re-adjust the timing by pressing the “clear” button and the “timing” button.

5）The irradiation site, the irradiation distance, and the irradiation time are the same as the mechanical timing.

★Attention

1. When using for the first time or for a long time, the treatment head may start to take off (smoke). This is caused by the insulation cotton’s daily moisture absorption, it will disappear after a period of preheating.

2. Irradiation of the eye must be carried out under the guidance of a doctor.

5. The site to be irradiated must be completely exposed, otherwise the effect will be affected. For the use on babies, skin temperature is reduced.

★Performance

The energy generated by the radiant panel of the therapy device should be distributed mainly in the wavelength range of 2 μm to 25 μm.

The temperature error on the heater surface is not more than ±10% of the nominal value (270 °C).

The heater surface temperature unevenness does not exceed 20%.

The thermal response time should not exceed 20 min.

The therapeutic device is equipped with an electronic timer with a timing range of 0 min to 95 min and a mechanical timer timing range of 0 min~60min. When the scheduled working time is reached, the heater stops working immediately and emits a sound or light indication. The timer is accurate and the error does not exceed ±10%.

★Maitenance

1. The working life of the therapeutic device is 2000h. When the machine is not working normally, please check if the fuse is damaged first. If it is damaged, please contact the technician and replace the spare parts (when replacing, please disconnect the power supply, open the control box (internal fuse) or open the external fuse holder, remove the damaged fuse and replace it with the same type and size one.

2. The radiant panel gradually turns dark red (about two years later), indicating that the radiant panel needs to be replaced. Then you should contact with the technician from the contributing company and purchase the same size and the same type of radiant panels for replacement. The use of other parts or materials will reduce the minimum safety.