1. 安装openssh

win10安装openssh,让cmd命令行支持ssh以远程登录树莓派

下载地址

	nSSH 8.5p1-1 installer for both x86 a as missing last time) so I hope it pro			
service to be ur	ssword that is generated nable to start - you MUST	REPLACE THAT	ΓPASSWORD W	TITH SOMETHING T
MEETS THE CON replaced in all o			. I I alikiy, tilat į	password snould be
	Windows x86		Windows x64	password snould be
replaced in all o	Windows x86	be lazy :-)	Windows x64	
version	Windows x86	setupssh-8.5pi	Windows x64 1-1.exe HEW 96d5e2do6be26c52cbf; cygwin_source.64.85p	7 d9 51-1.zip

2. ssh登录树莓派

使用ssh登录树莓派,需要获得树莓派的IP地址。win10打开终端,输入命令远程登录树莓派:

ssh pi@树莓派ip

默认密码为 raspberry ,输入密码登录树莓派:

```
Microsoft Windows [版本 10.0.19041.985]

**Co. Wicrosoft Corporation. 保留所有权利。

**Ac. Windows Corporation. Relation of Corporation of Cor
```

2.1 首次登录

登录树莓派需要获得树莓派IP地址,树莓派联网有两种方式:

- 有线: 使用网线连接。
- 无线: WiFi

树莓派连上网络之后,可以在路由器后台管理界面查到树莓派的IP地址。

在没有网线和显示器的情况下,这里提供一种简单的方式供使用者第一次登录树莓派:树莓派里预置了一条WiFi连接信息,如下所示:

```
network={
    ssid="wifi"
    psk="25802580"
}
```

ssid 为WiF名称, psk 为Wif密码,首次登录树莓派时可以用手机开启热点,并将热点名字改为"wifi",密码改为"25802580",树莓派开机后会自动连上手机热点,然后在手机里面热点连接设备信息里面可以看到树莓派IP,接下来使用上面介绍的方法登录树莓派。

2.2 配置WiFi信息

第一次成功登录树莓派之后,需要配置WiFi信息,供树莓派登录时自动连接。树莓派WiFi配置文件为 /etc/wpa_supplicant/wpa_supplicant.conf ,打开这个文件,在里面添加WiFi信息,树莓派开机时会自动连上。添加WiFi信息的格式:

```
network={
    ssid="wifi名字"
    psk="wifi密码"
}
```

预置的wifi信息作用很大,请不要删除!经过实验,5GHz频段的WiFi无法连接,配置WiFi信息时请填写2.4G频段的

2.3 开机推送IP地址

树莓派连上网之后,可以在路由器后台管理界面查看IP地址。也可以固定IP地址,但是固定IP地址会有连接冲突的风险,导致树莓派联网失败。这里配置了开机推送IP地址的功能,推送方式为免费的邮件推送。

使用方法:在树莓派登录成功之后,打开文件 /home/pi/start/start.py ,将56行代码中的邮箱改成自己的:

```
if __name__ == '__main__':

# LCD.turn_light(0)

print("正在开机...")

time.sleep(15)

smtp('2251513837@qq.com',"IP:" + str(get_host_ip()))

LCD.clear_lcd()

LCD.print_lcd(3, 0, 'WELCOME!!!')

LCD.print_lcd(0, 0, 'Raspberry Pi 3B')

time.sleep(3)
```

这样再树莓派开机并成功连上网络之后,会给设置的邮箱推送树莓派IP地址,效果如下:



树莓派开机需要一定时间才能连上网络,为了避免在未连接上网络时就执行了邮件推送程序,程序里设置了15s的延迟,树莓派上电15s之后才能收到邮件信息,请耐心等待。

3. 云平台系统运行


```
assets
       — button.css
       └─ style.css
   — images
       ├─ admin.svg
       ├─ bg1.png
       - bg.png
       ├─ bnt.png
       — close.svg
       ├─ login_bg.jpg
       ├─ point1.svg
       — point2.svg
       ├─ point.svg
       └─ school_logo.png
       — echarts.min.js
       ├─ jquery.min.js
       ├─ jsmpg.js
       - run.js
       └─ vue.js
  - common
   ├─ Config.py
   ├─ __init__.py
   — LCD.py
   ├─ Notice.py
   - __pycache__
      — Config.cpython-37.pyc
       ____init___.cpython-37.pyc
       ─ Notice.cpython-37.pyc
      └─ User.cpython-37.pyc
   L— User.py
 - controller
   — data.py
   — device.py
   ├─ __init__.py
   L___ pycache___
       — data.cpython-37.pyc
       — device.cpython-37.pyc
       ____init__.cpython-37.pyc
— main.py
 — model
  ├─ DB.py
   ├─ __init__.py
```

项目根目录下有一启动脚本 run.sh , 启动云平台系统只需执行启动脚本即可,执行以下命令:

```
./run.sh
```

```
pi@raspberrypi: "/BSproject $ ./run. sh
kill: (2836): No such process
Initializing camera
Initializing broadcast server on port 8084
Initializing broadcast thread
Spawning background conversion process
Starting recording
Starting websockets thread
Starting HTTP server thread
Starting broadcast thread
Starting broadcast thread
```

没有报错,说明系统正常运行。使用Chrome或新版Edge浏览器,输入地址 树莓派ip:5000 打开可看到效果:



管理员用户名: admin 密码: 123456