faultDetection

ssh root@192.168.123.111

```
onl
```

```
cd bf-sde-9.2.0
source set_sde.bash
./p4_build.sh ~/port/solution/p4src/port2.p4
./run_switchd.sh -p port2

ucli
pm
port-add -/- 4oG NONE
port-enb -/-
show
exit

bfrt_python
bfrt
port2.pipe.Ingress.forward.add_with_l3_switch(ingress_port=44,port=60)
```

```
bf-sde.pm> port-del -/-
portbf-sde.pm> port-add -/- 100G RS
bf-sde.pm> port-enb -/-
bf-sde.pm> show
```