



Android R&S Environment Building Guide

0.2

AMLOGIC, Inc.

2518 Mission College Blvd
Santa Clara, CA 95054
U.S.A.
www.amlogic.com

AMLOGIC reserves the right to change any information described herein at any time without notice.
AMLOGIC assumes no responsibility or liability from use of such information.

Revision History

Revision Number	Revised Date	Changes
0.1	01.04.2020	Initial release draft
0.2	29.10.2021	Modify for Android R&S

Confidential!
young_yang@sdmctech.com
2022-09-09 15:53:45

CATALOG

1. ANDROID ENVIRONMENT.....	4
2. ENVIRONMENT SETUP STEP	4
2.1 BASEMENT ENVIRONMENT AND TOOLS	4
2.2 32/64 BIT SYSTEM COMPATIBLE TOOL & UBOOT TOOLS.....	4
2.3 INSTALL OPENJDK	4
2.4 TOOLCHAIN CONFIGURATION	4
3. Q&A.....	4
3.1 BUILD FAIL WITH: FAILED WITH: SIGNAL: KILLED.....	4
3.2 BUILD FAIL WITH: TEMPORARY AREA NO SPACE	5
3.3 EXCEPTION IN THREAD “MAIN” JAVA.LANG.OUTOFMEMORYERROR: JAVA HEAP SPACE	5

1. Android Environment

This document build Android compare environment based on Ubuntu Desktop. Following lists the required environment:

Environment	Ubuntu 18.04 LTS Desktop or higher version
CPU	X86_64, 4 cpu cores at least
Memory	16G
Disk	250G at least

2. Environment Setup Step

2.1 Basement Environment and Tools

```
sudo dpkg --add-architecture i386
sudo apt-get update
sudo apt-get install -y automake make perl gcc g++
sudo apt-get install -y git gperf unixodbc dos2unix java-common vim autoconf
sudo apt-get install -y repo python-pip python-dev
sudo apt-get install git-core gnupg flex bison build-essential zip curl zlib1g-dev gcc-multilib g++-multilib libc6-
dev-i386 libncurses5 lib32ncurses5-dev x11proto-core-dev libx11-dev lib32z1-dev libgl1-mesa-dev libxml2-
utils xsltproc unzip fontconfig
```

2.2 32/64 bit System Compatible Tool & uboot Tools

```
sudo apt-get install -y libc6:i386 zlib1g:i386 lib32stdc++6 libstdc++6:i386
sudo apt-get install -y u-boot-tools
```

2.3 Install OpenJDK

```
sudo add-apt-repository ppa:openjdk-r/ppa
sudo apt-get install -y openjdk-8-jdk
sudo update-alternatives --config java
sudo update-alternatives --config javac
```

2.4 Toolchain Configuration

You can get toolchain from FAE. Different platforms use different toolchains, but they are configured in the same way:

(1) Install toolchain in /opt/ directory.

(2) Set variable PATH to access toolchain binary. You can set following command in /etc/bashrc or ~/.bashrc.

```
export PATH=/opt/<Toolchain Rootdir>/bin:$PATH
```

(3) Run <toolchain>-gcc -v, and it indicates ok when print version.

Following list the used toolchains:

	module	Toolchain	
		Toolchain name	version
Android R&S	BL33	aarch64-none-elf-gcc	4.9.2
		arm-none-eabi-gcc	4.4.1
	Kernel	64bit aarch64-linux-gnu-gcc	6.3.1
		32bit arm-linux-gnueabi-gcc	6.3.1

3. Q&A

3.1 Build Fail With: Failed With: Signal: Killed

It might be the swap partition is too small, and following set 1GB swap area:

```
dd if=/dev/zero of=/root/swapfile bs=1M count=1024
mkswap /root/swapfile
swapon /root/swapfile
```

If you want to set swap area when system start, add following statement in /etc/fstab:

```
/root/swapfile swap swap defaults 0 0
```

3.2 Build Fail With: Temporary Area no Space

Compressing system.new.dat with brotli

running: brotli --quality=6 --output=/tmp/tmpi0WKJ3/system.new.dat.br /tmp/tmpi0WKJ3/system.new.dat

Traceback (most recent call last):

```
File "build/make/tools/releasetools/ota_from_target_files", line 2004, in <module>
  main(sys.argv[1:])
File "build/make/tools/releasetools/ota_from_target_files", line 1978, in main
  output_file=args[1])
File "build/make/tools/releasetools/ota_from_target_files", line 832, in WriteFullOTAPackage
  system_diff.WriteScript(script, output_zip)
File "/home/amlogic/android/android-p/build/make/tools/releasetools/common.py", line 1580, in WriteScript
  self._WriteUpdate(script, output_zip)
File "/home/amlogic/android/android-p/build/make/tools/releasetools/common.py", line 1735, in
_WriteUpdate
  'compression of {}.new.dat failed'.format(self.partition)
AssertionError: compression of system.new.dat
```

Building Android needs /tmp/ (variable \$TMPDIR) directory to save temporary files, so it will report error when temporary directory has no space. For this problem, you can just redirect \$TMPDIR to others folder with enough space:

```
mkdir -p /home/<homedir>/tmp
export TMPDIR=/home/<homedir>/tmp
```

If you want to auto setup when system start, please set this commands in ~/.bashrc or /etc/bashrc.

3.3 Exception in thread "main" java.lang.OutOfMemoryError: Java heap space

Java JVM memory is not enough.

```
export JAVA_OPTS='-Xms1024m -Xmx1024m'
```

-Xms <size> Set JVM heap size when initialize.

-Xmx <size> Set JVM heap max memory size.

If you want to auto setup when system start, please set this command in ~/.bashrc or /etc/bashrc.