

Ch.1-2 Computer Abstractions & Technology

▼ 1.6 Performance

- 고려해야 할 사항
 - 1. 왜 다른 프로그램에 대해 더 나은 하드웨어가 있는가?
 - 2. 하드웨어와 관련된 시스템 성능에는 어떠한 요인이 있는가?
 - 3. 어떻게 machine의 instruction이 성능에 영향을 주는가?
- · depends on

Algorithm: affects IC, possibly CPI Programming language: affects IC, CPI

Compiler: affects IC, CPI

Instruction Set Architecture: affects IC, CPI, T_c

⇒ प्रम् अस अभिनास क्रान्य। ततत तत्रा क्राप्ट्री

▼ response time & throughput

- response time : 어떤 일로 결과를 만들어 내는 시간 (+ask 첫 첫 2(b) 선생 (기산)
 - 컴퓨터의 processor를 더 빠른 버전으로 바꿈 → response time이 빨라짐
- **throughput**: 단위 시간 당 response time → 주어진 시간 동안 얼마나 많은 일을 처리?
 - processor를 더 많이 추가함 → throughput이 좋아짐
- ▼ Relative Performance পুলা মৃতাহ পুলাম্ব এস্থ

performance = 1/ Execution time

- ⇒ 컴퓨터의 성능은 실행 시간에 반비례
- ⇒ X is n time faster than Y

大りナイガニナ あいる ロイ

$$\frac{Performance_X}{Performance_Y} = \frac{ExecutionTime_Y}{ExecutionTime_X} = n$$

- example
 - 。 A:10초, B:15초
 - E_B / E_A= 15/10 = 1.5
 - 。 Computer A: B보다 1.5 원 등 빠름


▼ Measuring Execution Time → 성능 等なか)

- Elapsed time(wall clock time, response time) programming 시에 들어가는 시
 간) ⇒ 시작보는 경험가지인 중으로시간
 - o total response time, including all aspects(processing, I/O, OS overhead, idle time)
 - determines system performance

CPU time = user CPU time + system CPU time

- ∘ 주어진 작업을 수행하는데 걸리는 시간 (not include I/O, other job's shares)
 - 각 프로그램은 CPU와 시스템 성능에 각각 영향 받음
 - OS의 각 작업이 어떤 프로그램을 위해서 수행되고 있는지 쉽게 알 수 없음
 - OS 간의 기능 차이도 존재!
- CPU clocking ⇒ Cγcle.
 - 거의 모든 컴퓨터는 hw 이벤트가 발생하는 시점을 clock이 결정
 - clock cycle: clock의 시간 간격

 CPV clock cycle: CPV clockel (지난 2년의 > CPV 내용에서 event가 방법생성 시경.



- 1. clock period : 한 clock cycle이 걸리는 시간, (<u>register를 update</u>)
 - ex. 250ps = 0.25ns = 250×10-12s ⇒ 4GB 정도의 clock speed
- KB $10^3 = 2^{10}$ MB $10^6 = 2^{20}$ GB $10^1 = 2^{40}$ TB $10^{12} = 2^{40}$ Peta 10^{15}

अंतिधिया क्टिन तेह निक्रामान्ड अत्र

(C(ock 35)

- 2. clock frequency (rate): cycles per second → clock period의 역
 - ex. 4.0GHz = 4000MHz = 4.0×109Hz
- ⇒ 사용자 cpu 시간으로 계산한 것을 cpu 성능이라고 생각할 것

▼ CPU Time

- 컴퓨터의 성능 up ⇒ 어떻게?
 - 1. clock 개수 down, 시간 down
 - 2. clock speed up
- example

clock Rate CPU Time

- Computer A: 2GHz clock, 10s CPU
- Computer B: 1.2 × Clock CyclesA, 6s CPU

10 X 2 XIO

- ⇒ B의 clock이 더 빠른가?
- A Clock Gides = CPU Times X Clock Rotes

$$= (0 \times 2 \times 10^{9}) = 2 \times 10^{10}$$

(B) Clock Rotter =
$$\frac{\text{Clock Grees}}{\text{CPU Times}} = \frac{\text{Clock Grees}}{\text$$

.. By Alt 24H Without Stef

▼ 명령어(instruction) 성능 and CPI(clock cycles per instructions)

श्ली (१५०० € इस्ते।

Clock Cycles = Instruction Count × Cycles per Instruction

- ি দুর্ঘুন সান্ instruction count ⇒ ISA(instruction set architecture), compiler প্রাথমিন ইথ্যু
- CPI(명령어 당 평균 clocky cycles) 전성서 중 clock Cycle 수
 - 。 각 명령어가 다른 CPI를 가짐 ⇒ 명령어 조합에 따라 달라질 수 있음(필연x)
- example → と TSA 가정
 - Computer A : Cycle Time = 250ps, CPI = 2.0 में र्ठा देशत सि १९६
 - Computer B: Cycle Time = 500ps, CPI = 1.2

- instruction
 - 다른 instruction → 다른 개수의 cycle

Clock Cycles =
$$\sum_{i=1}^{n} (CPI_i \times Instruction Count_i)$$

weighted average CPI ⇒ 가중치를 이용한 평균

$$\frac{\text{CPI}}{\text{Instruction Count}} = \sum_{i=1}^{n} \left(\text{CPI}_{i} \times \frac{\text{Instruction Count}_{i}}{\text{Instruction Count}} \right) \text{ The Garage CPI}$$

$$\frac{\text{CPI}}{\text{Instruction Count}} \times \text{Clock Rate}$$

$$\frac{\text{CPI}}{\text{Instruction Count}} \times \text{Clock Rate}$$

$$\frac{\text{CPI}}{\text{Instruction Count}} \times \text{Relative frequency} \Rightarrow \text{VEXIZI}$$

$$\text{CPI} \text{Time} = \text{Clock Cycle Time} \times \frac{\text{CPI}_{S} \times \text{ICJ}}{\text{J=1}} \times \text{ICJ}$$

	CPI for each instruction class			
	A	В	C	
CPI	1	2	3	

total

Instruction counts for each instruction class				
A	В	C		
2 2/5	1 /	2 2/5		
4 4	1 16	1 16		
	2 2/9 4 44	A B 2 7/9 1 /9 4 4/9 1		

.. २५० तकिट्रें

o example: calculating CPI bottom up

Base Machine(Reg / Reg)

THE OPERATIONOL

				1 0110 0	
Operation	Cycles	Frequency	CPI _i	Time(%)	<u>ज</u> ्य
ALU	1 >	50% 0.5	- 0.5	33% = 0.5	
Load	2	20% 0.2	= 0.4	27%	
Store	2 y	10% %.(= 0.2	13%	
Branch	2	20% 0-2	= 0.4	27%	
		Average CPI			
			り四点対	2104-21/2019-	

Typical Mix of instruction types in a program clock cycle

• Time = Instruction Count / (.5

CPI = Cycles x Instruction Count L) Frequencyz weighted average.

total CPT = 15

- example: Branch Stall Impact ⇒ instruction이 판단-실행까지 걸리는 시간
 - 가정

- 1. Base Machine : CPI = 1.0 (ideal) ignoring branch →한 사이클에 하 나
- 2. A branch instruction is stalling for 3 cycles → 3 cycle마다 한 번
- instruction 중 30%가 branch일 때, branch instructions이 3 cycle 70% (deal

Operation	Cycles	Frequency	CPI(i)	Time(%)
Others	1 -> CPI	× 70%	= 0.7	37%
Branch	4	X 30%	= 1.2	63%
	CPT.	0000	1.9 (7號) CPI) > 6% (44)	1 > 1.0 (7deal)

- New CPI = 1.9
- New machine is 1/1.9 = 0.52 times faster(시간이 두 배 정도 늘어남)

The BIG Picture

$$CPU Time = \frac{Instructions}{Program} \times \frac{Clock cycles}{Instruction} \times \frac{Seconds}{Clock cycle}$$