no. people	task		material			
		procedure	s	tools	expertise	notes
2	make / ckic	1. Measure and mark 2x12			saw	
			three	table saw or	operator,	
		3. Bevel all 4 pieces of wood.	2x10s, 1	hand/circular	high level	
		4. Sand cuts	2x12	saw	precision	
2	prep base					do not use
		1. Collect rigid insulation		exacto-knife		large
		material; 2. Cut to size; 3.Fill	randon	or hand saw.		styrofoam.
		gaps in floorboards; 4.spread	sized rigid	No power		Save scraps
		and staple plastic.	insulation	tools	little to none	of insulation.
2	nresshoard				saw	
		1. Measure and cut sheets to	pressboar		operator,	see Emily's
		be base; 2. Place over	d; short	table saw or	medium	design map
		insulated base, when	deck	hand/circular	precision	before
		complete.	screws	saw	skills	beginning