
## AtlasEdge firmware update over Flyswatter JTAG probe on Windows


## 1. Connect all wires as shown on the picture




## **Components listing:**

- a. Windows laptop
- b. Flyswatter2 JTAG probe with USB cable
- c. Olimex 20 to 10 pin adapter with ribbon cable
- d. AtlasEdge board with 5V/2A power supply (or USB-B cable)

Make sure to attach ribbon cable in a correct way, as shown on the photo!



2. Install Flyswatter2 probe drivers:



- a. Plug in Flyswatter2 probe to the host
- b. Go to bin\ directory, run "zadig\_2.1.1.exe".
- c. Options > List all devices.
- d. Select your probe (Flyswatter2), pick WinUSB and hit Reinstall Driver; do it for Interface 0 and Interface 1.
- e. Close zadig and REPLUG YOUR PROBE!

## 3. Flash the firmware

- a. Download and extract the latest firmware release and extract it
- b. In the extracted atlasedge\_flasher directory, run the flashing script:
  - Windows: Execute (double-click) flash-jtag.bat in order to flash production image.
  - Linux: Run flash-jtag.sh in order to flash production image
  - OSX: Not supported

That's how successful flash looks like