Manometer
Support
Ritter
Made in Germany

Manometer
Support
Thermometer
(Gas)
Thermometer
(Packing Fluid)


Thermometer
(Packing Fluid)

SENSORCHOICE

Gas Outlet
Filling Nozzle
Manometer Connection
Caution
To attain proper packing fluid level the gas meter must be aligned precisely horizontally, and the fluid column surface must be plane and flush with the overflow faucet trim (i.e., neither convex nor concave).
Gas Inlet
Filling Level Indicator

Manometer
Connection
Gas Inlet

Gas Outlet

luid level
ane pre-
the fluid
plane and
ucet brim
concave).
Gas Inlet

Filling Nozzle


10
1
Ritter
Made in Germ