

Considerations and Pro Tips

Hard won wisdom from bridge building:

- Use wax paper under the bridge when assembling to prevent sticking to the work surface. It will save a major headache.
- Do not forget to use the kerf setting on the lazar! We calculated it in the ud5 files.
- Clamp well when curing epoxy, and cure at a temperature above room temperature for at least 24 hours. Cold temperatures will prevent proper curing and weaken the joints significantly.
- Go with the grain. Balsa is garbage if you put the grain the wrong way.