





Chapter 1: Transformations and rigid movements



abdelaziz@lirmm.fr


Montpellier, France

NOTATIONS AND DEFINITIONS


- Point : lowercase italic letter
- Vector : lowercase bold letter
- Null vector: 0
- Matrix: bold capital letter
- ❖ Norm of a vector : || ||
- ❖ Scalar product : a ⋅ b
- Cross product: $\mathbf{a} \wedge \mathbf{b}$
- Pose = position + orientation

NOTATIONS AND DEFINITIONS

Let $\mathcal{R}_i = (0, \mathbf{x}_i, \mathbf{y}_i, \mathbf{z}_i)$ be a direct orthonormal frame




- \bullet Orthogonal frame: $\mathbf{x}_i \perp \mathbf{y}_i \perp \mathbf{z}_i$
- * Normalized frame : $\|\mathbf{x}_i\| = \|\mathbf{y}_i\| = \|\mathbf{z}_i\| = 1$



Indirect frame

POINT REPRESENTATION




 \bullet The coordinates of a point m are represented by the vector:


$$\mathbf{m} = \begin{pmatrix} m_\chi \\ m_y \\ m_z \end{pmatrix}$$
 i to say that the vector \mathbf{m} is expressed in the frame \mathcal{R}_i

Or:

$$^{\mathbf{i}}\mathbf{m} = m_{\chi}\mathbf{x}_{\mathbf{i}} + m_{\chi}\mathbf{y}_{\mathbf{i}} + m_{z}\mathbf{z}_{\mathbf{i}}$$



 \mathcal{R}_j : frame attached the solid (S)




 $\mathcal{R}_i \text{:}$ reference frame

Q: What is the pose (position + orientation) of the solid with respect to the frame \mathcal{R}_i ?


Position of a solid (S)

* The position \mathcal{R}_i with respect to \mathcal{R}_i is represented by the vector:

$${}^{i}\mathbf{p}_{j} = \overrightarrow{OO_{j}} = \begin{pmatrix} x \\ y \\ z \end{pmatrix}$$



Orientation of the solid (S)



The vector of the base \mathcal{R}_i can be expressed in the frame \mathcal{R}_i as:

$${}^{i}\mathbf{x}_{j} = \begin{pmatrix} \mathbf{x}_{j} \cdot \mathbf{x}_{i} \\ \mathbf{x}_{j} \cdot \mathbf{y}_{i} \\ \mathbf{x}_{j} \cdot \mathbf{z}_{i} \end{pmatrix}; \qquad {}^{i}\mathbf{y}_{j} = \begin{pmatrix} \mathbf{y}_{j} \cdot \mathbf{x}_{i} \\ \mathbf{y}_{j} \cdot \mathbf{y}_{i} \\ \mathbf{y}_{j} \cdot \mathbf{z}_{i} \end{pmatrix}; \qquad {}^{i}\mathbf{z}_{j} = \begin{pmatrix} \mathbf{z}_{j} \cdot \mathbf{x}_{i} \\ \mathbf{z}_{j} \cdot \mathbf{y}_{i} \\ \mathbf{z}_{j} \cdot \mathbf{z}_{i} \end{pmatrix}$$

The orientation of the frame \mathcal{R}_i with respect to \mathcal{R}_i is represented by:

$${}^{i}\mathbf{R}_{j} = \begin{pmatrix} {}^{i}\mathbf{x}_{j} & {}^{i}\mathbf{y}_{j} & {}^{i}\mathbf{z}_{j} \end{pmatrix}$$


 ${}^{i}\mathbf{R}_{j}$: 3 × 3 rotation matrix, expressing the transition from the frame \mathcal{R}_{i} towards the frame \mathcal{R}_{j}

Properties:


The pose of the solid (S), represented by the vector ${}^{i}\mathbf{p}_{j}$, and the matrix ${}^{i}\mathbf{R}_{j}$ are gathered inside a matrix ${}^{i}\mathbf{T}_{j}$, known as homogeneous transformation matrix

 ${}^{ ext{i}}\mathbf{T_{j}}$: transition matrix from the frame \mathcal{R}_{i} towards the frame \mathcal{R}_{j}

$${}^{i}\mathbf{T}_{j} = \begin{pmatrix} & {}^{i}\mathbf{R}_{j} & & {}^{i}\mathbf{p}_{j} \\ 0 & 0 & 0 & 1 \end{pmatrix}$$




Pure translation



$${}^{i}\mathbf{T}_{j} = \mathbf{Trans}(a, b, c) = \begin{pmatrix} 1 & 0 & 0 & a \\ 0 & 1 & 0 & b \\ 0 & 0 & 1 & c \\ 0 & 0 & 0 & 1 \end{pmatrix}$$

Pure rotation (1)



$$^{\mathbf{i}}\mathbf{x}_{\mathbf{j}} = \begin{pmatrix} 1 \\ 0 \\ 0 \end{pmatrix};$$

$$^{i}\mathbf{y}_{j} = \begin{pmatrix} 0 \\ \cos \theta \\ \sin \theta \end{pmatrix};$$

$$^{i}\mathbf{z}_{j} = \begin{pmatrix} 0 \\ -\sin\theta \\ \cos\theta \end{pmatrix}$$

$${}^{i}\mathbf{T}_{j} = \mathbf{Rot}(\mathbf{x}, \theta) = \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & \cos \theta & -\sin \theta & 0 \\ 0 & \sin \theta & \cos \theta & 0 \\ 0 & 0 & 0 & 1 \end{pmatrix}$$


Pure rotation (2)

$$\mathbf{Rot}(\mathbf{x}, \theta) = \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & \cos \theta & -\sin \theta & 0 \\ 0 & \sin \theta & \cos \theta & 0 \\ 0 & 0 & 0 & 1 \end{pmatrix}$$

$$\mathbf{Rot}(\mathbf{y}, \theta) = \begin{pmatrix} \cos \theta & 0 & \sin \theta & 0 \\ 0 & 1 & 0 & 0 \\ -\sin \theta & 0 & \cos \theta & 0 \\ 0 & 0 & 0 & 1 \end{pmatrix}$$


$$\mathbf{Rot}(\mathbf{z}, \theta) = \begin{pmatrix} \cos \theta & -\sin \theta & 0 & 0\\ \sin \theta & \cos \theta & 0 & 0\\ 0 & 0 & 1 & 0\\ 0 & 0 & 0 & 1 \end{pmatrix}$$

Example 1: compute the homogeneous transformation matrix ${}^{i}T_{j}$




Response:

Example 2: compute the homogeneous transformation matrix ${}^{i}T_{j}$




Response:

Remarks:



$$\mathbf{R}_1 = \mathbf{rot}(\mathbf{z}, \pi/2) * \mathbf{rot}(\mathbf{x}, \pi/2)$$



Remarks:

Let
$$\mathbf{T}_1=\begin{pmatrix}\mathbf{R}_1&\mathbf{p}_1\\0&0&0&1\end{pmatrix}$$
 and $\mathbf{T}_2=\begin{pmatrix}\mathbf{R}_2&\mathbf{p}_2\\0&0&0&1\end{pmatrix}$.
$$\mathbf{T}_1\mathbf{T}_2=\begin{pmatrix}\mathbf{R}_1\mathbf{R}_2&\mathbf{R}_1\mathbf{p}_2+\mathbf{p}_1\\0&0&0&1\end{pmatrix}$$

$$\mathbf{T}_2\mathbf{T}_1=\begin{pmatrix}\mathbf{R}_2\mathbf{R}_1&\mathbf{R}_2\mathbf{p}_1+\mathbf{p}_2\\0&0&0&1\end{pmatrix}$$
 $\Rightarrow \mathbf{T}_1\mathbf{T}_2\neq \mathbf{T}_2\mathbf{T}_1$

Properties:

$$1) \quad \mathbf{R}^{-1} = \mathbf{R}^T$$

$$\mathbf{R}^T\mathbf{R}=\mathbf{I}_3$$

3)
$$det(\mathbf{R}) = 1$$


$$^{i}\mathbf{T}_{j}^{-1} = ^{j}\mathbf{T}_{i}$$

5)
$$\mathbf{T} = \begin{pmatrix} \mathbf{R} & \mathbf{p} \\ 0 & 0 & 0 & 1 \end{pmatrix} \Rightarrow \mathbf{T}^{-1} = \begin{pmatrix} \mathbf{R}^T & -\mathbf{R}^T \mathbf{p} \\ 0 & 0 & 0 & 1 \end{pmatrix}$$

6)
$${}^{0}\mathbf{T}_{k} = {}^{0}\mathbf{T}_{1} {}^{1}\mathbf{T}_{2} {}^{2}\mathbf{T}_{3} \dots {}^{k-1}\mathbf{T}_{k}$$

Matrices de transformation homogènes

Example 3: from the example 2, compute ${}^{J}T_{i}$ using the properties 4 and 5




Response:

$${}^{j}T_{i} = \begin{pmatrix} 0 & 1 & 0 & -9 \\ 0 & 0 & 1 & -4 \\ 1 & 0 & 0 & -3 \\ 0 & 0 & 0 & 1 \end{pmatrix}$$

Point belonging to a solid in pure rotation

Let m be a point belonging to a solid (S). The coordinates of m, expressed in the frame $\mathcal{R}_i(0, \mathbf{x}_i, \mathbf{y}_i, \mathbf{z}_i)$, are represented by a vector:



POINT BELONGING TO A SOLID IN PURE ROTATION


* After a pure rotation of the solid around the origin O, the coordinates of m', expressed in the frame $\mathcal{R}_{j}(O,\mathbf{x}_{j},\mathbf{y}_{j},z_{j})$, are:

$$^{\mathbf{j}}\mathbf{m}'=(m_{x}\quad m_{y}\quad m_{z})^{T}=^{\mathbf{i}}\mathbf{m}$$

• The coordinates of m', expressed un the frame $\mathcal{R}_{i}(0,\mathbf{x}_{i},\mathbf{y}_{i},\mathbf{z}_{i})$, are:

$${}^{i}\mathbf{m}' = {}^{i}\mathbf{R}_{j} {}^{j}\mathbf{m}' = {}^{i}\mathbf{R}_{j} {}^{i}\mathbf{m}$$

with ${}^{i}\mathbf{R}_{j}$ being the rotation matrix $\mathcal{R}_{i} \longrightarrow \mathcal{R}_{j}$



Point belonging to a solid in pure rotation

Example 1:

Let m be a point with the coordinates $(0 \ 1 \ \sqrt{3})^T$, expressed in the frame $\mathcal{R}_i(O, \mathbf{x}_i, \mathbf{y}_i, \mathbf{z}_i)$. Compute the coordinates of this transformed point (now point m') after a rotation of the frame \mathcal{R}_i by $\pi/6$ around the axis \mathbf{y}_i .

 $\pi/6$

Response:

POINT BELONGING TO A SOLID IN PURE ROTATION

Solution :

$${}^{i}\mathbf{m} = \begin{pmatrix} 0 \\ 1 \\ \sqrt{3} \end{pmatrix} = {}^{j}\mathbf{m}'$$

$${}^{i}\mathbf{m}' = {}^{i}\mathbf{R}_{j} {}^{j}\mathbf{m}' = {}^{i}\mathbf{R}_{j} {}^{i}\mathbf{m}$$

$${}^{y_{i}}\mathbf{y}_{j} \odot \bigcirc \bigcirc \stackrel{\pi/6}{\longrightarrow} \mathbf{z}_{i}$$


$${}^{i}\mathbf{R}_{j} = \begin{pmatrix} \cos \theta & 0 & \sin \theta \\ 0 & 1 & 0 \\ -\sin \theta & 0 & \cos \theta \end{pmatrix} = \begin{pmatrix} \frac{\sqrt{3}}{2} & 0 & \frac{1}{2} \\ 0 & 1 & 0 \\ -\frac{1}{2} & 0 & \frac{\sqrt{3}}{2} \end{pmatrix}$$

$${}^{i}\mathbf{m}' = {}^{i}\mathbf{R}_{j} {}^{j}\mathbf{m}' = {}^{i}\mathbf{R}_{j} {}^{i}\mathbf{m} = \begin{pmatrix} \frac{\sqrt{3}}{2} & 0 & \frac{1}{2} \\ 0 & 1 & 0 \\ -\frac{1}{2} & 0 & \frac{\sqrt{3}}{2} \end{pmatrix} \begin{pmatrix} 0 \\ 1 \\ \sqrt{3} \end{pmatrix} = \begin{pmatrix} \frac{\sqrt{3}}{2} \\ 1 \\ \frac{3}{2} \end{pmatrix}_{22}$$

POINT BELONGING TO A SOLID IN PURE ROTATION

Exemple 2:


Let m'' be a point of coordinates $(\sqrt{2} \ 0 \ 0)^T$, expressed in the frame $\mathcal{R}_k(0, \mathbf{x}_k, \mathbf{y}_k, \mathbf{z}_k)$. Determine the coordinates of the same point in the frame \mathcal{R}_i



Réponse:

POINT BELONGING TO A SOLID IN A FREE MOVEMENT

- ${}^{i}\mathbf{m} = (m_x \quad m_y \quad m_z)^T$, coordinate of m expressed in $\mathcal{R}_{\mathbf{i}}$
- $^{\mathbf{j}}\mathbf{m}'=(m_x \quad m_y \quad m_z)^T$, coordinates of m' expressed in $\mathcal{R}_{\mathbf{j}}$
- ullet The coordinates of m', expressed in the frame \mathcal{R}_{i} are:




POINT BELONGING TO A SOLID IN A FREE MOVEMENT

Example 3:

Coordinates of m' in \mathcal{R}_j : ${}^j\mathbf{m}' = (\sqrt{3} \quad 4 \quad 5)^T$

Compute the coordinates of m' in $\mathcal{R}_{\mathbf{i}}$



Response:

POINT BELONGING TO A SOLID IN A FREE MOVEMENT


Solution:

$${}^{j}\mathbf{m}' = \begin{pmatrix} \sqrt{3} \\ 4 \\ 5 \end{pmatrix}$$
$${}^{i}\mathbf{m}' = {}^{i}\mathbf{T}_{j} {}^{j}\mathbf{m}'$$

$${}^{\mathbf{i}}\mathbf{T}_{\mathbf{j}} = \begin{pmatrix} 0 & 0 & -1 & 3 \\ 1 & 0 & 0 & 5 \\ 0 & -1 & 0 & 4 \\ 0 & 0 & 0 & 1 \end{pmatrix}$$

$${}^{i}\mathbf{T}_{j} \ {}^{i}\mathbf{m}' = \begin{pmatrix} 0 & 0 & -1 & 3 \\ 1 & 0 & 0 & 5 \\ 0 & -1 & 0 & 4 \\ 0 & 0 & 0 & 1 \end{pmatrix} \begin{pmatrix} \sqrt{3} \\ 4 \\ 5 \\ 1 \end{pmatrix} = \begin{pmatrix} -2 \\ \sqrt{3} + 5 \\ 0 \\ 1 \end{pmatrix}$$

Knowing the Roll (γ) Pitch (β) Yaw (α) angles of a solid, the associated rotation matrix can be expressed as:



$$R = rot(z, \alpha) rot(y, \beta) rot(x, \gamma)$$

$$= \begin{pmatrix} \cos \alpha & -\sin \alpha & 0 \\ \sin \alpha & \cos \alpha & 0 \\ 0 & 0 & 1 \end{pmatrix} \begin{pmatrix} \cos \beta & 0 & \sin \beta \\ 0 & 1 & 0 \\ -\sin \beta & 0 & \cos \beta \end{pmatrix} \begin{pmatrix} 1 & 0 & 0 \\ 0 & \cos \gamma & -\sin \gamma \\ 0 & \sin \gamma & \cos \gamma \end{pmatrix}$$

$$= \begin{pmatrix} \cos \alpha \cos \beta & -\sin \alpha \cos \gamma + \cos \alpha \sin \beta \sin \gamma & \sin \alpha \sin \gamma + \cos \alpha \sin \beta \cos \gamma \\ \sin \alpha \cos \beta & \cos \alpha \cos \gamma + \sin \alpha \sin \beta \sin \gamma & -\cos \alpha \sin \gamma + \sin \alpha \sin \beta \cos \gamma \\ -\sin \beta & \cos \beta \sin \gamma & \cos \beta \cos \gamma \end{pmatrix}$$

Inversely, to determine the Roll Pitch Yaw angles from a given rotation

matrix
$$\mathbf{R} = \begin{pmatrix} x_x & y_x & z_x \\ x_y & y_y & z_y \\ x_z & y_z & z_z \end{pmatrix}$$
, one can proceed as follow:

• if
$$x_z \neq \pm 1$$

$$\alpha = \operatorname{atan2}(x_y, x_x)$$

$$\beta = \operatorname{atan2}\left(-x_z, \sqrt{x_x^2 + x_y^2}\right)$$

$$\gamma = \operatorname{atan2}(y_z, z_z)$$

• if
$$x_z = \pm 1$$

$$\alpha - sign(\beta)\gamma = atan2(z_y, z_x)$$

 α et γ are indeterminate

$$\sin\frac{\pi}{4} = \frac{\sqrt{2}}{2}$$


$$\Rightarrow \tan \frac{\pi}{4} = 1$$

$$\cos\frac{\pi}{4} = \frac{\sqrt{2}}{2}$$

$$\sin\frac{5\pi}{4} = -\frac{\sqrt{2}}{2}$$

$$\cos\frac{5\pi}{4} = -\frac{\sqrt{2}}{2}$$

$$\Rightarrow \tan \frac{5\pi}{4} = 1$$



$$tan^{-1}(1) = atan(1) = ???$$

 $atan2(\sin\theta,\cos\theta)$


Example:

$$atan2\left(\frac{\sqrt{2}}{2}, \frac{\sqrt{2}}{2}\right) = \frac{\pi}{4}$$


$$\operatorname{atan2}\left(-\frac{\sqrt{2}}{2}, \frac{\sqrt{2}}{2}\right) = \frac{7\pi}{4}$$

$$atan2\left(-\frac{\sqrt{2}}{2}, -\frac{\sqrt{2}}{2}\right) = \frac{5\pi}{4}$$

$$atan2\left(\frac{\sqrt{2}}{2}, -\frac{\sqrt{2}}{2}\right) = \frac{3\pi}{4}$$



Knowing the Euler angles (ψ, θ, φ) angles of a solid, the associated rotation matrix can be expressed as:



$$\mathbf{R} = \mathbf{rot}(\mathbf{z}, \boldsymbol{\psi}) \ \mathbf{rot}(\mathbf{x}_{\psi}, \boldsymbol{\theta}) \ \mathbf{rot}(\mathbf{z}_{\theta}, \boldsymbol{\varphi})$$

$$= \begin{pmatrix} \cos \psi & -\sin \psi & 0 \\ \sin \psi & \cos \psi & 0 \\ 0 & 0 & 1 \end{pmatrix} \begin{pmatrix} 1 & 0 & 0 \\ 0 & \cos \theta & -\sin \theta \\ 0 & \sin \theta & \cos \theta \end{pmatrix} \begin{pmatrix} \cos \varphi & -\sin \varphi & 0 \\ \sin \varphi & \cos \varphi & 0 \\ 0 & 0 & 1 \end{pmatrix}$$

$$= \begin{pmatrix} \cos\psi\cos\varphi - \sin\psi\cos\theta\sin\varphi & -\cos\psi\sin\varphi - \sin\psi\cos\theta\cos\varphi & \sin\psi\sin\theta \\ \sin\psi\cos\varphi + \cos\psi\cos\theta\sin\varphi & -\sin\psi\sin\varphi + \cos\psi\cos\theta\cos\varphi & -\cos\psi\sin\theta \\ \sin\theta\sin\varphi & \sin\theta\cos\varphi & \cos\theta \end{pmatrix}$$

Inversely, to determine the Euler angles from a given rotation matrix

$$\mathbf{R} = \begin{pmatrix} x_x & y_x & z_x \\ x_y & y_y & z_y \\ x_z & y_z & z_z \end{pmatrix}$$
, we can proceed as follow:

$$\bullet$$
 if $z_z \neq \pm 1$

$$\psi = \operatorname{atan2}(z_x, -z_y)$$
$$\theta = \operatorname{acos}(z_z)$$
$$\varphi = \operatorname{atan2}(x_z, y_z)$$

$$\cdot$$
 If $z_z = \pm 1$

$$\theta = \pi (1 - z_z)/2$$

$$\psi + z_z \varphi = atan2(y_x, x_x)$$

 ψ et φ are indeterminate

Example:

Let the rotation matrix be
$$\mathbf{R}=\begin{pmatrix} \frac{\sqrt{3}}{2} & \frac{-1}{2} & 0\\ 0 & 0 & -1\\ \frac{1}{2} & \frac{\sqrt{3}}{2} & 0 \end{pmatrix}$$

$$\alpha = \operatorname{atan2}\left(0, \frac{\sqrt{3}}{2}\right)$$
 impossible
$$\beta = \operatorname{atan2}\left(-1/2, \frac{\sqrt{3}}{2}\right)$$
 impossible
$$\gamma = \operatorname{atan2}\left(\frac{\sqrt{3}}{2}, 0\right)$$
 impossible

Example:

Let the rotation matrix be
$$\mathbf{R} = \begin{pmatrix} \frac{\sqrt{3}}{2} & \frac{-1}{2} & 0\\ 0 & 0 & -1\\ \frac{1}{2} & \frac{\sqrt{3}}{2} & 0 \end{pmatrix}$$

$$\psi = \operatorname{atan2}(0, 1) = 0$$

$$\theta = \operatorname{acos}(0) = \pm \frac{\pi}{2}$$

$$\varphi = \operatorname{atan2}\left(\frac{1}{2}, \frac{\sqrt{3}}{2}\right) = \frac{\pi}{6}$$

Example:

Let the rotation matrix be
$$\mathbf{R} = \begin{pmatrix} 0.7071 & -0.3536 & -0.6124 \\ 0.7071 & 0.3536 & 0.6124 \\ 0 & -0.8660 & 0.5 \end{pmatrix}$$

$$\alpha = \text{atan2}(0.7071, 0.7071) = \frac{\pi}{4}$$

$$\beta = \text{atan2}(0, 1) = 0$$

$$\gamma = atan2\left(-\frac{\sqrt{3}}{2}, \frac{1}{2}\right) = -\frac{\pi}{3}$$

Example:


Let the rotation matrix be
$$\mathbf{R} = \begin{pmatrix} 0.3536 & -0.3536 & 0.8660 \\ 0.6124 & -0.6124 & -0.5 \\ 0.7071 & 0.7071 & 0 \end{pmatrix}$$

$$\psi = \operatorname{atan2}(0.8660, 0.5) = \frac{\pi}{3}$$

$$\theta = \operatorname{acos}(0) = \frac{\pi}{2}$$

$$\varphi = \operatorname{atan2}(0.7071, 0.7071) = \frac{\pi}{4}$$

* Let $\mathbf{u} = \begin{bmatrix} u_x & u_y & u_z \end{bmatrix}^T$ be a unit vector of a rotation axis with respect to the reference frame $\mathcal{R}_0 = (0, \mathbf{x}_0, \mathbf{y}_0, \mathbf{z}_0)$



$$rot(\mathbf{u},\vartheta) = rot(\mathbf{z},\alpha)rot(\mathbf{y},\beta)rot(\mathbf{z},\vartheta)rot(\mathbf{y},-\beta)rot(\mathbf{z},-\alpha)$$

$$\sin \alpha = \frac{u_y}{\sqrt{u_x^2 + u_y^2}}; \qquad \cos \alpha = \frac{u_x}{\sqrt{u_x^2 + u_y^2}};$$

$$\sin \beta = \sqrt{u_x^2 + u_y^2}; \quad \cos \beta = u_z$$

$$\mathbf{rot}(\mathbf{u}, \vartheta) = \begin{pmatrix} u_x^2 (1 - C_\vartheta) + C_\vartheta & u_x u_y (1 - C_\vartheta) - u_z S_\vartheta & u_x u_z (1 - C_\vartheta) + u_y S_\vartheta \\ u_x u_y (1 - C_\vartheta) + u_z S_\vartheta & u_y^2 (1 - C_\vartheta) + C_\vartheta & u_y r_z (1 - C_\vartheta) - u_x S_\vartheta \\ u_x u_z (1 - C_\vartheta) - u_y S_\vartheta & u_y u_z (1 - C_\vartheta) + u_x S_\vartheta & u_z^2 (1 - C_\vartheta) + C_\vartheta \end{pmatrix}$$

The vector **u** is constrained by the following relationship:

$$u_x^2 + u_y^2 + u_z^2 = 1$$

To solve the inverse problem and determine the angle ϑ and the unit

vector
$$\mathbf{u}$$
 from a given rotation matrix $\mathbf{R} = \begin{pmatrix} x_x & y_x & z_x \\ x_y & y_y & z_y \\ x_z & y_z & z_z \end{pmatrix}$, we can

proceed as follow:

$$C\vartheta = \frac{1}{2} (x_x + y_y + z_z - 1)$$

$$S\vartheta = \frac{1}{2} \sqrt{(y_z - z_y)^2 + (z_x - x_z)^2 + (x_y - y_x)^2}$$

lacktriangle The vector f u and the angle m heta are computed as:

$$\vartheta = atan2(S\vartheta, C\vartheta)$$

$$\mathbf{u} = \frac{1}{2\sin\theta} \begin{pmatrix} y_z - z_y \\ z_x - x_z \\ x_y - y_x \end{pmatrix}$$

Important:

If $\sin \vartheta = 0$, the expression of **u** becomes meaningless. To solve this problem, it is necessary to refer to particular expressions for $\vartheta = 0$ and $\vartheta = \pi$ (not given in this course).

ORIENTATION REPRESENTATION: UNIT QUATERNION

* The drawbacks of the axis/angle representation can be overcome by a different four-parameter representation; namely the *unit quaternion*. In other word, Euler parameters, defined as $\mathfrak{Q} = \{\eta, \epsilon\}$ where :

$$\eta = \cos\frac{\vartheta}{2}$$
$$\boldsymbol{\epsilon} = \sin\frac{\vartheta}{2}\mathbf{u}$$

 η is called the scalar part of the quaternion and $\epsilon = \begin{bmatrix} \epsilon_x & \epsilon_y & \epsilon_z \end{bmatrix}^T$ is called the vector part of the quaternion. They are constrained by the condition:

$$\eta^2 + \epsilon_x^2 + \epsilon_y^2 + \epsilon_z^2 = 1$$

Hence the name of unit quaternion

ORIENTATION REPRESENTATION: UNIT QUATERNION

The associated rotation matrix is given by:

$$\mathbf{rot}(\eta, \boldsymbol{\epsilon}) = \begin{pmatrix} 2(\eta^2 + \epsilon_x^2) - 1 & 2(\epsilon_x \epsilon_y - \eta \epsilon_z) & 2(\epsilon_x \epsilon_z + \eta \epsilon_y) \\ 2(\epsilon_x \epsilon_y + \eta \epsilon_z) & 2(\eta^2 + \epsilon_y^2) - 1 & 2(\epsilon_y \epsilon_z - \eta \epsilon_x) \\ 2(\epsilon_x \epsilon_z - \eta \epsilon_y) & 2(\epsilon_y \epsilon_z + \eta \epsilon_x) & 2(\eta^2 + \epsilon_z^2) - 1 \end{pmatrix}$$

ORIENTATION REPRESENTATION: UNIT QUATERNION

* To solve the inverse problem and compute the quaternion from a given rotation matrix $\mathbf{R} = \begin{pmatrix} x_x & y_x & z_x \\ x_y & y_y & z_y \\ x_z & y_z & z_z \end{pmatrix}$, one can proceed as follow:

$$\eta = \frac{1}{2} \sqrt{x_x + y_y + z_z + 1}$$

$$\epsilon = \frac{1}{2} \left[sign(y_z - z_y) \sqrt{x_x - y_y - z_z + 1} \right]$$

$$sign(z_x - x_z) \sqrt{y_y - z_z - x_x + 1}$$

$$sign(x_y - y_x) \sqrt{z_z - x_x - y_y + 1} \right]$$

End of chapter 1