WORK INSTRUCTIONS FETCH ROBOT RESET			
Work Instruction No.			
Revision No. 01	Site Code WI03	Page 1 OF 2	Zebra Technologies

1. OVERVIEW

This document outlines the procedure for resetting the F100 Robot.

2. CHARGING ERROR

✓ If a charging error occurs, the lightning bolt will be blinking red to reset follow the steps below.

1. Disconnect the charging cable.
2. Turn off the Robot, press and hold the power button for 5 seconds.
3. Turn off the breaker switch.
4. Wait for a minute or two.
5. Turn the breaker switch on again.
6. Press the power button again.
7. Connect that charging cable.
8. If the issue persists, look in the next connector to ensure there are no foreign objects obstructing the connection.



9. Ensure that the Fetch logo is facing up.

This document contains proprietary information which is the exclusive property of Zebra Technologies Corp.

The most recent version of this document is located on the ISO Library.
Verify revision number before use.

3. Multi LED Lights Issue on Flex Shelf

✓ If there is no charging error but the side LED lights on the Flex Shelf are blinking multiple colors at once, follow the steps listed in Section 2.



✓ If the reset functions did not work and you are experiencing the same issues.

1. Leave the unit in the charging area.
2. Make a note of the serial number and also make a note on the DC Fetch Battery Charging Tracker V.2.
3. Inform the individuals below.

   Mike Alaimo – Senior Mgr. Fetch Operations,
   Shailesh Jaiswal – Manufacturing Engineer,
   Eloy Rodas – Quality Engineer
   Elba Maya – SC Planner, and the onsite QA Team.

4. Await disposition from the team.
5. Do not put the unit away.

4. References

Document #	Document Title

5. Revision History

The following table lists all revisions (including the original document) to this procedure, the date, and the reason for the revision.

Rev.	Rev. Date	Description of Change	Revised By
01	07/19/2023	Original issue	A.Cabrera

This document contains proprietary information which is the exclusive property of Zebra Technologies Corp.

The most recent version of this document is located on the ISO Library.
Verify revision number before use.