

## Lösung 07: Watchdog, Energiesparmodi, Temperatursensor

## Aufgabe 1: Watchdog

```
#include <avr/wdt.h>
void setup() {
       Serial.begin(9600);
       Serial.println("System restart");
       // start watchdog
       cli();
       wdt reset();
       // preparation for configuration: write logic one to WDCE and WDE, p61
       WDTCSR |= (1<<WDCE) | (1<<WDE);</pre>
       // within 4 clock cycles: set timeout to 4 seconds and start watchdog
       // Hint: WDCE bit is implicitly cleared by "="
       WDTCSR = (1 << WDP3) \mid (1 << WDE);
       // configure interrupt
       DDRD \&= \sim (1 << DDD0);
                                  // configure PD0 as input
       PORTD |= (1 << PORTD0); // pull up, write to PORT when in INPUT mode, p68
       // globally activate
       sei();
interrupts
}
void loop() { }
                                    // empty!
ISR (INT0 vect) {
            wdt reset();
            Serial.println("ResetWDT");
}
```

#### Hinweise:

- Die internen Pull-Up Widerstände werden beim ATmega2560 standardmäßig aktiviert, wenn ein Pin als Eingang konfiguriert ist.
- Konfiguriert man für den Watchdog Timeout 4s, so beobachtet man auf der Konsole vermutlich etwas mehr als 4 Sekunden bis man erneut "System Restart" auf der seriellen Konsole liest. Der Grund ist, dass der Restart selbst Zeit benötigt. Man misst also eigentlich 4s + für den Restart benötigte Zeit.

## Aufgabe 2: Power-Down Mode

```
#include <avr/sleep.h>

void setup()
{
     Serial.begin(9600);
     delay(2000);
     Serial.println("System restart");

     // activate interrupt on pin0 of PORT D (INT0)
     DDRD &= ~(1 << DDD0);</pre>
```



```
PORTD |= (1 << PORTD0);
      EIMSK \mid = (1 << INT0);
      EICRA \mid = (1 << ISC01);
      sei();
      // configure power-down mode
      SMCR = (1 << SM1);
}
void loop() {
      // enter sleep mode
      Serial.println("Going to sleep");
      delay(200);
      sleep_mode();
      Serial.println("Waking up");
      delay(1000);
}
// ISR: can be empty, but must exist!
ISR (INT0 vect) {
}
```

## Aufgabe 3: Temperatursensor

Im folgenden Code wird gleich der Free Running Mode eingesetzt. Immer nach Beenden einer A/D Umsetzung wird sofort die neue Umsetzung gestartet.

```
void setup() {
      Serial.begin(9600);
      // enable ADC functionality
      ADCSRA = (1 << ADEN);
      // use /128 prescaler, see manual p271
      ADCSRA |= (1 << ADPS2) | (1 << ADPS1) | (1 << ADPS0);
      // select <u>autotrigger</u>, to use free-running mode
      ADCSRA |= (1 << ADATE) | (1 << ADSC);
      // use free-running mode
      ADCSRB &= ~((1 << ADTS2) | (1 << ADTS1) | (1 << ADTS0));
      // select ADC2 as input pin
      ADMUX |= (1 << MUX1);
      // use reference voltage 2,56 V, manual p281
      ADMUX = (1 << REFS1) | (1 << REFS0);
}
void loop()
      // note: conversion is automatically triggered in free running mode
      // read analog value, first LOW then HIGH register
```

# **Embedded Systems (ESy)**

Sommersemester 2020 Prof. Dr. Wolfgang Mühlbauer

Blatt 07



```
unsigned int read = ADCL + 256 * ADCH;

// convert integer value into temperature
double temperature = 0.25 * read - 50;
Serial.println(temperature);
delay(1000);
}
```