#### Adrian Cristian Crisan

https://drive.matlab.com/sharing/67e401c0-ccbc-48e9-9c17-19f694be4e96

# Milling and Welding Todo

I have solved for you as an example the drilling task. Similar procedure ought to be done with welding task

#### **Table of Contents**

Load the cylinder data	
Plot the robot to initial position	
Visualize the cylinder	
Visualize the other cylinder	
Draw drill task profile	
Recording the drilling task	
Draw welding task profile	
Recording the welding task	
Only Welding points	
Functions	10

See the video: https://youtu.be/cVZWm9ORY30

As you can see in the video a Robot Arm perform three task. Only two tasks are shown:

- 1. Make a hole in a cylinder by drilling it. Observe that the tool mantain the same orientation during the drilling task.
- 2. Insertion of a smaller cylinder not recorder here.
- 3. Welding the two cylinder. Observe that the tool always form a 45° among the two cylinder axis



## Load the cylinder data

```
clear;
close all;
clf
load('F_V_cylinder.mat');
```

## Plot the robot to initial position

Pay attention how to move the robot base and add a tool

```
radius = 0.20;
```

```
n = 200;
mdl_puma560
p560.base = transl(-0.1, 0, 0)
```

p560 =

Puma 560 [Unimation]:: 6 axis, RRRRRR, stdDH, slowRNE

- viscous friction; params of 8/95;

++	+		+	+	
jj	theta	d	a	alpha	offset
1	q1	0	0	1.5708	0
2	q2	0	0.4318	0	0
3	q3	0.15005	0.0203	-1.5708	0
4	q4	0.4318	0	1.5708	0
5	q5	0	0	-1.5708	0
6	q6	0	0	0	0
++			+	+	+

base: t = (-0.1, 0, 0), RPY/xyz = (0, 0, 0) deg

#### p560.tool = transl(0,0,0.15)

p560 =


Puma 560 [Unimation]:: 6 axis, RRRRRR, stdDH, slowRNE

- viscous friction; params of 8/95;

+						++
į	offset	alpha	a	d	theta	j
	(	1.5708	0	0	q1	1
	6	0	0.4318	0	q2	2
	6	-1.5708	0.0203	0.15005	q3	3
Ì	(	1.5708	0	0.4318	q4	4
	6	-1.5708	0	0	q5	5
	6	0	0	0	q6	6

base: t = (-0.1, 0, 0), RPY/xyz = (0, 0, 0) degtool: t = (0, 0, 0.15), RPY/xyz = (0, 0, 0) deg


p560.plot(qn, 'zoom', 2.5, 'workspace', [-1.5 1.5 -1.5 1.5 -0.5 1], 'view', [20 20]); axis equal hold on



# Visualize the cylinder

This is the cylinder that we will drill

```
Cy_scale = 0.25;
CY_pose = transl([-0.3 0.3 -0.35]) * troty(-pi/6) * trotx(-pi/6);
V_cy_drill = CY_pose * [Cy_scale .* V_cy'; ones(1, length(V_cy))];
FVsPlot(F_cy,V_cy_drill(1:3,:)',[0 1 0])
```



### Visualize the other cylinder


This are the cylinders that we will weld

The first one is the main cylinder

```
Cy_scale2 = 0.25;
CY_pose2 = transl([0.3 0.3 -0.35]) * troty(pi/6) * trotx(-pi/6);
V_cy_drill2 = CY_pose2 * [Cy_scale2 .* V_cy'; ones(1,length(V_cy))];
FVsPlot(F_cy, V_cy_drill2(1:3, :)', [0 1 0])
```

This second one is the welded cylinder

```
Cy_scale3 = 0.2;
CY_pose3 = CY_pose2 * transl(0,0,0.6) * trotx(pi/2) * troty(-pi/4) * transl(0,0,-0.25);
V_cy_drill3 = CY_pose3 * [Cy_scale3 .* V_cy'; ones(1,length(V_cy))];
FVsPlot(F_cy, V_cy_drill3(1:3,:)', [0 0 1])
```



### Draw drill task profile

Drill hole center 'D\_h\_c'

```
D_h_c = CY_pose * transl(0,0,0.6) * trotx(-pi/2) * troty(-pi/4) * transl(0,0,-0.25);
```

#### Drill poses

```
n=60


n = 60

for i=1:n
Drill_Pose(:,:,i)= D_h_c*trotz(2*pi*i/n)*transl(radius, 0,0);
end
```

### Plotting Drill poses. Notice 'z' axis of the poses

```
cir=transl(Drill_Pose)'
cir = 3 \times 60
   -0.2849
            -0.2785
                      -0.2740
                                -0.2715
                                          -0.2709
                                                    -0.2723
                                                              -0.2757
                                                                        -0.2809 ...
             0.5459
   0.5583
                       0.5325
                                 0.5181
                                           0.5030
                                                     0.4872
                                                               0.4710
                                                                         0.4545
    0.2587
             0.2430
                       0.2276
                                 0.2126
                                           0.1981
                                                     0.1844
                                                               0.1716
                                                                         0.1598
hold on
plot3(cir(1,:), cir(2,:), cir(3,:),'r','LineWidth',3);
```


```
%axis([-1.5 1.5 -1.5 1.5 -0.5 1])
axis equal
trplot(Drill_Pose(:,:,1), 'length',0.2, 'arrow')
trplot(Drill_Pose(:,:,15), 'length',0.2, 'arrow')
trplot(Drill_Pose(:,:,30), 'length',0.2, 'arrow')
trplot(Drill_Pose(:,:,45), 'length',0.2, 'arrow')
```



## Recording the drilling task

```
Q = p560.ikine6s(Drill_Pose, 'run');
p560.plot(Q, 'view', [20 20], 'zoom', 1.5, 'workspace', [-1.5 1.5 -1.5 1.5 -0.5 1], ...
   'trail', '-', 'jaxes', 'zoom', 2, 'movie', 'Puma_drilling_task.mp4')
```

Animate: saving video --> Puma\_drilling\_task.mp4 with profile 'MPEG-4'



### Draw welding task profile

Welding hole center 'W\_h\_c'


#### Generating points

```
r=0.2;
t=0:pi/16:2*pi;
cp0=[r*cos(t);r*sin(t);abs(r*cos(t));ones(1,length(t))]
cp0 = 4 \times 33
    0.2000
              0.1962
                        0.1848
                                  0.1663
                                            0.1414
                                                      0.1111
                                                                0.0765
                                                                          0.0390 ...
        0
              0.0390
                        0.0765
                                  0.1111
                                            0.1414
                                                      0.1663
                                                                0.1848
                                                                          0.1962
   0.2000
              0.1962
                        0.1848
                                  0.1663
                                            0.1414
                                                      0.1111
                                                                0.0765
                                                                          0.0390
    1.0000
              1.0000
                        1.0000
                                  1.0000
                                            1.0000
                                                      1.0000
                                                                1.0000
                                                                          1.0000
```

#### Plotting Welding poses

```
% Translation of the welding
T0 = transl(0.5, 0.5, 0.2) * trotz(pi/4) * troty(-pi/4) * transl(0, 0, -0.1);
```

```
cp1 = T0 * cp0;
% Draws the welding
scatter3(cp1(1,:), cp1(2,:), cp1(3,:),'.', 'm', 'LineWidth', 2)
% Reference frame
trplot(T0, 'length', 0.2, 'arrow')
T1 = T0 * transl(0, 0.2, 0) * troty(pi) * trotx(pi/4);
trplot(T1, 'length', r/2, 'arrow', 'width', 0.5, 'color','r')
T2 = T0 * transl(-0.141421, 0.141421, 0.141421) * troty(pi) * trotz(-pi/4) * trotx(pi/4);
trplot(T2, 'length', r/2, 'arrow', 'width', 0.5, 'color','r')
T3 = T0 * transl(-0.2, 0, 0.2) * troty(pi) * trotz(-pi/2) * trotx(pi/4);
trplot(T3, 'length', r/2, 'arrow', 'width', 0.5, 'color', 'r')
T4 = T0 * transl(-0.141421, -0.141421, 0.141421) * trotz(-pi/4) * trotx(-3*pi/4);
trplot(T4, 'length', r/2, 'arrow', 'width', 0.5, 'color','r')
T5 = T0 * transl(0, -0.2, 0) * trotx(-3*pi/4);
trplot(T5, 'length', r/2, 'arrow', 'width', 0.5, 'color','r')
T6 = T0 * transl(0.141421, -0.141421, 0.141421) * trotz(pi/4) * trotx(-3*pi/4);
trplot(T6, 'length', r/2, 'arrow', 'width', 0.5, 'color','r')
T7 = T0 * transl(0.2, 0, 0.2) * troty(pi) * trotz(pi/2) * trotx(pi/4);
trplot(T7, 'length', r/2, 'arrow', 'width', 0.5, 'color','r')
T8 = T0 * transl(0.141421, 0.141421) * troty(pi) * trotz(pi/4) * trotx(pi/4);
trplot(T8, 'length', r/2, 'arrow', 'width', 0.5, 'color','r')
```



```
Welding_Pose(:,:,1) = T1;
Welding_Pose(:,:,2) = T2;
Welding_Pose(:,:,3) = T3;
Welding_Pose(:,:,4) = T4;
Welding_Pose(:,:,5) = T5;
Welding_Pose(:,:,6) = T6;
Welding_Pose(:,:,7) = T7;
Welding_Pose(:,:,8) = T8;
Q = p560.ikine6s(Welding_Pose, 'run');
Warning: point not reachable
%p560.plot(Q,'view',[150 45], 'zoom',1.5,'workspace', [-1 0.5 -0.5 0.5 -1 1])
```

## Recording the welding task

```
% Q = p560.ikine6s(Welding_Pose, 'run');
% p560.plot( Q,'view',[150 45], 'zoom',1.5,'workspace', [-1 0.5 -0.5 0.5 -1 1],...
```

```
% 'trail','-','jaxes','zoom',2,'movie','Puma_welding_task.mp4')
```


### **Only Welding points**

```
figure
T0 = transl(0.5, 0.5, 0.2) * trotz(pi/4) * troty(-pi/4) * transl(0, 0, -0.1);
cp1 = T0 * cp0;
scatter3(cp1(1,:), cp1(2,:), cp1(3,:),'.', 'm', 'LineWidth', 2)

hold on

% Reference point
trplot(T0, 'length', 0.2, 'arrow')

trplot(T1, 'length', r/2, 'arrow', 'width', 0.5, 'color','r')
trplot(T2, 'length', r/2, 'arrow', 'width', 0.5, 'color','r')
trplot(T3, 'length', r/2, 'arrow', 'width', 0.5, 'color','r')
trplot(T4, 'length', r/2, 'arrow', 'width', 0.5, 'color','r')
trplot(T5, 'length', r/2, 'arrow', 'width', 0.5, 'color','r')
trplot(T6, 'length', r/2, 'arrow', 'width', 0.5, 'color','r')
trplot(T7, 'length', r/2, 'arrow', 'width', 0.5, 'color','r')
trplot(T8, 'length', r/2, 'arrow', 'width', 0.5, 'color','r')
```



### **Functions**

```
function T_b_a=FVsPlot(F,V,color)
patch('Faces',F,'Vertices',V,'FaceColor',color, ...
```

```
'FaceAlpha',0.8,...
'EdgeColor', 'none', ...
'FaceLighting', 'gouraud', ...
'AmbientStrength', 0.15);

% Add a camera light, and tone down the specular highlighting camlight('headlight'); material('dull');

grid on xlabel 'X [mm]' ylabel 'Y [mm]' zlabel 'Z [mm]' axis equal end
```