

- Prepare the M3x40 screw and cable-holder from the previous step.
- Drive the screw all the way through the printed part.
- \bigwedge Note there is a recess (slot) for the screw's head on one side of the printed part.

