

- Make sure the hotend thermistor cables (thinner pair) are going above the heater cables. If not, guide them according to the picture.
- Guiding the thermistor cables below the heater cables may cause issues later.

