

- Take the M3n nut and insert it all the way to the support. It is crucial!
- i Use the screw pulling technique.
- Place the support on the extruder and ensure the inclined part is facing "down" (towards the nozzle)
- Secure the support using an M3x10 screw.

