

- Prepare M3x18 screws (3x)
- Prepare the motor for X-axis with an assembled pulley.
- Place the X-axis on the motor as shown in the picture.
- Insert the M3x18 screws and tighten them so that their positions are at the back of the oval hole like in the picture.

