

- This is the most important and hardest chapter, take your time, don't rush. Properly assembled extruder is essential.
- The bag with fasteners includes M3x20 and M3x18 screws make sure you won't mix them! Pay attention to the instructions, when to use the M3x20.
- **Keep the magnets apart in a sufficient distance.** They can break each other!
- The hotend for MK3S+ needs a shorter PTFE tube compared to the MK3S (more info at help.prusa3d.com/PTFE-MK3S+).
- Pay great attention to the cable management, if you miss some important step you would need to disassemble the extruder.
- This bag includes extra fasteners. Don't worry if you finish with few unused screws and nuts.

