

- Use the three M3x14 screws to fix the fan in place. Don't over tighten them, you can break the fan's plastic casing. Also make sure the fan can rotate freely.
- Note that the screws are "self-tapping" in the printed parts. There are no nuts.
- Leave the last hole empty, for now.
- Now, go to Extruder-idler parts preparation (both fan versions)

