

- For the following step, please prepare:
- Trapezoidal nut (2x)
- M3x18 screw (4x)
- ▲ M3n nut (4x)
- Turn the X-axis upside down and insert nuts into traps on both X-ends.
- in case you can't press the nuts in, don't use excessive force. First, check that there isn't any obstacle in the nut trap.

