

ctrlX I/O

System Module XI812101

Copyright

© Bosch Rexroth AG 2024

All rights reserved, also regarding any disposal, exploitation, reproduction, editing, distribution, as well as in the event of applications for industrial property rights.

Disclaimer

The data specified above only serve to describe the product. As our products are constantly being further developed, no statements concerning a certain condition or suitability for a certain application can be derived from our information. The information given does not release the user from the obligation of own judgment and verification. It must be remembered that our products are subject to a natural process of wear and aging.

DC-AE/PAX (TaDo)/(PiaSt)

Table of contents

1	About this documentation	4
2	Important information	4
2.1	Product information	4
2.2	Firmware versioning	4
2.3	Firmware	4
2.4	Firmware update via FoE	5
2.4.1	ctrlX I/O Engineering	5
3	XI812101-V1.6.0	5
3.1	Note about the new functions	5
3.2	Resolved defects and modifications	6
3.2.1	Bug 699222: "Complete Access" to CoE objects incorrect	6
3.2.2	Bug 946554: Saving the "Configured Station Alias" fails	6
4	Service and support	7
5	Index	9

1 About this documentation

Editions of this documentation

Edition	Release date	Notes
01	2024-11	ctrlX I/O, system module XI812101: Version XI812101-V1.6.0

Further information

- See ➔ [XI8 System Modules](#)

2 Important information

2.1 Product information

For the latest information on our products, go to ➔ <https://www.boschrexroth.com>.

For current security advisories, please refer to ➔ <https://psirt.bosch.com/security-advisories/>

ctrlX I/O modules use the EtherCAT® technology.

EtherCAT® is a registered trademark and patented technology licensed by the Beckhoff Automation GmbH, Germany.

EtherCAT is an open, internationally standardized standard and developed further by the EtherCAT Technology Group (ETG).

2.2 Firmware versioning

The ctrlX I/O firmware is versioned according to the following naming structure: MAJOR.MINOR.PATCH

- **MAJOR:**
Is increased in case of incompatible changes or function extensions. It is required to download a new version of the ESI device description file.
- **MINOR:**
Downward-compatible functional changes or bugfixes. It can be required to download a new version of the ESI device description file. Please check if this is necessary. The MINOR version number is always integer for released versions. Odd-numbered MINOR version numbers refer to test version which have not finally been released.
- **PATCH:**
Downward-compatible bugfixes. It can be required to download a new version of the ESI device description file. Please check if this is necessary.

2.3 Firmware

Table 1: Delivery status of active boost terminal

Index	Version	Remark
AA1	1.2.1	First edition
N.N.	1.6.0	Only available as FW upate.

Only the specified versions of the module have been published until now. Following a firmware update, the version ID deviates from the change ID.



2.4 Firmware update via FoE

⚠ WARNING**Risk of injury due to unsafe machine states**

The machine has to be in a safe state before updating.

The firmware of the module can be updated via FoE. For new firmware files, go to ➔ www.boschrexroth.com/mediadirectory and search for the type code of the module.

A firmware module can be updated with all EtherCAT masters supporting the file download via FoE. The module has to be in the BOOTSTRAP state. Entering a password or a file name is not required.

If the update has been completed successfully, the module is restarted as soon as the module state changes from BOOTSTRAP to another state. The reloaded firmware is started.



Do not disconnect the voltage supply of the module during the file transfer.

Please note that the logic voltage supply is temporarily interrupted for the following modules when completing the firmware update of the bus coupler and a subsequent restart.



If switching to INIT is not possible, disconnect the ctrlX I/O from the power supply and connect it again.



The new firmware version might require an updated description file in the Engineering to use new functions. For details, refer to the release notes. Check whether the latest version of the description file is installed.

2.4.1 ctrlX I/O Engineering

Within the ctrlX I/O Engineering, the required user interface is only displayed for modules supporting a firmware update.

1. ➔ Switch the EtherCAT master of the ctrlX CORE to the "INIT" state.
2. ➔ First change to the active state in the ctrlX I/O Engineering by enabling "Show online data".
 - ➔ This is the requirement to update the firmware. The corresponding user interface tab is only displayed if the requirement is met.
3. ➔ To open the device editor, double-click on the module in the ctrlX I/O Engineering device tree and select the "FoE". tab.
4. ➔ In the "Download" section, select the firmware file (*.EFW) under "Local file name". Ensure that this is the correct file for the module to be updated.
5. ➔ Check that the option "Required state" is active under "Details" and that "BOOTSTRAP" is selected.
6. ➔ Use the "Download" button to start the firmware update.

3 XI812101-V1.6.0

3.1 Note about the new functions

NOTICE

To use the new features of this version, you must use the latest version of the device description file (revision 00010100(hex)).

Check and update the description file if necessary.

3.2 Resolved defects and modifications

3.2.1 Bug 699222: "Complete Access" to CoE objects incorrect

Description

Access via "Complete Access" to a complete CoE object only worked for the first subindex.

Bugfix

"Complete Access" now works as expected.

3.2.2 Bug 946554: Saving the "Configured Station Alias" fails

Description

The "Configured Station Alias" written in the module was not saved in the module. The date was reset to the default value after a restart.

Bugfix

The value is now saved correctly and loaded when the module is started.

4 Service and support

Our worldwide service network provides an optimized and efficient support. Our experts provide you with advice and assistance. You can contact us **24/7**.

Service Germany

Our technology-oriented Competence Center in Lohr, Germany, is responsible for all your service-related queries for electric drive and controls.

Contact the **Service Hotline** and **Service Helpdesk** under:

Phone: **+49 9352 40 5060**

Fax: **+49 9352 18 4941**

Email: [↗ service.svc@boschrexroth.de](mailto:service.svc@boschrexroth.de)

Internet: [↗ http://www.boschrexroth.com](http://www.boschrexroth.com)

Additional information on service, repair (e.g. delivery addresses) and training can be found on our internet sites.

Service worldwide

Outside Germany, please contact your local service office first. For hotline numbers, refer to the sales office addresses on the internet.

Preparing information

To be able to help you more quickly and efficiently, please have the following information ready:

- Detailed description of malfunction and circumstances
- Type plate specifications of the affected products, in particular type codes and serial numbers
- Your contact data (phone and fax number as well as your e-mail address)

5 Index

1, 2, 3 ...

"Complete Access" to CoE objects incorrect. . . 6

A

About this documentation. 4

B

Bug 699222. 6

Bug 946554. 6

F

Firmware versioning. 4

H

Helpdesk. 7

Hotline. 7

I

Important information. 4

N

Note about the new functions. 5

P

Product information. 4

R

Resolved defects and modifications. 6

S

Saving the "Configured Station Alias" fails. . . . 6

Service hotline. 7

Support. 7

Bosch Rexroth AG
Bgm.-Dr.-Nebel-Str. 2
97816 Lohr a.Main
Germany
Tel. +49 9352 18 0
Fax +49 9352 18 8400
www.boschrexroth.com/electrics

